

AQ-L3x9

Line differential protection device

Instruction manual



Table of contents

| | |
|---|-----|
| 1 Document information | 4 |
| 2 Safety information | 6 |
| 3 Abbreviations | 7 |
| 4 General | 9 |
| 5 IED user interface | 10 |
| 5.1 Front panel | 10 |
| 5.2 LED assignment | 11 |
| 5.3 Touch screen | 11 |
| 5.4 The embedded web server | 20 |
| 5.4.1 Ethernet connections | 21 |
| 5.4.2 Getting started | 25 |
| 5.4.3 Menu items | 27 |
| 5.4.4 Troubleshooting | 37 |
| 6 Software setup | 38 |
| 6.1 Functions included in AQ-L3x9 | 38 |
| 6.2 Measurements | 39 |
| 6.2.1 Current measurement and scaling | 39 |
| 6.2.2 Voltage measurement and scaling | 42 |
| 6.2.3 Line measurement | 46 |
| 6.3 Protection functions | 52 |
| 6.3.1 Three-phase instantaneous overcurrent protection ($I>$; 50/51) | 52 |
| 6.3.2 Residual instantaneous overcurrent protection ($I0>$; 50N/51N) | 54 |
| 6.3.3 Three-phase time overcurrent protection ($I>$; 50/51) | 55 |
| 6.3.4 Residual time overcurrent protection ($I0>$; 50N/51N) | 64 |
| 6.3.5 Three-phase directional overcurrent protection ($I_{dir}>$; 67) | 66 |
| 6.3.6 Residual directional overcurrent protection ($I0_{dir}>$; 67N) | 69 |
| 6.3.7 Current unbalance protection (60) | 72 |
| 6.3.8 Circuit breaker failure protection (CBFP; 50BF/52BF) | 74 |
| 6.3.9 Overvoltage protection ($U>$; 59) | 76 |
| 6.3.10 Undervoltage protection ($U<$; 27) | 76 |
| 6.3.11 Residual overvoltage protection ($U0>$; 59N) | 77 |
| 6.3.12 Thermal overload protection ($T>$; 49) | 78 |
| 6.3.13 Line differential protection (87L) – transformer not in protected zone | 80 |
| 6.3.14 Line differential protection (87L) – transformer in protected zone | 86 |
| 6.3.15 Overfrequency protection ($f>$; 81O) | 109 |
| 6.3.16 Underfrequency protection ($f<$; 81U) | 110 |
| 6.3.17 Rate-of-change of frequency protection ($fd/ft>/<$; 81R) | 111 |
| 6.3.18 Pole slip (78) | 112 |
| 6.3.19 Teleprotection (85) | 119 |
| 6.3.20 Inrush current detection (68) | 126 |
| 6.3.21 Stub protection | 127 |
| 6.3.22 Distance protection | 129 |
| 6.4 Control, monitoring and measurements | 144 |
| 6.4.1 Common function | 144 |
| 6.4.2 Trip logic (94) | 147 |
| 6.4.3 Dead line detection (DLD) | 149 |
| 6.4.4 Voltage transformer supervision (VTS) | 151 |
| 6.4.5 Current transformer supervision (CTS) | 153 |
| 6.4.6 Synchrocheck ($dV/da/df$; 25) | 154 |
| 6.4.7 Auto-reclosing (MV) (79) | 161 |
| 6.4.8 Auto-reclosing (HV) (79) | 166 |
| 6.4.9 Switch-on-to-fault | 173 |

| | |
|--|------------|
| 6.4.10 Voltage variation (voltage sag and swell) | 175 |
| 6.4.11 Disturbance recorder | 177 |
| 6.4.12 Event recorder | 179 |
| 6.4.13 Measured values | 183 |
| 6.4.14 Status monitoring for switching devices | 185 |
| 6.4.15 Trip circuit supervision | 185 |
| 7 Line differential communication applications | 186 |
| 7.1 Peer-to-peer communication | 186 |
| 7.2 Pilot wire application | 187 |
| 7.3 Line differential communication via telecom networks | 188 |
| 7.4 Redundant line differential communication | 190 |
| 7.5 Three terminal line differential communication | 191 |
| 8 System integration | 192 |
| 9 Connections | 193 |
| 9.1 Block diagrams | 193 |
| 9.2 Connection example | 194 |
| 10 Construction and installation | 196 |
| 10.1 Construction | 196 |
| 10.2 CPU module | 197 |
| 10.3 Power supply module | 198 |
| 10.4 Binary input module(s) | 199 |
| 10.5 Binary output module(s) | 200 |
| 10.6 Tripping module | 201 |
| 10.7 Voltage measurement module | 202 |
| 10.8 Current measurement module | 203 |
| 10.9 Installation and dimensions | 204 |
| 11 Technical data | 207 |
| 11.1 Protection functions | 207 |
| 11.2 Control functions | 211 |
| 11.3 Monitoring functions | 212 |
| 11.4 Hardware | 212 |
| 11.5 Tests and environmental conditions | 214 |
| 12 Ordering information | 216 |
| 13 Contact and reference information | 217 |

Disclaimer

Please read these instructions carefully before using the equipment or taking any other actions with respect to the equipment. Only trained and qualified persons are allowed to perform installation, operation, service or maintenance of the equipment. Such qualified persons have the responsibility to take all appropriate measures, including e.g. use of authentication, encryption, anti-virus programs, safe switching programs etc. necessary to ensure a safe and secure environment and usability of the equipment. The warranty granted to the equipment remains in force only provided that the instructions contained in this document have been strictly complied with.

Nothing contained in this document shall increase the liability or extend the warranty obligations of the manufacturer Arcteq Relays Ltd. The manufacturer expressly disclaims any and all liability for any damages and/or losses caused due to a failure to comply with the instructions contained herein or caused by persons who do not fulfil the aforementioned requirements. Furthermore, the manufacturer shall not be liable for possible errors in this document.

Please note that you must always comply with applicable local legislation and regulations. The manufacturer gives no warranties that the content of this document is in all respects in line with local laws and regulations and assumes no liability for such possible deviations.

You are advised to notify the manufacturer in case you become aware of any errors in this document or of defects in the equipment.

The manufacturer reserves the right to update or amend this document at any time.

Copyright

Copyright © Arcteq Relays Ltd. 2023. All rights reserved.

1 Document information

Table. 1 - 1. History of Revision 1.

| | |
|----------|--|
| Revision | 1.00 |
| Date | November 2010 |
| Changes | <ul style="list-style-type: none"> The first revision of the manual. |
| Revision | 1.01 |
| Date | January 2011 |
| Changes | <ul style="list-style-type: none"> HW construction and application drawing revised. |
| Revision | 1.02 |
| Date | February 2011 |
| Changes | <ul style="list-style-type: none"> Directional earth fault function revised. Synchrocheck function revised. Voltage measurement module revised. CPU module description added. Binary input module description revised. IRIG-B information added. Voltage variation (sag and swell) function added. Ordering information and type designation updated. Technical data revised. |
| Revision | 1.03 |
| Date | March 2012 |
| Changes | <ul style="list-style-type: none"> The "Line differential communication applications" chapter added. |
| Revision | 1.04 |
| Date | July 2012 |
| Changes | <ul style="list-style-type: none"> Line differential with transformer in protected zone added. MHO characteristics added. Synchrocheck parameters updated. Technical data updated. Order code updated. |
| Revision | 1.05 |
| Date | February 2015 |
| Changes | <ul style="list-style-type: none"> Current and voltage measurement descriptions revised. |
| Revision | 1.06 |
| Date | March 2015 |

| | |
|-----------------|--|
| Changes | <ul style="list-style-type: none"> • Description for trip logic revised. • Description for the common function added. • Description for the line measurements function added. |
| Revision | 1.07 |
| Date | May 2018 |
| Changes | <ul style="list-style-type: none"> • The separated parameters for phase-to-phase and phase-to-earth fault detection (distance) added. |
| Revision | 1.09 |
| Date | December 2019 |
| Changes | <ul style="list-style-type: none"> • The "Construction and installation" chapter updated. |

Table. 1 - 2. History of Revision 2.

| | |
|-----------------|--|
| Revision | 2.00 |
| Date | February 2023 |
| Changes | <ul style="list-style-type: none"> • Updated the Arcteq logo on the cover. • An overall visual update for the manual's layout and design. • Added the "Safety information" chapter. • Added the "Abbreviations" chapter. • Added the previously separate documents "AQ 300 Operator's manual" and "AQ 300 Web server description" into the "IED user interface" chapter. • Various images updated. • Updated contact and reference information. |

2 Safety information

This document contains important instructions that should be saved for future use. Read the document carefully before installing, operating, servicing, or maintaining this equipment. Please read and follow all the instructions carefully to prevent accidents, injury and damage to property.

Additionally, this document contains four (4) types of special messages to call the reader's attention to useful information as follows:

**NOTICE!**

"Notice" messages indicate relevant factors and conditions to the the concept discussed in the text, as well as to other relevant advice.

**CAUTION!**

"Caution" messages indicate a potentially hazardous situation which, if not avoided, **could** result in minor or moderate personal injury, in equipment/property damage, or software corruption.

**WARNING!**

"Warning" messages indicate a potentially hazardous situation which, if not avoided, **could** result in death or serious personal injury as well as serious damage to equipment/property.

**DANGER!**

"Danger" messages indicate an imminently hazardous situation which, if not avoided, **will** result in death or serious personal injury.

These symbols are added throughout the document to ensure all users' personal safety and to avoid unintentional damage to the equipment or connected devices.

Please note that although these warnings relate to direct damage to personnel and/or equipment, it should be understood that operating damaged equipment may also lead to further, indirect damage to personnel and/or equipment. Therefore, we expect any user to fully comply with these special messages.

3 Abbreviations

| | |
|------|------------------------------------|
| AC | alternating current |
| AVR | automatic voltage regulator |
| CB | circuit breaker |
| CBFP | circuit breaker failure protection |
| CPU | central processing unit |
| CT | current transformer |
| CTS | current transformer supervision |
| CVT | capacitive voltage transformer |
| DC | direct current |
| DI | digital input(s) |
| DLD | dead line detection |
| DO | digital output(s) |
| EFT | electronic fast transients |
| EMC | electromagnetic compatibility |
| EOB | Ethernet Overboard |
| ESD | electrostatic discharge |
| HMI | human—machine interface |
| IDMT | inverse definite minimum time |

| | |
|--------------|--|
| IED | intelligent electronic device |
| IO | inputs and outputs |
| LCD | liquid-crystal display |
| LED | light-emitting diode |
| NC | normally closed |
| NO | normally open |
| NTP | Network Time Protocol |
| RF | radio frequency |
| RCA | relay characteristic angle |
| RMS | root mean square |
| SCADA | supervisory control and data acquisition |
| SDRAM | synchronous dynamic random access memory |
| SLD | single-line diagram |
| SOTF | switch-on-to-fault |
| TMS | time multiplier setting |
| VT | voltage transformer |
| VTs | voltage transformer supervision |

4 General

The AQ-L3x9 line protection IED is a member of the AQ-300 product line. The AQ-300 protection product line in respect of hardware and software is a modular device. The hardware modules are assembled and configured according to the application IO requirements and the software determines the available functions. This manual describes the specific application of the AQ-L3x9 line protection IED.

Arcteq protection IED can be ordered in two mechanical sizes. The AQ-L359 comes in half of 19 inch rack arrangement and the AQ-L399 comes in full 19 inch rack arrangement allowing for larger quantity of IO cards. The functionality is the same in both units.

5 IED user interface

5.1 Front panel

The figure below presents the front panel structure for AQ-300 series units, while the table below the image describes the functions of the front panel's various elements.

Figure. 5.1 - 1. AQ-300 front panel structure.




Table. 5.1 - 3. Elements of the front panel.

| Function | Description |
|-----------------------|--|
| Device LED | One (1) three-colored circular LED. <ul style="list-style-type: none">• Green = normal operation• Yellow = warning state• Red = alarm state |
| COM LED | One (1) yellow circular LED, which indicates the EOB communication link and activity. |
| User LEDs | Three-colored circular LEDs. Their number depends on the relay model. |
| LED description label | A changable label with LED functionality descriptions. |
| Optical interface | (for factory usage) |
| EOB connector | Ethernet Overboard communication interface. It attains an isolated and non-galvanic Ethernet connection with the help of a magnetic EOB device. The EOB device has an RJ-45 type connector which supports 10Base-T Ethernet connection to the user's computer. |
| Touch screen | The main screen, a 3.5" (320 x 240 pixels) portrait-oriented TFT display with a resistive touch screen interface. Optionally, the touch screen can be 5.7" and landscape-oriented. |

| Function | Description |
|-------------------|--|
| Operation buttons | <p>The device has four (4) capacitive operational buttons:</p> <ul style="list-style-type: none"> • "X" (below the LED label) latches and resets the LEDs. • The button with a blue icon (top right) changes the touch screen menus. • "ON" and "OFF" (bottom right). <p>Pushing a button causes an audible buzzer pressure feedback. All four buttons also have an LED off their top-left corner to indicate their status.</p> |

5.2 LED assignment

On the front panel of the device there is user LEDs with the "Changeable LED description label". Some LEDs are factory assigned, some are free to be defined by the user. Table below shows the LED assignment of the AQ-L3x9 factory configuration.

Table. 5.2 - 4. The LED assignment of AQ-L3x9.


| LED | Explanation |
|--------------|--|
| Gen. Trip | Trip command generated by the TRC94 function |
| OC trip | Trip command generated by the phase overcurrent function |
| OCN trip | Trip command generated by the residual overcurrent protection function |
| Therm. Trip | Trip command of the line thermal protection function |
| Unbal. Trip | Trip command of the current unbalance protection function |
| Inrush | Inrush current detected |
| Voltage trip | Trip command generated by the voltage-related functions |
| Frequ trip | Trip command generated by the frequency-related functions |
| REC blocked | Blocked state of the automatic reclosing function |
| Reclose | Reclose command of the automatic reclosing function |
| Final trip | Final trip command at the end of the automatic reclosing cycles |
| LED 312 | Free LED |
| LED 313 | Free LED |
| LED 314 | Free LED |
| LED 315 | Free LED |
| LED 316 | Free LED |

5.3 Touch screen

The touch screen comes with a variety of powerful features, including the ability to make customized menus. It also supports single-line diagrams (SLD). The touch screen can be accessed and controlled remotely via the device's web interface. For more information on the remote user interface, please refer to "The embedded web server" chapter below.

The image below depicts the main screen of the front panel as well as the "ON", "OFF" and "Change screen" buttons.

Figure. 5.3 - 2. The main menu and three operation buttons.



The touch screen is the main control where you can enable functions and input values.

The "Change screen" button changes the menu shown on the main display. The menus are in the following order by default: the main menu, the parameter menu, the online measurement menu, the events menu, and the system settings menu. You can also add a number of customized menus which can be created with EuroCAP software. Pushing the button moves the displayed menu by one, in a cycle.

The operation buttons can be used to define certain functions on customer-defined menus. For example, you can set up these buttons to turn a circuit breaker on or off, or to increment and decrement the position of a transformer's tap changer. For more information, please refer to the "Custom user-defined menus" chapter.

Main menu

The main menu is the first one shown when the device is turned on. It displays general information such as the device and station names, the current time, and language options (when available).

Figure. 5.3 - 3. Lock status indicator, as displayed in the main menu.



Lock status indicator

The **lock status indicator** shows whether a password is required to unlock the device before parameters or settings can be changed. By default, the device is not password-protected. However, if such a functionality is needed, you can set the password application via the web interface.



NOTICE!

The password cannot be set with the touch screen.

When a device is protected by a password, push the lock icon. This brings up a password input screen (see the image below) where you can enter the password. When the password is entered correctly, the lock status indicator on the main menu becomes unlocked, as does the menu in question. The device can be unlocked from any of the menus.

Figure. 5.3 - 4. The password input screen.

**NOTICE!**

The lock icon is displayed even when the device has no password!

Parameter menu

In the parameters menu (below) you can view, set and edit certain parameters within the device. You can also choose which of the parameter sets the device uses.


The parameter set that is currently active has a red box around it (see the figure below). When you want to edit or activate a parameter set, touching its name to select and highlight it and then press the "Edit" or "Activate" button.

Figure. 5.3 - 5. The parameter set menu.



The **Activate** button activated the selected parameter set, which the device will now use. Depending on the device's configuration, the "Activate" button may not be available. The **Edit** button takes you to another screen where you can choose which function blocks the parameter set uses. Please note that when there is only one parameter set, the device takes you immediately to the parameter set edit screen (below).

Figure. 5.3 - 6. The parameter set edit screen (left) and the function block screen (right).



Normally, the various function blocks appear blue. However, if any value has been changed within a function block, its listing appears red to notify the user. This also happens in the function block screen, where unmodified parameter values appear green but modified values appear red.


The **Set** button brings up a screen where you can modify a value. If there is a lock icon instead of the "Set" button, the device must first be unlocked. The **Back** button returns you to the previous screen.

Within all function blocks, the parameter values can have one of the following four types of input:

- Integer
A whole number, entered with the number pad.

- Floating-point number
A number with a decimal point, entered with the number pad. Please note that the pad has the decimal point available only when the value can be entered as a floating-point number!
- List item
The parameter lists the available options as a list, and the user selects the desired option from them.
- Checkbox
The user can enable and disable the parameter as a whole.

Figure. 5.3 - 7. Editing the parameter values.



The new parameter value is put in the "New value" field. The "Current value" field shows the parameter value that is currently in use. The "Min–Max/Step" field shows the range within which the parameter's value can be modified, as well as the step with which the value can be incremented or decremented. For example, in the image above, the range is between 1 000 and 10 000 with a step value of 1. This means that the value can be 1 001, 1 002, 1 003,...,9 999, 10 000. If the step value were 5, the field would only accept values such as 1 005, 1 010, 1 015, and so on.

The **OK button** confirms the value in the "New value" field and returns the user to the previous screen. The **Cancel button** deletes a single digit from the "New value" field. The **Erase button** discards any changes to the current parameter and returns the user to the previous menu item.


**CAUTION!**

Make sure that only one person edits the parameters at any one time, either in the touch screen or in the web interface! Simultaneous editing leads to confusion as to what the values of a parameter set actually are.

Online measurement menu

The online measurement menu displays real-time data depending on what is connected to the device. When you have selected a specific function block from the online functions list, clicking the **View button** takes you to a new window that displays the parameters and their current values. The image below shows the values of VT4 module 2: the voltages and angles for channels U1 and U2.

Figure. 5.3 - 8. Online measurement menu.




Events menu

The events menu displays a list of events that have occurred within and in relation to the device. This menu screen is continuously updated. If the scrollbar on the right is at the bottom, the screen shifts as a new event occurs. However, if the scrollbar is not on the bottom, the screen stays in place even when a new event occurs. This allows you to take a closer look at the events.

The first row of an event displays the function block's name, the second row displays the event's name and value, and the third row displays the event's time stamp (see the image below).


Figure. 5.3 - 9. Event structure.

**NOTICE!**

The events menu does not display the whole event log, only the first few hundred items in the log!

System settings menu

Figure. 5.3 - 10. System settings menu.



In the system settings menu you can set certain parameter values that are related to the device itself (as opposed to its protection functions and operations). The menu works similarly to the parameters menu and the same properties apply.

Table. 5.3 - 5. The system settings.


| Setting | Description |
|--|---|
| System parameters and station bus settings (IP address, netmask, default gateway, DNS servers) | Please contact your local network administrator for further information about these settings. |
| Ethernet communication (IEC 61850 enabled, IEC 104 enabled) | Enables or disables the IEC 61850 and IEC 104 communication protocols. |
| Serial communication | Selects which serial protocol the device uses. The "Serial baudrate" field sets the baudrate to a specific amount. Please note that this and link address only apply to legacy protocols! |
| Time synchronization | When time synchronization via NTP server addresses is enabled, the device uses Network Time Protocol to synchronize time with one of the servers. The device also supports other, non-NTP time synchronization methods, such as pin and serial. |
| Time zone settings | "GMT offset" defines the positive or negative offset for Greenwich Mean Time. "Use DST" and "DST start/stop" define the daylight savings time setting. As DST is different in each country, set these as appropriate. |
| LCD backlight | Changes the brightness of the touch screen's back illumination. |

Custom user-defined menus

You can add menus based on your application needs with the help of the AQtivate 300 software. You can also set up the operation buttons "I" and "O" to perform specific functions.

For example, let us say we have the following network depicted in the top-left image in the figure below as a single-line drawing. We have set the operation buttons to function as "ON" and "OFF", and now we would like to switch the line disconnecter Q2 on.

Figure. 5.3 - 11. Turning on Q2.



(1) First, we press Q2 on the touch screen to highlight the object. This causes Q2 to start blinking for a short while; if an action is not performed within this time, the object deselects on its own. So, while Q2 is highlighted and blinking, we press the "I" button (configured to function as an "ON" button) to turn it on. (2) A window pops up to confirm we want to do this action; again, we have a short time to give an answer (in this case, to press "Yes") before the requested operation is automatically cancelled. (3) Another window pops up to state that the operation was successful. (4) After acknowledging this window, the display is updated as appropriate, with the Q2 line disconnector in the "ON" position.

Just as the online measurement and events menus, this menu is also updated continuously. Therefore, any kind of change in the states or in the measured parameters are shown and updated accordingly. If there is an error with an operation, the device signals the user of this with an error pop-up window that includes the error code and the reason for the error.

5.4 The embedded web server

Introduction

This product offers the ability to remotely monitor and modify various parameters and settings within the device. You can access the front panel and choose other options with the help of a web browser. With the user-friendly interface, you can easily manage the device. Password protection is available to grant certain privileges and access to special functions.

You can perform the following actions with the embedded web server:

- modify user parameters
- check the event list and disturbance records
- manage the password
- display the measured data and the generated binary information
- perform commands

- provide remote or local firmware upgrades
- perform administrative tasks.

System requirements

In order to access the device interface you need a compatible web browser as well as an Ethernet connection. It is recommended that the screen resolution is at least 1024 x 768 so that the screen can display data properly.

You can use any of the following web browsers:

- Microsoft Internet Explorer, version 7.0 or higher
- Mozilla Firefox, version 1.5 or higher (**version 3.0 or higher recommended!**)
- Apple Safari, version 2.0.4 or higher
- Google Chrome, version 1.0 or higher
- Opera, version 9.25 or higher

You must also enable JavaScript within your browser. For security reasons the device is only allowed a limited number of connections over the network.

To access the device via a web browser write the correct IP address on the browser's address bar. You can find the device's IP address on the main menu of the device's touch screen.

5.4.1 Ethernet connections

Properties of the Ethernet connection

An AQ-300 unit has five (5) Ethernet ports built into the device, allowing it to be connected to IP/Ethernet-based networks. The unit has the following Ethernet ports available (the first is located in the front panel, the others on the rear side of the CPU unit):

- Ethernet over board (EOB) 10Base-T user interface
- Station Bus (100Base-FX Ethernet)
- Redundant Station Bus (100Base-FX Ethernet)
- Process Bus (100Base-FX Ethernet, in preparation)
- 10/100Base-Tx port via the RJ45 connector

There are three different types of interfaces for the communication ports:

- The EOB interface is attachable to the device's front panel by a proprietary magnetic connector. The connector box ends in a RJ45 8/8 plug, and the interface is a 10Base-T full duplex interface.
- The 100Base-FX Ethernet interface is of type ST, which offers 1 300 nm/MM for a 50 µm/125 µm (or, 62.5 µm/125 µm) fiber.
- The 10/100Base-Tx Ethernet interface is an RJ45 8/8 plug.


The following table catalogues the different Ethernet communication versions available for the different AQ-300 CPU versions.

Table. 5.4.1 - 6. The available Ethernet communication in different CPU versions.

| CPU version | EOB | Station Bus | Redundant Station Bus | Process Bus | RJ45 | Legacy port/protocol |
|-------------|-----|-------------|-----------------------|-------------|------|----------------------|
| CPU+0001 | Yes | Yes | No | Prep | Yes | No |
| CPU+0002 | Yes | Yes | Yes | Prep | No | No |
| CPU+0003 | Yes | Yes | Yes | No | No | No |

The diagram below depicts the three (3) different CPU versions and their structures:

Figure. 5.4.1 - 12. The three CPU versions.



Settings needed for Ethernet connection

The AQ-300 devices can only be accessed over Ethernet-based communication protocols. This is why it is very important for the network to be set up correctly before accessing the device.

IP settings

The device operates with fixed IPv4 addressing. At the moment dynamically assigned IP addresses are not supported. We recommend using the private address range as defined in RFC 1918. All addresses must be in the same network range. Additionally, the computer should be set to use fixed IP settings.

You can connect to a stand-alone device by plugging the EOB cable into your computer or by using the RJ45 connector at the back of the device (this requires a crossover UTP cable). When you want to connect the device to a station or corporate network, contact the system administrator for all the required information: an available IP address, the gateway address, the netmask, the DNS and NTP server addresses.


Web browser settings

Make sure that your browser does **NOT** use a proxy server while accessing an AQ-300 device. However, if there is a proxy server in your network, contact the system administrator and have them add an exception.

EOB connection

Attach the magnetic EOB connector to the front panel of the device; the magnets assure that the adapter is in the correct position. Next, connect the other end of the cable to a computer's RJ45 port (see the figure below).

Figure. 5.4.1 - 13. Using the EOB connection.




Please note that the RJ45 connector can also be connected to an Ethernet switch. When this is the case, all the network's IEDs with client functionalities (e.g. a computer) have access to the device.

RJ45 connection


As seen in the beginning of this chapter, the CPU version "+0001" also has an integrated RJ4 port. When using a UTP crossover cable with RJ45 connectors at both ends, you can connect the device directly to a computer (see the figure below).

Figure. 5.4.1 - 14. Using the RJ45 connection.



The crossover cable's pinout has been depicted in the diagram below:

Figure. 5.4.1 - 15. The pinout of the crossover cable.




Please note that the cable's RJ45 connector can also be connected to an Ethernet switch. When this is the case, all the network's IEDs with client functionalities (e.g. a computer) have access to the device.

ST-type fiber optic connection

The ST-type fiber optic connector of the 100Base-FX Ethernet provides a connection to an Ethernet switch with an identical fiber optic input. When using this connection, all the network's IEDs with client functionalities (e.g. a computer) have access to the device (see the figure below).


Figure. 5.4.1 - 16. Using the ST-type fiber optic connection to connect computers via an optical Ethernet switch.



5.4.2 Getting started

Make sure you are connected to your AQ-300 device and that you have JavaScript enabled within your web browser. Type the IP address of the device into your browser's address bar to access its embedded web server (see the image below).

Figure. 5.4.2 - 17. Web server elements.




The menu that is currently selected is highlighted in black (in the image above, the main menu is selected). If the content area is too long to fit the browser window, you can scroll down; the menu bar will always be visible as it follows the user.

In some configurations the language that is currently displayed can be changed; to do this, click one of the other available languages represented by flags, located at the top of the touch screen. The page automatically refreshes in the chosen language. Please note that changing the display language only affects the local browser, NOT other browser or the language of the touch screen.

5.4.3 Menu items

Main menu

Figure. 5.4.3 - 18. The main menu and its elements.



In the main menu you can control the device's front panel. The image of a touch screen (located on the right) behaves the same way as the actual touch screen. For more information on the touch screen, please refer to the "Touch screen" subchapter in the "IED user interface" main chapter.

In the "Identification" section of the view, you can change the station name and the device name. Type the desired name in the relevant field and click the **Rename** button.

The "Information" section shows additional information about the device. The uptime fields show how much time has passed since the device was last powered on. The "Station bus MAC address" displays the network card's MAC address, which is a unique identification number assigned by Arcteq (the address range assigned by the IEEE authority). Please note that these fields are read-only and cannot be modified!

Parameters menu

Figure. 5.4.3 - 19. The parameters menu and its elements.

The screenshot shows the 'Parameters' menu with two expandable sections. The top section, 'CT4 module', is expanded and shows parameters: Rated Secondary 11-3 (1A), Rated Secondary 14 (0.2A), Starpoint 11-3 (Line), Starpoint 14 (Normal), Rated Primary 11-3 (500), and Rated Primary 14 (500). The bottom section, 'Current Unbalance', is also expanded and shows: Operation (On), Start Signal Only (On), Start Current (50), and Time Delay (1000). Annotations highlight specific UI elements: 'Modified values appear in orange' points to 'Starpoint 14' and 'Rated Primary 14'; 'Listbox' points to the 'Starpoint 14' dropdown; 'Unit' points to the 'A' unit for 'Rated Primary 14'; 'Range/Step' points to the '(100 - 4000 / 1)' range for 'Rated Primary 14'; 'Textfield' points to the '500' value for 'Rated Primary 14'; and 'Checkbox' points to the 'On' checkbox for 'Start Signal Only'.

You can view and change various parameters and variables in this menu. You can manage the different parameter sets by resetting, renaming, exporting and importing them. You can also apply a password for importing, exporting and setting.

All parameters are part of specific function blocks. You can expand and collapse the individual function block information boxes by clicking the [+] and [-] signs in front of its name. You can also use the button at the top to expand all function blocks, collapse them all, or print out a printer-friendly layout of the function blocks (opens in a new browser window).

The parameter sheet has the following general layout

- The first column contains the name of the parameter. In multilingual devices changing the language also changes this name.
- The second column displays the current values of the selected parameter set stored in the device. Changing the parameter does NOT activate it, it only loads to the fields.
- The third column is used to give parameters user-desired values. When changed, the color changes to blue to draw attention to the change. The expected value range and step are located to the right of the parameter line.

The parameter values are displayed in text fields, checkboxes, or listboxes. All of these can be modified; the name of the parameter whose value has been modified appears in orange, as does the name of the function block (see the image above). When modifying *text fields*, please be mindful of the parameter range and step, although the device does alert the user when an improper value is entered. The new value is displayed in red. *Checkboxes* (Boolean parameter type) enable and disable certain functions and properties; a ticked checkbox means that the parameter is enabled. *Listboxes* (enumerated parameter type) open a drop-down menu with a number of predetermined values. When a value that is not the default is selected, both the letters and the box outline become red.



NOTICE!

A parameter line has the unit between the new value textfield and the range/step information when applicable. Some parameters do not have units!

The parameter values are checked for changes when you navigate away from the parameter page or when you try to load another parameter set. A pop-up window notifies you if you have made changes and try to leave the page without saving them. Clicking **Cancel** returns you to the parameter page, whereas clicking **OK** ignores the changes.

In the "Parameter set" section of the page there are options for managing the parameter sets. The section lists all the available parameter sets, and each can be manipulated with the buttons located on the right of the line.

Figure. 5.4.3 - 20. Managing multiple parameter sets.



With the **Activate** button, you can enable the selected parameter set. The device will now use the values from this set. The **Rename** button, unsurprisingly, renames the selected parameter set. The names can include alphanumeric characters, spaces, dashes and underscores. Please note that two or more parameter sets CANNOT share the same name! The **Save parameters** button saves the selected parameter set in a separate file, which can be loaded into the device at any time.

The **Set parameters** button (located below the menu bar on the left) overwrites the selected parameter set with the values that are on the screen. Note that this only modifies the values of the selected set; to have the device use these values you must also activate the set! You can also set a password that is required before overwriting can be done.

The "Editable fields" section has two buttons. The **Reset to defaults** button replaces the values on the screen with the factory default settings. With the **Load parameters** button you can import values from a parameter set file. These values must be saved after loading by pressing the **Set parameters** button.



NOTICE!

These buttons and functions only appear if the device is configured to have more than one parameter set. The available buttons and functions depend on the configuration.

System settings menu

In the system settings menu you can adjust the miscellaneous device settings. This menu can also be password protected. The text fields, checkboxes and listboxes function the same as in the parameter menu. The column structure is also the same.

The **Set settings** button (located below the menu bar on the left) enabled the device to use the values displayed on the screen at the time the button was clicked. Please note that if the device's IP address has changed, the device must first be accessed through the new IP address.

Figure. 5.4.3 - 21. The system settings menu.




Table. 5.4.3 - 7. The system setting sections and their content.

| Section name | Description |
|------------------------|---|
| Safe settings | If enabled, the device asks you to confirm the saving of new settings by pressing the "I" (ON) button on the device's front panel. Pressing "O" (OFF) discards the changes. This selection must be made within 300 seconds. |
| Power system frequency | Sets the power system frequency. By default it is 50 Hz, can be changed to 60 Hz. CAUTION! Changing this parameter initiates a system restart! |
| Station bus settings | Contains the settings for IPv4-based communication (IP address, mask, gateway, DNS address). The DHCP server function can be switched on with a combo-box. CAUTION! Uncontrolled use of the DHCP server function can cause serious communication failures! |
| Ethernet communication | The device can communicate using several Ethernet-based protocols at the same time. Only IEC 61850 is licensed, other protocols are available by default. You can adjust the T0 time of GOOSE messaging with the GOOSE repeat rate combo-box. |
| Serial communication | Contains the physical parameters for serial communication (only one protocol can be selected!). Note that serial communication requires a proper CPU card! |
| Time synchronization | Contains the settings for a broad range of time synchronization protocols (NTP, serial communication, pulse inputs). If the "Time sync warning" parameter is enabled and the device is not synchronized, an alarm is raised (that is, the "Status" LED becomes yellow). |
| Time zone settings | Contains the settings to offset GMT and to define daylight savings time. |

| Section name | Description |
|---------------|--|
| LCD backlight | Contain the parameters to control the LCD panel's behaviour. The light switches off after its set timeout. The "Backlight group" parameter is useful when you have two or more devices close to each other: touching one switches on all devices that have been configured to belong to the same group. |

Online data menu

Figure. 5.4.3 - 22. The online data menu.

The screenshot displays the 'Online data menu' with three main sections, each with a collapse/expansion toggle ([-] or [+]).

- [-] Common**
 - Mode of device: on
 - Health of device: Ok
 - SystemWarning: ☐
- [-] VT4 module**
 - Voltage Ch - U1: 0.00 V
 - Angle Ch - U1: 0 deg
 - Voltage Ch - U2: 0.00 V
 - Angle Ch - U2: 0 deg
 - Voltage Ch - U3: 0.00 V
 - Angle Ch - U3: 0 deg
 - Voltage Ch - U4: 0.00 V
 - Angle Ch - U4: 0 deg
 - Vector display: A circular vector plot with a scale of 100.0 V.
- [-] CT4 module**
 - Current Ch - I1: 0.00 A
 - Angle Ch - I1: 0 deg
 - Current Ch - I2: 0.00 A
 - Angle Ch - I2: 0 deg
 - Current Ch - I3: 0.00 A
 - Angle Ch - I3: 0 deg
 - Current Ch - I4: 0.00 A
 - Angle Ch - I4: 0 deg
 - Vector display: A circular vector plot with a scale of 1.0 A.


This menu displays the data measured by the device. Each block has their own section, and these sections can be expanded and collapsed individually as needed with the [+] and [-] signs in front of their names. The values on screen are updated every second, which may cause older systems to slow down or halt the browser altogether. All data is strictly read-only, and cannot be modified. If there is a counter on the page, next to it will be a button that resets it.

Binary data is displayed as a checkbox (for example, the "SystemWarning" parameter in the first section in the image above), whereas enumerated data is presented as text information. If you are using a browser compatible with HTML5, analogue measurements are drawn as vectors.

Events menu

This page displays the events that have occurred in the device. The events are listed in the following format: [local time] : [function block] : [channel] : [new value].


Figure. 5.4.3 - 23. Elements of the events menu.



With the **Refresh** button you can refresh the list displaying the events, the **Erase all events** button clears the list on the screen, and the **Export to file** button downloads the events and saves them as a .txt file.

Commands menu

Figure. 5.4.3 - 24. The commands menu.




In the commands menu you can instruct the processor to carry out customized, user-defined commands. You can use the various mode buttons (**On**, **Blocked**, **Test**, **Test/Blocked**, **Off**) and LED buttons (**On**, **Off**) to define functions. A status update is always generated with a command, regardless of whether the command was successful or not. If the command was unsuccessful, the device gives the reason for the error.

Disturbance recorder

This page displays a list of the disturbance records that the device has recorded.


Figure. 5.4.3 - 25. Disturbance recorder.



The "Recorded disturbances" section lists all disturbance records. You can refresh the list with the **Refresh** button to display any new disturbance records that have occurred after the page was opened or refreshed last. You can also clear the list with the **Erase all records** button. Additionally, you can create a disturbance record manually by clicking the **Manual start** button.

There is one record per line. You can download the chosen record by clicking the **Download** button on its line; the device downloads you a COMTRADE file which you can then open with any supporting software for further evaluation. You can also click the **View** button to open a new browser window which then displays a simple preview of the disturbance record (see the image below).


Figure. 5.4.3 - 26. Example of a disturbance record preview.



You can set a setpoint by clicking anywhere on the graph, and the positioning the cursor to a desired second point. The preview then displays the timestamp of the first setpoint, and the time difference between the two setpoints. You can also scale the time axis with the scaling controls (the plus and minus magnifying glasses), or by clicking the **Scale mode** button to switch between standard and scaled modes. The scaled mode stretches the Y axis of all recorded values.

Network protectionHood


Figure. 5.4.3 - 27. The network protectionHood menu.



This page shows all other devices that are located in the same network with the AQ-300 unit. The page identifies compatible devices and displays information about them, such as their IP address and version. The device that is currently accessed is highlighted in red in the list. You are redirected to other devices by clicking their corresponding links. The **Refresh** button scans the network for connected devices.

Documentation

Figure. 5.4.3 - 28. The documentation menu.




This page displays the documentation files on the device. You can upload other documents and files on the device, which are then saved and can be accessed later. One file can be up to 2048K , and there is storage for up to 8 MB of documentation.

The "Embedded documentation" section displays all the documents that have been preloaded into the device. You cannot delete these. The "User documents" section lists all the files the user has uploaded into the device, and you can delete them with the **Delete** button. You can upload a selected file with the **Upload** button. Please ensure that the file size is below the limit and that you have enough storage left before commencing the upload.

Advanced

Figure. 5.4.3 - 29. The Advanced menu.




This menu displays the additional, more advanced options. You can set a password request before a user is allowed access to these options.

Password manager

You can modify and clear the three available passwords. The *master password* is used for accessing the Advanced menu. The *password for settings* is required when a user wants to set parameters or settings, or wants to clear counters in the Online data menu. The *password for control* is required when executing commands in the Commands menu. If no password has been created, you can create one with the **Modify password** button.

Figure. 5.4.3 - 30. Password manager.



Status/log

The Status/log submenu displays information from various logs. The log files are primarily meant for the manufacturer, but a user can also view them.

Figure. 5.4.3 - 31. Status/log.



The **Get report** button generates a .zip file that has all of the log files archived together. The files have valuable information and they can help in analyzing errors and malfunctions; see the table below for the different log types and their contents.

Table. 5.4.3 - 8. Log types.

| Log name | Description |
|----------------|--|
| Relay CPU | Displays the logged events that are connected to the relay's CPU. |
| SPORT | Displays the log file from the SPORT communication interface. |
| System startup | Displays the events that have occurred when the system was started up. |
| Serial Comm | Displays the log file from the serial communication interface. |
| LCD display | Displays the log file about the events that have occurred with the LCD display. |
| IEC 61850 | Displays the log file from the IEC 61850 communication interface. |
| Access | Displays information about the users who have accessed the device remotely through the embedded web browser interface. |
| Error | Displays the errors that have occurred with the remote user interface. |



NOTICE!


All log files are in English, regardless of your language selection!

Update manager

When a new version of the firmware is available, it can be updated in this submenu. Click the **Update** button of the correct section to select the new firmware file and upload it into the device. Please make sure that you are updating the right firmware; for example, do not attempt to update the "Relay DSP firmware" section with a "Comm. DSP firmware" file!

This page also displays information about the firmware currently in use as well as of the configuration of the device.

Figure. 5.4.3 - 32. Update manager.



5.4.4 Troubleshooting

Some browsers have a tendency to handle and cache various JavaScript function improperly, and this may cause anomalies and errors in the interface. If you notice improper functionalities, try to clear both the browser history and cache, and refresh the web page.

If this does not clear the problem, please contact Arcteq for further instructions.

6 Software setup

6.1 Functions included in AQ-L3x9

In this chapter are presented the protection and control functions as well as the monitoring functions.

The implemented protection functions are listed in the table below. The function blocks are described in detail in following chapters.

Table. 6.1 - 9. Available protection functions

| Function Name | IEC | ANSI | Description |
|---------------------------|---------------------|------|--|
| IOC50 | I >>> | 50 | Three-phase instantaneous overcurrent protection |
| TOC50_low TOC50_high | I> I>> | 51 | Three-phase time overcurrent protection |
| IOC50N | I0 >>> | 50N | Residual instantaneous overcurrent protection |
| TOC51N_low TOC51N_high | I0> I0>> | 51N | Residual time overcurrent protection |
| TOC67_low TOC67_high | Idir > Idir >> | 67 | Directional three-phase overcurrent protection |
| TOC67N_low TOC67N_high | I0dir > I0dir >> | 67N | Directional residual overcurrent protection |
| INR2 | I _{2h} > | 68 | Inrush detection and blocking |
| VCB60 | I _{ub} > | 46 | Current unbalance protection |
| TTR49L | T > | 49L | Line thermal overload protection |
| TOV59_low TOV59_high | U > U >> | 59 | Definite time overvoltage protection |
| TUV27_low TUV27_high | U < U << | 27 | Definite time undervoltage protection |
| TOV59N_low TOV59N_high | U0> U0>> | 59N | Residual voltage protection |
| TOF81_high TOF81_low | f > f >> | 81O | Overfrequency protection |
| TUF81_high TUF81_low | f < f << | 81U | Underfrequency protection |
| FRC81_high FRC81_low | df/dt | 81R | Rate of change of frequency protection |
| BRF50MV | CBFP | 50BF | Breaker failure protection |
| DIFF87L | IdL > | 87L | Line differential protection |

| | | | |
|--------------------|---------------------|----|----------------------|
| PLSLIP78 | $\Delta Z/\Delta t$ | 78 | Pole slip protection |
| SCH85 | - | - | Teleprotection |
| STB50 | - | - | Stub protection |
| DIS21 DIS21_MHO | $Z <$ | 21 | Distance protection |

Table. 6.1 - 10. Available control and monitoring functions

| Name | IEC | ANSI | Description |
|---------|-------------------|------|--|
| TRC94 | - | 94 | Trip logic |
| DLD | - | - | Dead line detection |
| VTS | - | 60 | Voltage transformer supervision |
| SYN25 | SYNC | 25 | Synchro-check function Δf , ΔU , $\Delta \phi$ |
| REC79MV | $0 \rightarrow 1$ | 79 | Autoreclosing function |
| SOTF | - | - | Switch on to fault |
| DREC | - | - | Disturbance recorder |

6.2 Measurements

6.2.1 Current measurement and scaling

If the factory configuration includes a current transformer hardware module, the current input function block is automatically configured among the software function blocks. Separate current input function blocks are assigned to each current transformer hardware module.

A current transformer hardware module is equipped with four special intermediate current transformers. As usual, the first three current inputs receive the three phase currents (IL1, IL2, IL3), the fourth input is reserved for zero sequence current, for the zero sequence current of the parallel line or for any additional current. Accordingly, the first three inputs have common parameters while the fourth current input needs individual setting.

The role of the current input function block is to

- set the required parameters associated to the current inputs,
- deliver the sampled current values for disturbance recording,
- perform the basic calculations
 - Fourier basic harmonic magnitude and angle,
 - True RMS value;
- provide the pre-calculated current values to the subsequent software function blocks,
- deliver the calculated Fourier basic component values for on-line displaying.

The current input function block receives the sampled current values from the internal operating system. The scaling (even hardware scaling) depends on parameter setting, see parameters **Rated Secondary I1-3** and **Rated Secondary I4**. The options to choose from are 1A or 5A (in special applications, 0.2A or 1A). This parameter influences the internal number format and, naturally, accuracy. A small current is processed with finer resolution if 1A is selected.

If needed, the phase currents can be inverted by setting the parameter **Starpoint I1-3**. This selection applies to each of the channels IL1, IL2 and IL3. The fourth current channel can be inverted by setting the parameter **Direction I4**. This inversion may be needed in protection functions such as distance protection, differential protection or for any functions with directional decision.

Figure. 6.2.1 - 33. Example connection.




Table. 6.2.1 - 11. Values for the example above.

| | |
|--|--|
| Phase current CT: CT primary 100A CT secondary 5A | Ring core CT in Input I0: I0CT primary 10A I0CT secondary 1A |
| Phase current CT secondary currents starpoint is towards the line. | |

Figure. 6.2.1 - 34. Example connection with phase currents connectef into summing "Holmgren" connection into the IO residual input.




Table. 6.2.1 - 12. Values for the example above.

| | |
|---|---|
| Phase current CT: CT primary 100A CT secondary 5A | Ring core CT in Input I0: I0CT primary 100A I0CT secondary 5A |
| Phase currents are connected to summing "Holmgren" connection into the I0 residual input. | |

The sampled values are available for further processing and for disturbance recording.

The performed basic calculation results the Fourier basic harmonic magnitude and angle and the true RMS value. These results are processed by subsequent protection function blocks and they are available for on-line displaying as well.

The function block also provides parameters for setting the primary rated currents of the main current transformer (Rated Primary I1-3 and Rated Primary I4). This function block does not need that parameter settings. These values are passed on to function blocks such as displaying primary measured values, primary power calculation, etc.

Table. 6.2.1 - 13. Enumerated parameters of the current input function

| Parameter name | Title | Selection range | Default |
|--|----------------------|---------------------|---------|
| Rated secondary current of the first three input channels. 1A or 5A is selected by parameter setting, no hardware modification is needed. | | | |
| CT4_Ch13Nom_EPar_ | Rated Secondary I1-3 | 1A,5A | 1A |
| Rated secondary current of the fourth input channel. 1A or 5A (0.2A, 1A) is selected by parameter setting, no hardware modification is needed. | | | |
| CT4_Ch4Nom_EPar_ | Rated Secondary I4 | 1A,5A (0.2A, 1A) | 1A |
| Definition of the positive direction of the first three currents, given by location of the secondary star connection point | | | |
| CT4_Ch13Dir_EPar_ | Starpoint I1-3 | Line,Bus | Line |
| Definition of the positive direction of the fourth current, given as normal or inverted | | | |
| CT4_Ch4Dir_EPar_ | Direction I4 | Normal,Inverted | Normal |

Table. 6.2.1 - 14. Floating point parameters of the current input function

| Parameter name | Title | Dim. | Min | Max | Default |
|-------------------------------------|--------------------|------|-----|------|---------|
| Rated primary current of channel1-3 | | | | | |
| CT4_Pri13_FPar_ | Rated Primary I1-3 | A | 100 | 4000 | 1000 |
| Rated primary current of channel4 | | | | | |
| CT4_Pri4_FPar_ | Rated Primary I4 | A | 100 | 4000 | 1000 |

Table. 6.2.1 - 15. Online measurements of the current input function

| Measured value | Dim. | Explanation |
|-----------------|--------------|---|
| Current Ch - I1 | A(secondary) | Fourier basic component of the current in channel IL1 |
| Angle Ch - I1 | degree | Vector position of the current in channel IL1 |
| Current Ch - I2 | A(secondary) | Fourier basic component of the current in channel IL2 |
| Angle Ch - I2 | degree | Vector position of the current in channel IL2 |
| Current Ch - I3 | A(secondary) | Fourier basic component of the current in channel IL3 |
| Angle Ch - I3 | degree | Vector position of the current in channel IL3 |
| Current Ch - I4 | A(secondary) | Fourier basic component of the current in channel I4 |
| Angle Ch - I4 | degree | Vector position of the current in channel I4 |

NOTICE!

The scaling of the Fourier basic component is such that if pure sinusoid 1A RMS of the rated frequency is injected, the displayed value is 1A. The displayed value does not depend on the parameter setting values "Rated Secondary".

NOTICE!

The reference of the vector position depends on the device configuration. If a voltage input module is included, then the reference vector (vector with angle 0 degree) is the vector calculated for the first voltage input channel of the first applied voltage input module. If no voltage input module is configured, then the reference vector (vector with angle 0 degree) is the vector calculated for the first current input channel of the first applied current input module. (The first input module is the one, configured closer to the CPU module.)

6.2.2 Voltage measurement and scaling

If the factory configuration includes a voltage transformer hardware module, the voltage input function block is automatically configured among the software function blocks. Separate voltage input function blocks are assigned to each voltage transformer hardware module.

A voltage transformer hardware module is equipped with four special intermediate voltage transformers. As usual, the first three voltage inputs receive the three phase voltages (UL1, UL2, UL3), the fourth input is reserved for zero sequence voltage or for a voltage from the other side of the circuit breaker for synchro switching.

The role of the voltage input function block is to

- set the required parameters associated to the voltage inputs,
- deliver the sampled voltage values for disturbance recording,
- perform the basic calculations
 - Fourier basic harmonic magnitude and angle,
 - True RMS value;
- provide the pre-calculated voltage values to the subsequent software modules,
- deliver the calculated basic Fourier component values for on-line displaying.


The voltage input function block receives the sampled voltage values from the internal operating system. The scaling (even hardware scaling) depends on a common parameter “Range” for type selection. The options to choose from are 100V or 200V, no hardware modification is needed. A small voltage is processed with finer resolution if 100V is selected. This parameter influences the internal number format and, naturally, accuracy.

There is a correction factor available if the rated secondary voltage of the main voltage transformer (e.g. 110V) does not match the rated input of the device. The related parameter is “VT correction”. As an example: if the rated secondary voltage of the main voltage transformer is 110V, then select Type 100 for the parameter “Range” and the required value to set here is 110%.

The connection of the first three VT secondary windings must be set to reflect actual physical connection of the main VTs. The associated parameter is “Connection U1-3”. The selection can be: Ph-N, Ph-Ph or Ph-N-Isolated.

The Ph-N option is applied in solidly grounded networks, where the measured phase voltage is never above 1.5- U_n . In this case the primary rated voltage of the VT must be the value of the rated PHASE-TO-NEUTRAL voltage.


Figure. 6.2.2 - 35. Phase to neutral connection. Connection U1-3.



| | |
|--|---|
| Ph-N Voltage: Rated Primary U1-3: 11.55kV (=20kV/ $\sqrt{3}$) Range: Type 100 | Residual voltage: Rated Primary U4: 11.54A |
|--|---|

If phase-to-phase voltage is connected to the VT input of the device, then the Ph-Ph option is to be selected. Here, the primary rated voltage of the VT must be the value of the rated PHASE-TO-PHASE voltage. This option must not be selected if the distance protection function is supplied from the VT input.

Figure. 6.2.2 - 36. Phase-to-phase connection.



| | |
|--|--|
| Ph-N Voltage: Rated Primary U1-3: 20kV Range: Type 100 | Residual voltage: Rated Primary U4: 11.54A (=20kV/√3) |
|--|--|

The fourth input is reserved for zero sequence voltage or for a voltage from the other side of the circuit breaker for synchron switching. Accordingly, the connected voltage must be identified with parameter setting “Connection U4”. Here, phase-to-neutral or phase-to-phase voltage can be selected: Ph-N, Ph-Ph.

If needed, the phase voltages can be inverted by setting the parameter “Direction U1-3”. This selection applies to each of the channels UL1, UL2 and UL3. The fourth voltage channel can be inverted by setting the parameter “Direction U4”. This inversion may be needed in protection functions such as distance protection or for any functions with directional decision, or for checking the voltage vector positions.

These modified sampled values are available for further processing and for disturbance recording.

The function block also provides parameters for setting the primary rated voltages of the main voltage transformers. This function block does not need that parameter setting but these values are passed on to function blocks such as displaying primary measured values, primary power calculation, etc.

Table. 6.2.2 - 16. Enumerated parameters of the voltage input function

| Parameter name | Title | Selection range | Default |
|---|-------|-------------------|----------|
| Rated secondary voltage of the input channels. 100 V or 200V type is selected by parameter setting, no hardware modification is needed. | | | |
| VT4_Type_EPar_ | Range | Type 100,Type 200 | Type 100 |
| Connection of the first three voltage inputs (main VT secondary) | | | |

| Parameter name | Title | Selection range | Default |
|---|-----------------|----------------------------|---------|
| VT4_Ch13Nom_EPar_ | Connection U1-3 | Ph-N, Ph-Ph, Ph-N-Isolated | Ph-N |
| Selection of the fourth channel input: phase-to-neutral or phase-to-phase voltage | | | |
| VT4_Ch4Nom_EPar_ | Connection U4 | Ph-N,Ph-Ph | Ph-Ph |
| Definition of the positive direction of the first three input channels, given as normal or inverted | | | |
| VT4_Ch12Dir_EPar_ | Direction U1-3 | Normal,Inverted | Normal |
| Definition of the positive direction of the fourth voltage, given as normal or inverted | | | |
| VT4_Ch4Dir_EPar_ | Direction U4 | Normal,Inverted | Normal |

Table. 6.2.2 - 17. Integer parameters of the voltage input function

| Parameter name | Title | Unit | Min | Max | Step | Default |
|--------------------|---------------|------|-----|-----|------|---------|
| Voltage correction | | | | | | |
| VT4_CorrFact_IPar_ | VT correction | % | 100 | 115 | 1 | 100 |

Table. 6.2.2 - 18. Float point parameters of the voltage input function

| Parameter name | Title | Dim. | Min | Max | Default |
|-----------------------------------|------------------|------|-----|------|---------|
| Rated primary voltage of channel1 | | | | | |
| VT4_PriU1_FPar_ | Rated Primary U1 | kV | 1 | 1000 | 100 |
| Rated primary voltage of channel2 | | | | | |
| VT4_PriU2_FPar_ | Rated Primary U2 | kV | 1 | 1000 | 100 |
| Rated primary voltage of channel3 | | | | | |
| VT4_PriU3_FPar_ | Rated Primary U3 | kV | 1 | 1000 | 100 |
| Rated primary voltage of channel4 | | | | | |
| VT4_PriU4_FPar_ | Rated Primary U4 | kV | 1 | 1000 | 100 |



NOTICE!

The rated primary voltage of the channels is not needed for the voltage input function block itself. These values are passed on to the subsequent function blocks.

Table. 6.2.2 - 19. On-line measured analogue values of the voltage input function

| Measured value | Dim. | Explanation |
|-----------------|--------------|---|
| Voltage Ch - U1 | V(secondary) | Fourier basic component of the voltage in channel UL1 |
| Angle Ch - U1 | degree | Vector position of the voltage in channel UL1 |
| Voltage Ch - U2 | V(secondary) | Fourier basic component of the voltage in channel UL2 |

| Measured value | Dim. | Explanation |
|-----------------|--------------|---|
| Angle Ch - U2 | degree | Vector position of the voltage in channel UL2 |
| Voltage Ch - U3 | V(secondary) | Fourier basic component of the voltage in channel UL3 |
| Angle Ch - U3 | degree | Vector position of the voltage in channel UL3 |
| Voltage Ch - U4 | V(secondary) | Fourier basic component of the voltage in channel U4 |
| Angle Ch - U4 | degree | Vector position of the voltage in channel U4 |

**NOTICE!**

The scaling of the Fourier basic component is such if pure sinusoid 57V RMS of the rated frequency is injected, the displayed value is 57V. The displayed value does not depend on the parameter setting values "Rated Secondary".

**NOTICE!**

The reference vector (vector with angle 0 degree) is the vector calculated for the first voltage input channel of the first applied voltage input module. The first voltage input module is the one, configured closer to the CPU module.

6.2.3 Line measurement

The input values of the AQ300 devices are the secondary signals of the voltage transformers and those of the current transformers.

These signals are pre-processed by the "Voltage transformer input" function block and by the "Current transformer input" function block. The pre-processed values include the Fourier basic harmonic phasors of the voltages and currents and the true RMS values. Additionally, it is in these function blocks that parameters are set concerning the voltage ratio of the primary voltage transformers and current ratio of the current transformers.

Based on the pre-processed values and the measured transformer parameters, the "Line measurement" function block calculates - depending on the hardware and software configuration - the primary RMS values of the voltages and currents and some additional values such as active and reactive power, symmetrical components of voltages and currents. These values are available as primary quantities and they can be displayed on the on-line screen of the device or on the remote user interface of the computers connected to the communication network and they are available for the SCADA system using the configured communication system.

Reporting the measured values and the changes

It is usual for the SCADA systems that they sample the measured and calculated values in regular time periods and additionally they receive the changed values as reports at the moment when any significant change is detected in the primary system. The "Line measurement" function block is able to perform such reporting for the SCADA system.

Operation of the line measurement function block

The inputs of the line measurement function are

- the Fourier components and true RMS values of the measured voltages and currents
- frequency measurement
- parameters.

The outputs of the line measurement function are

- displayed measured values
- reports to the SCADA system.



NOTICE!

The scaling values are entered as parameter setting for the “Voltage transformer input” function block and for the “Current transformer input” function block.

Measured values

The measured values of the line measurement function depend on the hardware configuration. As an example, table shows the list of the measured values available in a configuration for solidly grounded networks.

Table. 6.2.3 - 20. Example: Measured values in a configuration for solidly grounded networks

| Measured value | Explanation |
|----------------|--|
| MXU_P_OLM_ | Active Power — P (Fourier base harmonic value) |
| MXU_Q_OLM_ | Reactive Power — Q (Fourier base harmonic value) |
| MXU_S_OLM | Apparent Power — S (Fourier base harmonic value) |
| MXU_I1_OLM_ | Current L1 |
| MXU_I2_OLM_ | Current L2 |
| MXU_I3_OLM_ | Current L3 |
| MXU_U1_OLM_ | Voltage L1 |
| MXU_U2_OLM_ | Voltage L2 |
| MXU_U3_OLM_ | Voltage L3 |
| MXU_U12_OLM_ | Voltage L12 |
| MXU_U23_OLM_ | Voltage L23 |
| MXU_U31_OLM_ | Voltage L31 |
| MXU_f_OLM_ | Frequency |

Another example is in figure, where the measured values available are shown as on-line information in a configuration for compensated networks.

Figure. 6.2.3 - 37. Measured values in a configuration for compensated networks.

| [-] Line measurement | | |
|----------------------|------|------|
| Active Power - P | 0.00 | MW |
| Reactive Power - Q | 0.00 | MVar |
| Apparent Power - S | 0.00 | MVA |
| Power factor | 0.00 | |
| Current L1 | 0 | A |
| Current L2 | 0 | A |
| Current L3 | 0 | A |
| Voltage L1 | 0.0 | kV |
| Voltage L2 | 0.0 | kV |
| Voltage L3 | 0.0 | kV |
| Voltage L12 | 0.0 | kV |
| Voltage L23 | 0.0 | kV |
| Voltage L31 | 0.0 | kV |
| Frequency | 0.00 | Hz |

The available quantities are described in the configuration description documents.

Reporting the measured values and the changes

For reporting, additional information is needed, which is defined in parameter setting. As an example, in a configuration for solidly grounded networks the following parameters are available:

Table. 6.2.3 - 21. The enumerated parameters of the line measurement function.


| Parameter name | Title | Selection range | Default |
|--|-------------------------|----------------------------|-----------|
| Selection of the reporting mode for active power measurement | | | |
| MXU_PRepMode_EPar_ | Operation ActivePower | Off, Amplitude, Integrated | Amplitude |
| Selection of the reporting mode for reactive power measurement | | | |
| MXU_QRepMode_EPar_ | Operation ReactivePower | Off, Amplitude, Integrated | Amplitude |
| Selection of the reporting mode for apparent power measurement | | | |
| MXU_SRepMode_EPar_ | Operation ApparPower | Off, Amplitude, Integrated | Amplitude |
| Selection of the reporting mode for current measurement | | | |
| MXU_IRepMode_EPar_ | Operation Current | Off, Amplitude, Integrated | Amplitude |
| Selection of the reporting mode for voltage measurement | | | |
| MXU_URepMode_EPar_ | Operation Voltage | Off, Amplitude, Integrated | Amplitude |
| Selection of the reporting mode for frequency measurement | | | |
| MXU_fRepMode_EPar_ | Operation Frequency | Off, Amplitude, Integrated | Amplitude |

The selection of the reporting mode items is explained in next chapters.

"Amplitude" mode of reporting

If the "Amplitude" mode is selected for reporting, a report is generated if the measured value leaves the deadband around the previously reported value. As an example, the figure below shows that the current becomes higher than the value reported in "report1" PLUS the Deadband value, this results "report2", etc.

Figure. 6.2.3 - 38. Reporting when Amplitude mode is selected.



For this mode of operation, the Deadband parameters are explained in table below.

The "Range" parameters in the table are needed to evaluate a measurement as "out-of-range".

Table. 6.2.3 - 22. The enumerated parameters of the line measurement function.


| Parameter name | Title | Dim. | Min | Max | Step | Default |
|---------------------------------------|--------------------|------|-----|--------|------|---------|
| Deadband value for the active power | | | | | | |
| MXU_PDeadB_FPar_ | Deadband value - P | MW | 0.1 | 100000 | 0.01 | 10 |
| Range value for the active power | | | | | | |
| MXU_PRange_FPar_ | Range value - P | MW | 1 | 100000 | 0.01 | 500 |
| Deadband value for the reactive power | | | | | | |
| MXU_QDeadB_FPar_ | Deadband value - Q | MVar | 0.1 | 100000 | 0.01 | 10 |
| Range value for the reactive power | | | | | | |
| MXU_QRange_FPar_ | Range value - Q | MVar | 1 | 100000 | 0.01 | 500 |
| Deadband value for the apparent power | | | | | | |
| MXU_SDeadB_FPar_ | Deadband value - S | MVA | 0.1 | 100000 | 0.01 | 10 |

| Parameter name | Title | Dim. | Min | Max | Step | Default |
|---|--------------------------|------|------|--------|------|---------|
| Range value for the apparent power | | | | | | |
| MXU_SRange_FPar_ | Range value - S | MVA | 0.1 | 100000 | 0.01 | 500 |
| Deadband value for the current | | | | | | |
| MXU_IDeadB_FPar_ | Deadband value - I | A | 1 | 2000 | 1 | 10 |
| Range value for the current | | | | | | |
| MXU_IRange_FPar_ | Range value - I | A | 1 | 5000 | 1 | 500 |
| Deadband value for the phase-to-neutral voltage | | | | | | |
| MXU_UPhDeadB_FPar_ | Deadband value - U ph-N | kV | 0.1 | 100 | 0.01 | 1 |
| Range value for the phase-to-neutral voltage | | | | | | |
| MXU_UPhRange_FPar_ | Range value - U ph-N | kV | 1 | 1000 | 0.1 | 231 |
| Deadband value for the phase-to-phase voltage | | | | | | |
| MXU_UPPDeadB_FPar_ | Deadband value - U ph-ph | kV | 0.1 | 100 | 0.01 | 1 |
| Range value for the phase-to-phase voltage | | | | | | |
| MXU_UPPRange_FPar_ | Range value - U ph-ph | kV | 1 | 1000 | 0.1 | 400 |
| Deadband value for the frequency | | | | | | |
| MXU_fDeadB_FPar_ | Deadband value - f | Hz | 0.01 | 1 | 0.01 | 0.02 |
| Range value for the frequency | | | | | | |
| MXU_fRange_FPar_ | Range value - f | Hz | 0.05 | 10 | 0.01 | 5 |

"Integral" mode of reporting

If the "Integrated" mode is selected for reporting, a report is generated if the time integral of the measured value since the last report gets becomes larger, in the positive or negative direction, then the (deadband*1sec) area. As an example, the figure below shows that the integral of the current in time becomes higher than the Deadband value multiplied by 1sec, this results "report2", etc.

Figure. 6.2.3 - 39. Reporting when Integrated mode is selected.



Periodic reporting

Periodic reporting is generated independently of the changes of the measured values when the defined time period elapses.

Table. 6.2.3 - 23. The floating-point parameters of the line measurement function

| Parameter name | Title | Dim. | Min | Max | Step | Default |
|---------------------------------------|--------------------|------|-----|--------|------|---------|
| Deadband value for the active power | | | | | | |
| MXU_PDeadB_FPar_ | Deadband value - P | MW | 0.1 | 100000 | 0.01 | 10 |
| Range value for the active power | | | | | | |
| MXU_PRange_FPar_ | Range value - P | MW | 1 | 100000 | 0.01 | 500 |
| Deadband value for the reactive power | | | | | | |
| MXU_QDeadB_FPar_ | Deadband value - Q | MVar | 0.1 | 100000 | 0.01 | 10 |
| Range value for the reactive power | | | | | | |
| MXU_QRange_FPar_ | Range value - Q | MVar | 1 | 100000 | 0.01 | 500 |
| Deadband value for the apparent power | | | | | | |
| MXU_SDeadB_FPar_ | Deadband value - S | MVA | 0.1 | 100000 | 0.01 | 10 |
| Range value for the apparent power | | | | | | |
| MXU_SRange_FPar_ | Range value - S | MVA | 0.1 | 100000 | 0.01 | 500 |
| Deadband value for the current | | | | | | |
| MXU_IDeadB_FPar_ | Deadband value - I | A | 1 | 2000 | 1 | 10 |
| Range value for the current | | | | | | |
| MXU_IRange_FPar_ | Range value - I | A | 1 | 5000 | 1 | 500 |

| Parameter name | Title | Dim. | Min | Max | Step | Default |
|---|--------------------------|------|------|------|------|---------|
| Deadband value for the phase-to-neutral voltage | | | | | | |
| MXU_UPhDeadB_FPar_ | Deadband value - U ph-N | kV | 0.1 | 100 | 0.01 | 1 |
| Range value for the phase-to-neutral voltage | | | | | | |
| MXU_UPhRange_FPar_ | Range value - U ph-N | kV | 1 | 1000 | 0.1 | 231 |
| Deadband value for the phase-to-phase voltage | | | | | | |
| MXU_UPPDeadB_FPar_ | Deadband value - U ph-ph | kV | 0.1 | 100 | 0.01 | 1 |
| Range value for the phase-to-phase voltage | | | | | | |
| MXU_UPPRange_FPar_ | Range value - U ph-ph | kV | 1 | 1000 | 0.1 | 400 |
| Deadband value for the frequency | | | | | | |
| MXU_fDeadB_FPar_ | Deadband value - f | Hz | 0.01 | 1 | 0.01 | 0.02 |
| Range value for the frequency | | | | | | |
| MXU_fRange_FPar_ | Range value - f | Hz | 0.05 | 10 | 0.01 | 5 |


If the reporting time period is set to 0, then no periodic reporting is performed for this quantity. All reports can be disabled for a quantity if the reporting mode is set to "Off".

6.3 Protection functions

6.3.1 Three-phase instantaneous overcurrent protection ($I > 50/51$)

The instantaneous overcurrent protection function operates according to instantaneous characteristics, using the three sampled phase currents. The setting value is a parameter, and it can be doubled with dedicated input binary signal. The basic calculation can be based on peak value selection or on Fourier basic harmonic calculation, according to the parameter setting.

Figure. 6.3.1 - 40. Operating characteristics of the instantaneous overcurrent protection function.




The variables in the image above are:

- t_{OP} (seconds) = theoretical operating time if $G > G_S$ (without additional time delay)
- G = measured peak value or Fourier base harmonic of the phase currents
- G_S = pick-up setting value

The structure of the algorithm consists of following modules. Fourier calculation module calculates the RMS values of the Fourier components of the residual current. Peak selection module is an alternative for the Fourier calculation module and the peak selection module selects the peak values of the phase currents individually. Instantaneous decision module compares the peak- or Fourier basic harmonic components of the phase currents into the setting value. Decision logic module generates the trip signal of the function.

In the figure below, is presented the structure of the instantaneous overcurrent algorithm.

Figure. 6.3.1 - 41. The structure of the function's algorithm.



The algorithm generates a trip command without additional time delay based on the Fourier components of the phase currents or peak values of the phase currents in case if the user set pick-up value is exceeded. The operation of the function is phase wise and it allows each phase to be tripped separately. Standard operation is three poles.

The function includes a blocking signal input which can be configured by user from either IED internal binary signals or IED binary inputs through the programmable logic.


Table. 6.3.1 - 24. Setting parameters of the instantaneous overcurrent protection function.

| Parameter | Setting value / range | Step | Default | Description |
|---------------|--|----------|------------|---|
| Operation | Off Peak value Fundamental value | - | Peak value | Operating mode selection of the function. Can be disabled, operating based into measured current peak values or operating based into calculated current fundamental frequency RMS values. |
| Start current | 20...3000 %In | 1 %In | 200 %In | Pick-up setting of the function. |

6.3.2 Residual instantaneous overcurrent protection (IO> 50N/51N)

The residual instantaneous overcurrent protection function operates according to instantaneous characteristics, using the residual current ($I_N = 3I_o$). The setting value is a parameter, and it can be doubled with dedicated input binary signal. The basic calculation can be based on peak value selection or on Fourier basic harmonic calculation, according to the parameter setting.

Figure. 6.3.2 - 42. Operating characteristics of the residual instantaneous overcurrent protection function.




The variables in the image above are:

- t_{OP} (seconds) = theoretical operating time if $G > G_s$ (without additional time delay)
- G = measured peak value or Fourier base harmonic of the residual current
- G_s = pick-up setting value

The structure of the algorithm consists of following modules. Fourier calculation module calculates the RMS values of the Fourier components of the residual current. Peak selection module is an alternative for the Fourier calculation module and the peak selection module selects the peak values of the residual currents individually. Instantaneous decision module compares the peak- or Fourier basic harmonic components of the phase currents into the setting value. Decision logic module generates the trip signal of the function.

Below is presented the structure of the instantaneous residual overcurrent algorithm.

Figure. 6.3.2 - 43. The structure of the residual instantaneous overcurrent algorithm.



The algorithm generates a trip command without additional time delay based on the Fourier components of the phase currents or peak values of the phase currents in case if the user set pick-up value is exceeded. The operation of the function is phase wise and it allows each phase to be tripped separately. Standard operation is three poles.

The function includes a blocking signal input which can be configured by user from either IED internal binary signals or IED binary inputs through the programmable logic.

Table. 6.3.2 - 25. Setting parameters of the residual instantaneous overcurrent protection function.

| Parameter | Setting value / range | Step | Default | Description |
|---------------|--|-------|------------|---|
| Operation | Off Peak value Fundamental value | - | Peak value | Operating mode selection of the function. Can be disabled, operating based into measured current peak values or operating based into calculated current fundamental frequency RMS values. |
| Start current | 10...400 %In | 1 %In | 200 %In | Pick-up setting of the function. |


6.3.3 Three-phase time overcurrent protection (I> 50/51)

Three phase time overcurrent function includes the definite time and IDMT characteristics according to the IEC and IEEE standards. The function measures the fundamental Fourier components of the measured three phase currents.

The structure of the algorithm consists of following modules. Fourier calculation module calculates the RMS values of the Fourier components of the 3-phase currents. Characteristics module compares the Fourier basic harmonic components of the phase currents into the setting value. Decision logic module generates the trip signal of the function.

In the figure below is presented the structure of the time overcurrent algorithm.

Figure. 6.3.3 - 44. The structure of the time overcurrent algorithm.




The algorithm generates a start signal based on the Fourier components of the phase currents or peak values of the phase currents in case if the user set pick-up value is exceeded. Trip signal is generated based into the selected definite time- or IDMT additional time delay is passed from the start conditions. The operation of the function is phase wise and it allows each phase to be tripped separately. Standard operation is three poles.

The function includes a blocking signal input which can be configured by user from either IED internal binary signals or IED binary inputs through the programmable logic.

Operating characteristics of the definite time is presented in the figure below.

Figure. 6.3.3 - 45. Operating characteristics of the instantaneous overcurrent protection function.



The variables in the image above are:

- t_{OP} (seconds) = theoretical operating time if $G > G_s$ (without additional time delay)
- G = measured peak value or Fourier base harmonic of the phase currents
- G_s = pick-up setting value

IDMT operating characteristics depend on the selected curve family and curve type. All of the available IDMT characteristics follow

$$t(G) = TMS \left[\frac{k}{\left(\frac{G}{G_s}\right)^\alpha - 1} + c \right]$$

The variables of the equation above are:

- $t(G)$ (seconds) = theoretical operate time with constant value of G , when $G > G_s$
- k, c = constants characterizing the selected curve
- α = constant characterizing the selected curve
- G = measured value of the Fourier base harmonic of the phase currents
- G_s = pick-up setting value
- TMS = time dial setting / preset time multiplier

The parameters and operating curve types follow corresponding standards presented in the table below.

Table. 6.3.3 - 26. Parameters and operating curve types for the IDMT characteristics.

| Curve family | Characteristics | k_r | c | α |
|--------------|-------------------------------------|--------|--------|----------|
| IEC | NI (normally inverse) | 0.14 | 0 | 0.02 |
| IEC | VI (very inverse) | 13.5 | 0 | 1 |
| IEC | EI (extremely inverse) | 80 | 0 | 2 |
| IEC | LTI (long time inverse) | 120 | 0 | 1 |
| IEEE/ANSI | NI (normally inverse) | 0.0086 | 0.0185 | 0.02 |
| IEEE/ANSI | MI (moderately inverse) | 0.0515 | 0.1140 | 0.02 |
| IEEE/ANSI | VI (very inverse) | 19.61 | 0.491 | 2 |
| IEEE/ANSI | EI (extremely inverse) | 28.2 | 0.1217 | 2 |
| IEEE/ANSI | LTI (long time inverse) | 0.086 | 0.185 | 0.02 |
| IEEE/ANSI | LTVI (long time, very inverse) | 28.55 | 0.712 | 2 |
| IEEE/ANSI | LTEI (long time, extremely inverse) | 64.07 | 0.250 | 2 |

In following figures the characteristics of IDMT curves are presented with minimum and maximum pick-up settings in respect of the IED measuring range.

Figure. 6.3.3 - 46. IEC - NI operating curves with minimum and maximum pick-up settings and TMS settings from 0.05 to 20.




Figure. 6.3.3 - 47. IEC - VI operating curves with minimum and maximum pick-up settings and TMS settings from 0.05 to 20.




Figure. 6.3.3 - 48. IEC - EI operating curves with minimum and maximum pick-up settings and TMS settings from 0.05 to 20.




Figure. 6.3.3 - 49. IEC - LTI operating curves with minimum and maximum pick-up settings and TMS settings from 0.05 to 20.




Figure. 6.3.3 - 50. IEEE/ANSI - NI operating curves with minimum and maximum pick-up settings and TMS settings from 0.05 to 20.




Figure. 6.3.3 - 51. IEEE/ANSI - MI operating curves with minimum and maximum pick-up settings and TMS settings from 0.05 to 20.




Figure. 6.3.3 - 52. IEEE/ANSI - VI operating curves with minimum and maximum pick-up settings and TMS settings from 0.05 to 20.




Figure. 6.3.3 - 53. IEEE/ANSI - EI operating curves with minimum and maximum pick-up settings and TMS settings from 0.05 to 20.




Figure. 6.3.3 - 54. IEEE/ANSI - LTI operating curves with minimum and maximum pick-up settings and TMS settings from 0.05 to 20.




Figure. 6.3.3 - 55. IEEE/ANSI - LTVI operating curves with minimum and maximum pick-up settings and TMS settings from 0.05 to 20.





Figure. 6.3.3 - 56. IEEE/ANSI - LTEI operating curves with minimum and maximum pick-up settings and TMS settings from 0.05 to 20.



Resetting characteristics for the function depends on the selected operating time characteristics. For the IEC type IDMT characteristics the reset time is user settable and for the ANSI/IEEE type characteristics the resetting time follows equation below.

Figure. 6.3.3 - 57. Resetting characteristics for ANSI/IEEE IDMT.

$$t_r(G) = TMS \left[\frac{k_r}{1 - \left(\frac{G}{G_S} \right)^\alpha} \right]$$

The variables in the equation above are:

- $t_r(G)$ (seconds) = theoretical reset time with constant value of G
- k_r = constants characterizing the selected curve
- α = constant characterizing the selected curve
- G = measured value of the Fourier base harmonic of the phase currents
- G_S = pick-up setting value
- TMS = time dial setting / preset time multiplier

The parameters and operating curve types follow corresponding standards presented in the table below.

Table. 6.3.3 - 27. Parameters and operating curve types for the IDMT characteristics.


| Curve family | Characteristics | k_r | α |
|--------------|-------------------------------------|--------------------------------|----------|
| IEC | NI (normally inverse) | User settable fixed reset time | |
| IEC | VI (very inverse) | | |
| IEC | EI (extremely inverse) | | |
| IEC | LTI (long time inverse) | | |
| IEEE/ANSI | NI (normally inverse) | 0.46 | 2 |
| IEEE/ANSI | MI (moderately inverse) | 4.85 | 2 |
| IEEE/ANSI | VI (very inverse) | 21.6 | 2 |
| IEEE/ANSI | EI (extremely inverse) | 29.6 | 2 |
| IEEE/ANSI | LTI (long time inverse) | 4.6 | 2 |
| IEEE/ANSI | LTVI (long time, very inverse) | 13.46 | 2 |
| IEEE/ANSI | LTEI (long time, extremely inverse) | 30 | 2 |

Table. 6.3.3 - 28. Setting parameters of the time overcurrent function.

| Parameter | Setting value / range | Step | Default | Description |
|---------------------|---|-------|-------------|---|
| Operation | Off DefinitTime IEC Inv IEC VeryInv IEC ExtInv IEC LongInv ANSI Inv ANSI ModInv ANSI VeryInv ANSI ExtInv ANSI LongInv ANSI LongVeryInv ANSI LongExtInv | - | DefinitTime | Operating mode selection of the function. Can be disabled, Definite time or IDMT operation based IEC or ANSI/IEEE standards. |
| Start current | 5...400 %In | 1 %In | 200 %In | Pick-up current setting of the function. |
| Min Delay | 0...60 000 ms | 1 ms | 100 ms | Minimum operating delay setting for the IDMT characteristics. |
| Definite delay time | 0...60 000 ms | 1 ms | 100 ms | Definite time operating delay setting. This parameter is not in use when IDMT characteristics is selected for the operation. |
| Reset delay | 0...60 000 ms | 1 ms | 100 ms | Settable reset delay for definite time function and IEC IDMT operating characteristics. This parameter is in use with definite time and IEC IDMT characteristics. |
| Time Mult | 0.05...999.0 | 0.01 | - | Time multiplier / time dial setting of the IDMT operating characteristics. This parameter is not in use with definite time characteristics. |

6.3.4 Residual time overcurrent protection (I0>; 50N/51N)

The residual definite time overcurrent protection function operates with definite time characteristics, using the RMS values of the fundamental Fourier component of the neutral or residual current ($I_N=3I_0$). In the figure below is presented the operating characteristics of the function.




The variables in the image above are:

- t_{OP} (seconds) = theoretical operating time if $G > G_S$ (without additional time delay)
- G = measured value of the Fourier base harmonic of the residual current
- G_S = pick-up setting

The structure of the algorithm consists of following modules. Fourier calculation module calculates the RMS values of the Fourier components of the residual current. Characteristics module compares the Fourier basic harmonic components of the residual current into the setting value. Decision logic module generates the trip signal of the function.

In the figure below is presented the structure of the residual time overcurrent algorithm.

Figure. 6.3.4 - 58. Structure of the residual time overcurrent protection algorithm.



The algorithm generates a start signal based on the Fourier components of the residual current in case if the user set pick-up value is exceeded. Trip signal is generated after the set definite time delay.

The function includes a blocking signal input which can be configured by user from either IED internal binary signals or IED binary inputs through the programmable logic.


Table. 6.3.4 - 29. Setting parameters of the residual time overcurrent function.

| Parameter | Setting value / Range | Step | Default | Description |
|---------------------|---|-------|-------------|---|
| Operation | Off DefinitTime IEC Inv IEC VeryInv IEC ExtInv IEC LongInv ANSI Inv ANSI ModInv ANSI VeryInv ANSI ExtInv ANSI LongInv ANSI LongVeryInv ANSI LongExtInv | - | DefinitTime | Operating mode selection of the function. Can be disabled, Definite time or IDMT operation based into IEC or ANSI/IEEE standards. |
| Start current | 1...200 %In | 1 %In | 50 %In | Pick-up current setting of the function. |
| Min Delay | 0...60 000 ms | 1 ms | 100 ms | Minimum operating delay setting for the IDMT characteristics. |
| Definite delay time | 0...60 000 ms | 1 ms | 100 ms | Definite time operating delay setting. This parameter is not in use when IDMT characteristics is selected for the operation. |
| Reset time | 0...60 000 ms | 1 ms | 100 ms | Settable reset delay for definite time function and IEC IDMT operating characteristics. This parameter is in use with definite time and IEC IDMT characteristics. |
| Time Mult | 0.05...999.0 | 0.01 | 1.00 | Time multiplier / time dial setting of the IDMT operating characteristics. This parameter is not in use with definite time characteristics. |

6.3.5 Three-phase directional overcurrent protection (Idir>; 67)


The directional three-phase overcurrent protection function can be applied on networks where the overcurrent protection must be supplemented with a directional decision. The inputs of the function are the Fourier basic harmonic components of the three phase currents and those of the three phase voltages. In the figure below is presented the structure of the directional overcurrent protection algorithm.

Figure. 6.3.5 - 59. The structure of the directional overcurrent protection algorithm.



Based on the measured voltages and currents the function block selects the lowest calculated loop impedance of the six loops (L1L2, L2L3, L3L1, L1N, L2N, L3N). Based on the loop voltage and loop current of the selected loop the directional decision is "Forward" if the voltage and the current is sufficient for directional decision, and the angle difference between the vectors is inside the set operating characteristics. If the angle difference between the vectors is outside of the set characteristics the directional decision is "Backward".

Figure. 6.3.5 - 60. Directional decision characteristics.



The voltage must be above 5% of the rated voltage and the current must also be measurable. If the voltages are below 5% of the rated voltage then the algorithm substitutes the small values with the voltage values stored in the memory. The input signals are the RMS values of the fundamental Fourier components of the three-phase currents and three phase voltages and the three line-to-line voltages.

The internal output status signal for enabling the directional decision is true if both the three-phase voltages and the three-phase currents are above the setting limits. The RMS voltage and current values of the fundamental Fourier components of the selected loop are forwarded to angle calculation for further processing.

If the phase angle between the three-phase voltage and three-phase current is within the set range (defined by the preset parameter) or non-directional operation is selected by the preset parameter the function will operate according to the selected "Forward", "Backward" or non directional setting.

Operating time of the function can be definite time or IDMT based on user selection. Operating characteristics of the IDMT function are presented in the "Three-phase time overcurrent protection (I> 50/51)" chapter.

Table. 6.3.5 - 30. Setting parameters of the directional overcurrent function.

| Parameter | Setting value / range | Step | Default | Description |
|----------------------|-------------------------------|-------|---------|--|
| Direction | NonDir Forward Backward | - | Forward | Direction mode selection. |
| Operating angle | 30...90 deg | 1 deg | 60 deg | Operating angle setting. Defines the width of the operating characteristics in both sides of the characteristic angle. The default setting of 60 deg means that the total width of the operating angle is 120 deg. |
| Characteristic angle | 40...90 deg | 1 deg | 60 deg | Characteristic angle setting. Defines the center angle of the characteristic. |


| Parameter | Setting value / range | Step | Default | Description |
|---------------------|--|-------|-------------|---|
| Operation | Off DefinitTime IEC Inv IEC VeryInv IEC ExtInv IEC LongInv ANSI Inv ANSI ModInv ANSI VeryInv ANSI ExtInv ANSI LongInv ANSI LongVeryInv ANSI LongExtInv | - | DefinitTime | Operating mode selection of the function. Can be disabled, Definite time or IDMT operation based into IEC or ANSI/IEEE standards. |
| Start current | 5...1 000 %In | 1 %In | 50 %In | Pick-up current setting of the function. |
| Min Delay | 0...60 000 ms | 1 ms | 100 ms | Minimum operating delay setting for the IDMT characteristics. |
| Definite delay time | 0...60 000 ms | 1 ms | 100 ms | Definite time operating delay setting. This parameter is not in use when IDMT characteristics is selected for the operation. |
| Reset delay | 0...60 000 ms | 1 ms | 100 ms | Settable reset delay for definite time function and IEC IDMT operating characteristics. This parameter is in use with definite time and IDMT characteristics. |
| Time Mult | 0.05...999.00 | 0.01 | 1.00 | Time multiplier / time dial setting of the IDMT operating characteristics. This parameter is not in use with definite time characteristics. |

6.3.6 Residual directional overcurrent protection (I0dir>; 67N)

The main application area of the directional residual overcurrent protection function is earth-fault protection in all types of networks.


The inputs of the function are the Fourier basic harmonic components of the zero sequence current and those of the zero sequence voltage. In the figure below is presented the structure of the residual directional overcurrent algorithm.

Figure. 6.3.6 - 61. The structure of the residual directional overcurrent protection algorithm.




The block of the directional decision generates a signal of TRUE value if the $UN=3U_0$ zero sequence voltage and the $IN=-3I_0$ current is sufficient for directional decision, and the angle difference between the vectors is within the preset range. This decision enables the output start and trip signal of the residual overcurrent protection function block.

Figure. 6.3.6 - 62. Directional decision characteristics of operating angle mode.



In the figure above is presented the directional decision characteristics. Measured U_0 signal is the reference for measured $-I_0$ signal. RCA setting is the characteristic angle and $R0A$ parameter is the operating angle. In the figure F_i parameter describes the measured residual current angle in relation to measured U_0 signal and IN is the magnitude of the measured residual current. In the figure described situation the measured residual current is inside of the set operating sector and the status of the function would be starting in "Forward" mode. The protection function supports operating angle mode and also wattmetric and varmetric operating characteristics.

Figure. 6.3.6 - 63. Wattmetric and varmetric operating characteristics.



In the in the figure above are presented the characteristics of the wattmetric and varmetric operating principles in forward direction. For reverse operating direction the operating vectors are turned 180 degrees.

Table. 6.3.6 - 31. Setting parameters of the residual directional overcurrent function.

| Parameter | Setting value / range | Step | Default | Description |
|----------------------|--|-------|---------|--|
| Direction | NonDir Forward-Angle Backward-Angle Forward- $I_0 \cdot \cos(\phi_i)$ Backward- $I_0 \cdot \cos(\phi_i)$ Forward- $I_0 \cdot \sin(\phi_i)$ Backward- $I_0 \cdot \sin(\phi_i)$ Forward- $I_0 \cdot \sin(\phi_i + 45)$ Backward- $I_0 \cdot \sin(\phi_i + 45)$ | - | - | Direction mode selection of the function. By the direction mode selection also the operating characteristics is selected either non-directional, operating angle mode, wattmetric $I_0 \cos(\phi_i)$ or varmetric $I_0 \sin(\phi_i)$ mode. |
| U0 min | 1...10 % | 1 % | - | The threshold value for the 3U0 zero sequence voltage, below this setting no directionality is possible. % of the rated voltage of the voltage transformer input. |
| I0 min | 1...50 % | 1 % | - | The threshold value for the 3I0 zero sequence current, below this setting no operation is possible. % of the rated current of the current transformer input. <i>With 0.2A sensitive current module 2 mA secondary current pick-up sensitivity can be achieved. (ordering option)</i> |
| Operating Angle | 30...90 deg | 1 deg | - | Width of the operating characteristics in relation of the Characteristic Angle (<i>only in Forward/Backward-Angle mode</i>). Operating Angle setting value is \pm deg from the reference Characteristic Angle setting. For example, with setting of Characteristic Angle = 0 deg and Operating Angle 30 deg Forward operating characteristic would be area inside +30 deg and -30 deg. |
| Characteristic Angle | -180...180 deg | 1 deg | - | The base angle of the operating characteristics. |

| Parameter | Setting value / range | Step | Default | Description |
|---------------|---|------|-------------|---|
| Operation | Off DefinitTime IEC Inv IEC VeryInv IEC ExtInv IEC LongInv ANSI Inv ANSI ModInv ANSI VeryInv ANSI ExtInv ANSI LongInv ANSI LongVeryInv ANSI LongExtInv | - | DefinitTime | Selection of the function disabled and the timing characteristics. Operation when enabled can be either Definite time or IDMT characteristic. |
| Start current | 1...200 % | 1 % | - | Pick-up residual current |
| Time Mult | 0.05...999 | 0.01 | - | Time dial / multiplier setting used with IDMT operating time characteristics. |
| Min. Time | 0...60 000 ms | 1 ms | - | Minimum time delay for the inverse characteristics. |
| Def Time | 0...60 000 ms | 1 ms | - | Definite operating time |
| Reset Time | 0...60 000 ms | 1 ms | - | Settable function reset time |


6.3.7 Current unbalance protection (60)

The current unbalance protection function can be applied to detect unexpected asymmetry in current measurement.

The applied method selects maximum and minimum phase currents (fundamental Fourier components). If the difference between them is above the setting limit, the function generates a start signal.


Structure of the current unbalance protection function is presented in the figure below

Figure. 6.3.7 - 64. The structure of the current unbalance protection algorithm.



The analogue signal processing principal scheme is presented in the figure below.

Figure. 6.3.7 - 65. Analogue signal processing for the current unbalance function.



The signal processing compares the difference between measured current magnitudes. If the measured relative difference between the minimum and maximum current is higher than the setting value the function generates a trip command. For stage to be operational the measured current level has to be in range of 10 % to 150 % of the nominal current. This precondition prevents the stage from operating in case of very low load and during other faults like short circuit or earth faults.

The function can be disabled by parameter setting, and by an input signal programmed by the user.

The trip command is generated after the set defined time delay.

Table. 6.3.7 - 32. Setting parameters of the current unbalance function.

| Parameter | Setting value / range | Step | Default | Description |
|-------------------|--------------------------|------|-------------|---|
| Operation | On Off | - | On | Selection for the function enabled or disabled. |
| Start signal only | Activated Deactivated | - | Deactivated | Selection if the function issues either "Start" signal alone or both "Start" and after set time delay "Trip" signal. |
| Start current | 10...90 % | 1 % | 50 % | Pick up setting of the current unbalance. Setting is the maximum allowed difference in between of the min and max phase currents. |
| Time delay | 0...60 000 ms | 1 ms | 1 000 ms | Operating time delay setting for the "Trip" signal from the "Start" signal. |

6.3.8 Circuit breaker failure protection (CBFP; 50BF/52BF)

After a protection function generates a trip command, it is expected that the circuit breaker opens and/or the fault current drops below the pre-defined normal level. If not, then an additional trip command must be generated for all backup circuit breakers to clear the fault. At the same time, if required, a repeated trip command can be generated to the circuit breaker(s) which are expected to open. The breaker failure protection function can be applied to perform this task.

The starting signal of the breaker failure protection function is usually the trip command of any other protection function defined by the user. Dedicated timers start at the rising edge of the start signals, one for the backup trip command and one for the repeated trip command, separately for operation in the individual phases.

During the running time of the timers the function optionally monitors the currents, the closed state of the circuit breakers or both, according to the user's choice. When operation is based on current the set binary inputs indicating the status of the circuit breaker poles have no effect. If the operation is based on circuit breaker status the current limit values "Start current Ph" and "Start current N" have no effect on operation.

The breaker failure protection function resets only if all conditions for faultless state are fulfilled. If at the end of the running time of the backup timer the currents do not drop below the pre-defined level, and/or the monitored circuit breaker is still in closed position, then a backup trip command is generated in the phase(s) where the timer(s) run off.

The time delay is defined using the parameter "Backup Time Delay". If repeated trip command is to be generated for the circuit breakers that are expected to open, then the enumerated parameter "Retrip" must be set to "On". In this case, at the end of the timer(s) the delay of which is set by the timer parameter "Retrip Time Delay", a repeated trip command is also generated. The pulse duration of the trip command is shall the time defined by setting the parameter "Pulse length". The breaker failure protection function can be enabled or disabled by setting the parameter "Operation" to "Off".

Dynamic blocking is possible using the binary input "Block". The conditions can be programmed by the user.

Figure. 6.3.8 - 66. Operation logic of the CBFP function.





Table. 6.3.8 - 33. Setting parameters of the CBFP function.

| Parameter | Setting value / range | Step | Default | Description |
|-------------------|--|------|---------|---|
| Operation | Off Current Contact Current/ Contact | - | Current | Operating mode selection for the function. Operation can be either disabled "Off" or monitoring either measured current or contact status or both current and contact status. |
| Start current Ph | 20...200 % | 1 % | 30 % | Pick-up current for the phase current monitoring. |
| Start current N | 10...200 % | 1 % | 30 % | Pick-up current for the residual current monitoring. |
| Backup Time Delay | 60...1 000 ms | 1 ms | 200 ms | Time delay for CBFP tripping command for the back-up breakers from the pick-up of the CBFP function monitoring. |
| Pulse length | 0...60 000 ms | 1 ms | 100 ms | CBFP pulse length setting. |

6.3.9 Overvoltage protection ($U >$; 59)

The overvoltage protection function measures three phase to ground voltages. If any of the measured voltages is above the pick-up setting, a start signal is generated for the phases individually.

Figure. 6.3.9 - 67. The principal structure of the overvoltage function.



The general start signal is set active if the voltage in any of the three measured voltages is above the level defined by pick-up setting value. The function generates a trip command after the definite time delay has elapsed.


Table. 6.3.9 - 34.

| Parameter | Setting value / range | Step | Default | Description |
|-------------------|--------------------------|------|-------------|--|
| Operation | Off On | - | On | Operating mode selection for the function. Operation can be either enabled "On" or disabled "Off". |
| Start voltage | 30...130 % | 1 % | 63 % | Voltage pick-up setting |
| Start signal only | Activated Deactivated | - | Deactivated | Selection if the function issues either "Start" signal alone or both "Start" and after set time delay "Trip" signal. |
| Reset ratio | 1...10 % | 1 % | 5 % | Overvoltage protection reset ratio. |
| Time delay | 0...60 000 ms | 1 ms | 100 ms | Operating time delay setting for the "Trip" signal from the "Start" signal. |

6.3.10 Undervoltage protection ($U <$; 27)

The undervoltage protection function measures three voltages. If any of them is below the set pick-up value and above the defined minimum level, then a start signal is generated for the phases individually.

Figure. 6.3.10 - 68. The principal structure of the undervoltage function.



The general start signal is set active if the voltage of any of the three measured voltages is below the level defined by pick-up setting value. The function generates a trip command after the definite time delay has elapsed.


Table. 6.3.10 - 35. Setting parameters of the undervoltage function.

| Parameter | Setting value / range | Step | Default | Description |
|-------------------|--|------|-------------|---|
| Operation | Off 1 out of 3 2 out of 3 All | - | 1 out of 3 | Operating mode selection for the function. Operation can be either disabled "Off" or the operating mode can be selected to monitor single phase undervoltage, two phases undervoltage or all phases undervoltage condition. |
| Start voltage | 30...130 % | 1 % | 90 % | Voltage pick-up setting |
| Block voltage | 0...20 % | 1 % | 10 % | Undervoltage blocking setting. This setting prevents the function from starting in undervoltage condition which is caused for example from opened breaker. |
| Start signal only | Activated Deactivated | - | Deactivated | Selection if the function issues either "Start" signal alone or both "Start" and after set time delay "Trip" signal. |
| Reset ratio | 1...10 % | 1 % | 5 % | Undervoltage protection reset ratio |
| Time delay | 0...60 000 ms | 1 ms | 100 ms | Operating time delay setting for the "Trip" signal from the "Start" signal. |

6.3.11 Residual overvoltage protection (U0>; 59N)

The residual definite time overvoltage protection function operates according to definite time characteristics, using the RMS values of the fundamental Fourier component of the zero sequence voltage ($U_N=3U_0$).

Figure. 6.3.11 - 69. The principal structure of the residual overvoltage function.



The general start signal is set active if the measured residual voltage is above the level defined by pick-up setting value. The function generates a trip command after the set definite time delay has elapsed.

Table. 6.3.11 - 36. Setting parameters of the undervoltage function.

| Parameter | Setting value / range | Step | Default | Description |
|-------------------|--------------------------|------|-------------|--|
| Operation | Off On | - | On | Operating mode selection for the function. Operation can be either enabled "On" or disabled "Off". |
| Start voltage | 2...60 % | 1 % | 30 % | Voltage pick-up setting |
| Start signal only | Activated Deactivated | - | Deactivated | Selection if the function issues either "Start" signal alone or both "Start" and after set time delay "Trip" signal. |
| Reset ratio | 1...10 % | 1 % | 5 % | Residual overvoltage protection reset ratio |
| Time delay | 0...60 000 ms | 1 ms | 100 ms | Operating time delay setting for the "Trip" signal from the "Start" signal. |


6.3.12 Thermal overload protection ($T >$; 49)

The line thermal protection measures basically the three sampled phase currents. TRMS values of each phase currents are calculated including harmonic components up to 10th harmonic, and the temperature calculation is based on the highest TRMS value of the compared three phase currents.

The basis of the temperature calculation is the step-by-step solution of the thermal differential equation. This method provides "overtemperature", i.e. the temperature above the ambient temperature. Accordingly the final temperature of the protected object is the sum of the calculated "overtemperature" and the ambient temperature.

The ambient temperature can be set manually. If the calculated temperature (calculated "overtemperature"+ambient temperature) is above the threshold values, status signals are generated: Alarm temperature, Trip temperature and Unlock/restart inhibit temperature.

Figure. 6.3.12 - 70. The principal structure of the thermal overload function.



In the figure above is presented the principal structure of the thermal overload function. The inputs of the function are the maximum of TRMS values of the phase currents, ambient temperature setting, binary input status signals and setting parameters. Function outputs binary signals for Alarm, Trip pulse and Trip with restart inhibit.

The thermal replica of the function follows the following equation.

$$H(t) = \frac{\theta(t)}{\theta_n} = \frac{I^2}{I_n^2} \left(1 - e^{-\frac{t}{T}} \right) + \frac{\theta_0}{\theta_n} e^{-\frac{t}{T}}$$

The equation's variables are as follows:

- $H(t)$ = thermal level of the heated object; the temperature as a percentage of θ_n reference temperature
- θ_n = reference temperature above the ambient temperature, which can be measured in steady state in case of a continuous I_n reference current
- I_n = reference current (can be considered as the nominal current of the heated object); if the current flows continuously then the reference temperature can be measured in steady state
- I = measured current
- θ_0 = starting temperature
- T = heating time constant.

Table. 6.3.12 - 37. Setting parameters of the thermal overload function.

| Parameter | Setting value / range | Step | Default | Description |
|-------------------|-------------------------|-------|---------|---|
| Operation | Off Pulsed Locked | - | Pulsed | Operating mode selection. "Pulsed" operation means that the function gives tripping pulse when the calculated thermal load exceeds the set thermal load. "Locked" means that the trip signal releases when the calculated thermal load is cooled under the set Unlock temperature limit after the tripping. |
| Alarm temperature | 60...200 deg | 1 deg | 80 deg | Temperature setting for the alarming of the overloading. When the calculated temperature exceeds the set alarm limit function issues an alarm signal. |
| Trip temperature | 60...200 deg | 1 deg | 100 deg | Temperature setting for the tripping of the overloading. When the calculated temperature exceeds the set alarm limit function issues a trip signal. |

| Parameter | Setting value / range | Step | Default | Description |
|---------------------|-----------------------|-------|---------|---|
| Rated temperature | 60...200 deg | 1 deg | 100 deg | Rated temperature of the protected object. |
| Base temperature | 0...40 deg | 1 deg | 40 deg | Rated ambient temperature of the device related to allowed temperature rise. |
| Unlock temperature | 20...200 deg | 1 deg | 60 deg | Releasing of the function generated trip signal when the calculated thermal load is cooled under this setting. Restart inhibit release limit. |
| Ambient temperature | 0...40 deg | 1 deg | 25 deg | Setting of the ambient temperature of the protected device. |
| Startup Term | 0...60 % | 1 % | 0 % | On device restart starting used thermal load setting. When the device is restarted the thermal protection function will start calculating the thermal replica from this starting value. |
| Rated LoadCurrent | 20...150 % | 1 % | 100 % | The rated nominal load of the protected device. |
| Time constant | 1...999 min | 1 min | 10 min | Heating time constant of the protected device. |

6.3.13 Line differential protection (87L) – transformer not in protected zone

The AQ 300 series has two kinds of line differential algorithms available, one with transformer in the protected zone and one without. The type of the protection function has to be specified when ordering, for more details refer to ordering information of the IED. This chapter explains the details of line differential protection without transformer in protected zone.

The line differential protection function provides main protection for two terminal transmission lines. The line differential protection function does not apply vector shift compensation, thus transformers must be excluded from the protected section.


The operating principle is based on synchronized Fourier basic harmonic comparison between the line ends.

The devices at both line ends sample the phase currents and calculate the Fourier basic harmonic components. These components are exchanged between the devices synchronized via communication channels. The differential characteristic is a biased characteristic with two break points. Additionally, an unbiased overcurrent stage is applied, based on the calculated differential current.

The AQ 300 series protection IEDs communicate via fiber optic cables. Generally, mono-mode cables are required, but for distances below 2 km a multi-mode cable may be sufficient. The line differential protection can be applied up to the distance of 120 km. (The limiting factor is the damping of the fiber optic channel: up to 30 dB is permitted to prevent the disturbance of operation.)

The hardware module applied is the CPU module of the AQ 300 series protection IED. The two devices are interconnected via the “process bus”.

Figure. 6.3.13 - 71. Structure of the line differential protection algorithm.



The inputs are

- the Fourier base component values of three phase currents at the local line end
- the Fourier base component values of three phase currents received from the remote end
- parameters
- status signals.

The outputs are

- the binary output status signals
- the measured values for displaying.

The software modules of the line differential protection function:

- Differential current calculation
This module calculates the differential current for phases L1, L2 and L3 separately, based on the basic Fourier components of the six line currents.
- Bias current calculation
This module calculates the restraint current common to phases L1, L2 and L3, based on the basic Fourier components of the six line currents.
- Differential characteristics
This module compares the points defined by the differential currents in phases L1, L2 and L3 separately and the restraint current with the differential characteristic, defined by parameter setting. The high-speed overcurrent protection function based on the line differential currents is also performed in this module.
- Decision logic
The decision logic module decides if a general trip command is to be generated. The following description explains the details of the individual components.

Software module calculations

Differential current calculation

This module calculates the differential current for phases L1, L2 and L3 separately, based on the basic Fourier components of the six line currents. The differential current is the vector sum of the currents at the local line end and at the remote line end. The calculation is performed using the complex Fourier phasors and the result is the magnitude of the three differential currents. The parameters needed for the calculation are listed in table below.

Table. 6.3.13 - 38. Current compensation parameters.

| Parameter | Setting range | Step | Default | Explanation |
|-------------|---------------|------|---------|--|
| LocalRatio | 0.10...2.00 | 0.01 | 1.00 | Local end current ratio compensation factor. |
| RemoteRatio | 0.10...2.00 | 0.01 | 1.00 | Remote end current ratio compensatio factor. |

These parameters can compensate the different current ratios if different current transformers are applied at the ends of the protected line. The meaning of these parameters is:

$$LocalRatio = \frac{I_{ref}}{I_{n\ local}}$$

$$RemoteRatio = \frac{I_{ref}}{I_{n\ remote}}$$

where:

I_{ref} = an arbitrary reference current, which must be the same value in both formulas for the two devices at the line, ends

$I_{n\ local}$ = the rated current of the local current transformer

$I_{n\ remote}$ = the rated current of the remote current transformer; naturally, the values (remote and local) must be swapped for the respective devices as appropriate

Bias current calculation

The bias current is the maximum of the processed phase currents:

$$I_{bias} = (\max(I)_{L1\ local}, I_{L1\ remote}, I_{L2\ local}, I_{L2\ remote}, I_{L3\ local}, I_{L3\ remote})$$


The calculation is performed using the complex Fourier phasors and the result is the bias current, the magnitude of the maximum of the six phase currents measured.

The parameters needed for the calculation are listed in the table above ("Current compensation parameters").

Line differential characteristics

The line differential characteristic is drawn in the figure below.

Figure. 6.3.13 - 72. The line differential protection characteristics.



Decision logic

The decision logic combines the following binary signals:

- Start signals of the line differential characteristic module
- Disabling status signal defined by the user, using equation editor for custom configurations.
- Custom configurations.

Additional binary signals

Blocking input signal

The line differential protection function has a binary input signal, which serves the purpose of disabling the function. The conditions of disabling are defined by the user, applying the equation editor.

Freely programmable binary signals

The line differential protection function block provides 12 input and 12 output signals that the user can apply freely. The output signals can be programmed by the user using AQtivate 300 software. These signals are listed in the table below.

Table. 6.3.13 - 39. Freely programmable binary signals.

| Parameter | Explanation |
|--------------------|--|
| SendCh01...Ch02 | Free configurable signals to be sent via communication channel |
| ReceiveCh01...Ch02 | Free configurable signals received via communication channel |

Behavior during communication errors

In case of communication errors concerning single data, the line differential protection function is tolerant. Repeated errors are recognized and the function is disabled. This fact is signaled by the "CommFail" output signal.

In error state, if healthy signals are resumed, then the system restarts operation automatically.

Measured values

The measured and displayed values of the line differential protection function

Table. 6.3.13 - 40. Measured and displayed values of line differential function.


| Measured value | Dim. | Explanation |
|----------------|------|---------------------------------|
| I Diff L1 | p.u. | Differential current in line L1 |
| I Diff L2 | p.u. | Differential current in line L2 |
| I Diff L3 | p.u. | Differential current in line L3 |
| I Bias | p.u. | Restraint current |

Note: The evaluated basic harmonic values of the measured input phase currents help the commissioning of the line differential protection function. The reference quantity of the per unit values is the rated current of the current input.

Function block

The function block of the line differential function is shown in figure below. This block shows all binary input and output status signals that are applicable in the AQtivate 300 software.

Figure. 6.3.13 - 73. The function block of the line differential function without transformer in protected zone.



The binary input and output status signals of the dead line detection function are listed in tables below.

Table. 6.3.13 - 41. The binary input signals of the line differential function.

| Binary input signal | Explanation |
|----------------------|---|
| DIFF87L_DiffBlk_GrO_ | Block |
| DIFF87L_Send01_GrO_ | Free configurable signal to be sent via communication channel |
| ... | ... |
| DIFF87L_Send12_GrO_ | Free configurable signal to be sent via communication channel |

Table. 6.3.13 - 42. The binary output signals of the line differential function.

| Binary output signal | Signal title | Explanation |
|--|---------------|---|
| Trip command of the line differential protection function | | |
| DIFF87L_TrL1_GrL_ | Trip L1 | Trip command in line L1 |
| DIFF87L_TrL2_GrL_ | Trip L2 | Trip command in line L2 |
| DIFF87L_TrL3_GrL_ | Trip L3 | Trip command in line L3 |
| DIFF87L_GenTr_GrL_ | | General trip command |
| Free configurable signals to be sent via communication channel | | |
| DIFF87L_Rec01_GrL_ | Received Ch01 | Free configurable signal received via communication channel |
| ... | ... | ... |
| DIFF87L_Rec12_GrL_ | Received Ch12 | Free configurable signal received via communication channel |
| Communication failure signal | | |
| DIFF87L_CommFail_GrL_ | CommFail | Signal indicating communication failure |

Setting parameters

Table. 6.3.13 - 43. Setting parameters of the line differential protection with transformer within protected zone.

| Parameter | Setting range | Step | Default | Explanation |
|----------------------|---------------|------|---------|--|
| Operation | On Off | - | Off | Setting parameter to enable the line differential protection function. |
| Base Sensitivity | 10...50 % | 1 % | 30 % | Base Sensitivity setting of the differential characteristics. |
| 1st Slope | 10...50 % | 1 % | 30 % | 1st Slope setting |
| 2nd Slope | 50...100 % | 1 % | 70 % | 2nd Slope setting |
| 1st Slope Bias Limit | 100...400 % | 1 % | 200 % | 1st Slope Bias Limit (second turning point) |
| UnRst Diff Current | 500...1 500 % | 1 % | 800 % | Unrestrained line differential protection current level |
| Local Ratio | 0.10...2.00 | 0.01 | 1.00 | Local end current ratio compensation factor |
| Remote Ratio | 0.10...2.00 | 0.01 | 1.00 | Remote end current ratio compensation factor |

For the correct operation of the line differential protection function, the parameters for the process bus must be set. These parameters can be found on the “system settings” tab if the remote user interface communicates with the device. (For details see the document “Remote user interface description”.) Figure below shows the opened section for the “Process bus settings”. Select the parameters for both devices identically, as shown in this figure.

Figure. 6.3.13 - 74. Process bus settings for line differential protection.

| [-] Process bus settings | | |
|--------------------------|-----------|-----------------|
| Process bus mode | Two party | |
| VLAN ID | 1 | (0 - 4095 / 1) |
| VLAN priority | 0 | (0 - 7 / 1) |
| M.cast MAC address | 1 | (0 - 65535 / 1) |

6.3.14 Line differential protection (87L) – transformer in protected zone


The AQ 300 series has two kinds of line differential algorithms available, one with transformer in the protected zone and one without. The type of the protection function has to be specified when ordering, for more details refer to ordering information of the IED. This chapter explains the details of line differential protection with transformer in protected zone.

The line differential protection function provides main protection for two terminal transmission lines. This version of the line differential protection function considers also vector shift compensation, thus transformers with two voltage levels can be included in the protected zone.

The operating principle is the same as in the function without transformer in the protected zone. Additionally this function applies inrush current restraint based on second harmonic detection. The restraint against transformer over-excitation uses fifth harmonic analysis.

The figure below shows the structure of the line differential protection (DIF87LTR_) algorithm to protect line and transformer in the protected zone.

Figure. 6.3.14 - 75. Structure of the line differential protection algorithm with transformer in protected zone.



The inputs are

- the Fourier base component values of three phase currents received from the remote end

- the harmonic restraint decision from the remote end
- the sampled values of three local phase currents
- parameters
- status signals.

The outputs are

- the binary output status signals
- the measured values for displaying
- the Fourier base component values of three phase currents measured at the local end, to be sent to the remote end
- the harmonic restraint decision based on the local measurement, to be sent to the remote end.

The software modules of the line differential protection function:

- Communication
These modules send/receive the calculated base harmonic Fourier vectors to/from the remote end. The interchanged data include also the general restraint signals based on second and fifth harmonic analysis of the local measured currents.
- Fourier base harmonic
This module calculates the base Fourier components of three local phase currents. These results are needed also for the high-speed differential current decision and for the second and fifth harmonic restraint calculation. This module belongs to the preparatory phase.
- Fourier 2nd harmonic
This module calculates the second harmonic Fourier components of three local phase currents. These results are needed for the second harmonic restraint decision. This module belongs to the preparatory phase.
- Fourier 5th harmonic
This module calculates the fifth harmonic Fourier components of three local phase currents. These results are needed for the fifth harmonic restraint decision. This module belongs to the preparatory phase.
- Vector group
This module compensates the phase shift and turn's ratio of the transformer. The results of this calculation are the base Fourier components of the phase-shifted phase currents for both sides of the protected zone.
- Ibias
This module calculates the bias currents needed for the differential characteristic decision.
- Idiff
This module calculates the differential currents needed for the differential characteristic decision.
- 2nd harmonic restraint
The differential current can be high in case of transformer energizing, due to the current distortion caused by the transformer iron core asymmetric saturation. In this case the second harmonic content of the local current is applied in this module to disable the operation of the differential protection function. The result of this calculation is needed for the decision logic.
- 5th harmonic restraint
The differential current can be high in case of over-excitation of the transformer, due to the current distortion caused by the transformer iron core symmetric saturation. In this case the fifth harmonic content of the local current is applied in this module to disable the operation of the differential protection function. The result of this calculation is needed for the decision logic.
- Differential characteristics
This module performs the necessary calculations for the evaluation of the "percentage differential characteristics". This curve is the function of the restraint current, which is calculated based on the magnitude of the phase-shifted phase currents. The result of this calculation is needed for the decision logic.

- **Decision logic**
The decision logic module decides if the differential current of the individual phases is above the characteristic curve of the differential protection function. The second and fifth harmonic ratio of the local current, relative to the basic harmonic content can restrain the operation of the differential protection function. The restraint signal received from the remote end has the same influence. The high-speed overcurrent protection function based on the differential currents is performed in this module too.

Individual components

The vector shift and magnitude compensation

The three-phase power transformers transform the primary voltages and currents to the secondary side according to the turn's ratio and the vector group of the transformers. The Y (star) D (delta) or Z (zig-zag) connection of the three phase coils on the primary and on the secondary side causes vector shift of the voltages and currents. The conventional electromechanical or static electronic devices of the differential protection compensate the vector shift with appropriate connection of the current transformer secondary coils. The numerical differential protection function applies matrix transformation of the directly measured currents of one side of the transformer to match them with the currents of the other side.

In the transformer differential protection of Protecta the software module „Vector_group” calculates the matrix transformation and the turn's ratio matching. Here the target of the matrix transformation is the delta (D) side.

Principle of transformation to the D side

The conventional electromechanical or static electronic devices of the differential protection compensate the vector shift with appropriate connection of the current transformer coils. The principle is that the Y connected current transformers on the delta side of the transformer do not shift the currents flowing out of the transformer. The delta connected current transformers on the Y side of the transformer however result a phase shift. This means that the Y side currents are shifted according to the vector group of the transformer to match the delta side currents.

Additionally the delta connection of the current transformers eliminates the zero sequence current component, flowing on the grounded Y side of the transformer. As on the delta side no zero sequence current can be detected, this compensation is unavoidable for the correct operation of the differential protection.

If an external phase-to-ground fault occurs at the Y side of the transformer, then zero sequence current flows on the grounded Y side, but on the delta side no out-flowing zero sequence current can be detected. Without elimination of the zero sequence current component the differential protection generates a trip command in case of external ground fault. If the connection group of the current transformers on the Y side is delta however, then no zero sequence current flows out of the group. So the problem of zero sequence current elimination in case of external ground fault is solved.

Mathematical modeling of the current transformer's vector group connection

The numerical differential protection function applies numerical matrix transformation for modeling the delta connection of the current transformers. In the practice it means cyclical subtraction of the phase currents.

In the vector shift compensation the base Fourier components of the phase currents of the local side (IL1_F1_local, IL21_F1_local, IL3_F1_local) and those of the remote side (IL1_F1_remote, IL2_F1_remote, IL3_F1_remote) are transformed to (I1Rshift, I1Sshift, I1Tshift) and (I2Rshift, I2Sshift, I2Tshift) values of both sides respectively, using matrix transformation. The method of transformation is defined by the „Code” parameter, identifying the transformer vector group connection.

The table below summarizes the method of transformation, according to the connection group of the transformers with two voltage levels.

Table. 6.3.14 - 44. Vector shift compensation with transformation to the **delta** side.

[illegible]

| Tr. conn. group | Code | Transformation of the local side currents | Transformation of the remote side currents |
|-----------------------|------|---|--|
| Yd7 | 16 | $\begin{bmatrix} I1Rshift \\ I1Sshift \\ I1Tshift \end{bmatrix} = \frac{1}{\sqrt{3}} \begin{bmatrix} 1 & 0 & -1 \\ -1 & 1 & 0 \\ 0 & -1 & 1 \end{bmatrix} \begin{bmatrix} IL1_F1_local \\ IL2_F1_local \\ IL3_F1_local \end{bmatrix}$ | $\begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix} = \begin{bmatrix} -1 & 0 & 0 \\ 0 & -1 & 0 \\ 0 & 0 & -1 \end{bmatrix} \begin{bmatrix} IL1_F1_remote \\ IL2_F1_remote \\ IL3_F1_remote \end{bmatrix}$ |
| Yd11 | 17 | $\begin{bmatrix} I1Rshift \\ I1Sshift \\ I1Tshift \end{bmatrix} = \frac{1}{\sqrt{3}} \begin{bmatrix} 1 & -1 & 0 \\ 0 & 1 & -1 \\ -1 & 0 & 1 \end{bmatrix} \begin{bmatrix} IL1_F1_local \\ IL2_F1_local \\ IL3_F1_local \end{bmatrix}$ | $\begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix} = \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} IL1_F1_remote \\ IL2_F1_remote \\ IL3_F1_remote \end{bmatrix}$ |
| Yz1 | 18 | $\begin{bmatrix} I1Rshift \\ I1Sshift \\ I1Tshift \end{bmatrix} = \frac{1}{\sqrt{3}} \begin{bmatrix} 1 & 0 & -1 \\ -1 & 1 & 0 \\ 0 & -1 & 1 \end{bmatrix} \begin{bmatrix} IL1_F1_local \\ IL2_F1_local \\ IL3_F1_local \end{bmatrix}$ | $\begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix} = \frac{1}{3} \begin{bmatrix} 2 & -1 & -1 \\ -1 & 2 & -1 \\ -1 & -1 & 2 \end{bmatrix} \begin{bmatrix} IL1_F1_remote \\ IL2_F1_remote \\ IL3_F1_remote \end{bmatrix}$ |
| Yz5 | 19 | $\begin{bmatrix} I1Rshift \\ I1Sshift \\ I1Tshift \end{bmatrix} = \frac{1}{\sqrt{3}} \begin{bmatrix} 1 & -1 & 0 \\ 0 & 1 & -1 \\ -1 & 0 & 1 \end{bmatrix} \begin{bmatrix} IL1_F1_local \\ IL2_F1_local \\ IL3_F1_local \end{bmatrix}$ | $\begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix} = \frac{1}{3} \begin{bmatrix} -2 & 1 & 1 \\ 1 & -2 & 1 \\ 1 & 1 & -2 \end{bmatrix} \begin{bmatrix} IL1_F1_remote \\ IL2_F1_remote \\ IL3_F1_remote \end{bmatrix}$ |
| Yz7 | 20 | $\begin{bmatrix} I1Rshift \\ I1Sshift \\ I1Tshift \end{bmatrix} = \frac{1}{\sqrt{3}} \begin{bmatrix} 1 & 0 & -1 \\ -1 & 1 & 0 \\ 0 & -1 & 1 \end{bmatrix} \begin{bmatrix} IL1_F1_local \\ IL2_F1_local \\ IL3_F1_local \end{bmatrix}$ | $\begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix} = \frac{1}{3} \begin{bmatrix} -2 & 1 & 1 \\ 1 & -2 & 1 \\ 1 & 1 & -2 \end{bmatrix} \begin{bmatrix} IL1_F1_remote \\ IL2_F1_remote \\ IL3_F1_remote \end{bmatrix}$ |
| Yz11 | 21 | $\begin{bmatrix} I1Rshift \\ I1Sshift \\ I1Tshift \end{bmatrix} = \frac{1}{\sqrt{3}} \begin{bmatrix} 1 & -1 & 0 \\ 0 & 1 & -1 \\ -1 & 0 & 1 \end{bmatrix} \begin{bmatrix} IL1_F1_local \\ IL2_F1_local \\ IL3_F1_local \end{bmatrix}$ | $\begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix} = \frac{1}{3} \begin{bmatrix} 2 & -1 & -1 \\ -1 & 2 & -1 \\ -1 & -1 & 2 \end{bmatrix} \begin{bmatrix} IL1_F1_remote \\ IL2_F1_remote \\ IL3_F1_remote \end{bmatrix}$ |

Magnitude compensation

The differential currents are calculated using the (I1Rshift, I1Sshift, I1Tshift) and (I2Rshift, I2Sshift, I2Tshift) values and the DIF87L_TRPr_IPar (TR local) and DIF87L_TRSec_IPar (TR remote) parameters, defined by the turn's ratio of the transformer and that of the current transformers, resulting the currents with the apostrophe ('). (The positive direction of the currents is directed in on both sides.)


$$\begin{bmatrix} IdR \\ IdS \\ IdT \end{bmatrix} = \begin{bmatrix} I1Rshift' \\ I1Sshift' \\ I1Tshift' \end{bmatrix} + \begin{bmatrix} I2Rshift' \\ I2Sshift' \\ I2Tshift' \end{bmatrix} = \frac{100}{TR_local} \begin{bmatrix} I1Rshift \\ I1Sshift \\ I1Tshift \end{bmatrix} + \frac{100}{TR_remote} \begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix}$$

The current measuring software modules process these Fourier base harmonic values of the differential currents.

The principal scheme of the vector group compensation

Figure below shows the principal scheme of the vector shift compensation.

Figure. 6.3.14 - 76. Principal scheme of the vector shift compensation.



The inputs are:

- The three phase Fourier current vectors of the local side (IL1_F1_local, IL2_F1_local, IL3_F1_local)
- The three phase Fourier current vectors of the remote side (IL1_F1_remote, IL2_F1_remote, IL3_F1_remote)
- Parameters for vector shift and turn's ratio compensation.

The outputs are the phase-shifted currents:

The differential currents after phase-shift:

$$\begin{bmatrix} IdR \\ IdS \\ IdT \end{bmatrix}$$

The local currents after phase-shift:

$$\begin{bmatrix} I1Rshift' \\ I1Sshift' \\ I1Tshift' \end{bmatrix}$$

The remote currents after phase-shift:

$$\begin{bmatrix} I2Rshift' \\ I2Sshift' \\ I2Tshift' \end{bmatrix}$$

Harmonic restraint decision


The phase currents and the differential currents can be high in case of transformer energizing, due to the current distortion caused by the transformer iron core asymmetric saturation. In this case the second harmonic content of the differential current is applied to disable the operation of the differential protection function.

The differential current can be high in case of over-excitation of the transformer, due to the current distortion caused by the transformer iron core symmetric saturation. In this case the fifth harmonic content of the differential current is applied to disable the operation of the differential protection function.

The harmonic analysis block of modules consists of two sub-blocks, one for the second harmonic decision and one for the fifth harmonic decision. Each sub-blocks include three individual software modules for the phases.

The software modules evaluate the harmonic content relative to the basic harmonic component of the local phase currents, and compare the result with the parameter values, set for the second and fifth harmonic. If the content is high, then the assigned status signal is set to "true" value. If the duration of the active status is at least 25ms, then resetting of the status signal is delayed by additional 15ms.

Figure. 6.3.14 - 77. Principal scheme of the harmonic restraint decision.



The inputs are the basic, the second and the fifth harmonic Fourier components of the differential currents:

The basic harmonic Fourier components of the differential currents:

$$\begin{bmatrix} IL1_F1_local \\ IL2_F1_local \\ IL3_F1_local \end{bmatrix}$$

The second harmonic Fourier components of the differential currents:

$$\begin{bmatrix} IL1_F2_local \\ IL2_F2_local \\ IL3_F2_local \end{bmatrix}$$


The fifth harmonic Fourier components of the differential currents:

$$\begin{bmatrix} IL1_F5_local \\ IL2_F5_local \\ IL3_F5_local \end{bmatrix}$$

Parameters

The outputs of the modules are the status signals for each phase and for second and fifth harmonics separately, indicating the restraint status caused by high harmonic contents.

Figure. 6.3.14 - 78. Logic scheme of the harmonic restraint decision.



The logic scheme is repeated for the second (n=2) and fifth (n=5) harmonic restraint decision, for all three phases separately (x=L1, L2, L3).


First the ratio of the harmonic and the base harmonic is calculated, and this ratio is compared to the parameter setting (second and fifth separately). In case of high ratio value the restraint signal is generated immediately, and at the same time a timer is started. If 25ms delay is over, and during the running time the high ratio was continuous, then a drop-off timer is started, which extends the duration of the restraint signal. So if the duration of the active status is at least 25 ms, then resetting of the status signal is delayed by additional 15ms.

The six status signals of the phases are connected in OR gate to result general second or fifth harmonic restraint status signals.

Current magnitude calculation

The module, which evaluates the differential characteristics, compares the magnitude of the differential currents and those of the restraint currents. For this calculation the current magnitudes are needed. These magnitudes are calculated in this module.

Figure. 6.3.14 - 79. Principal scheme of the current magnitude calculation.



The inputs are the Fourier vectors of the phase-shifted currents:

The differential currents after phase-shift:

$$\begin{bmatrix} IdR \\ IdS \\ IdT \end{bmatrix}$$

The local currents after phase-shift:

$$\begin{bmatrix} I1Rshift' \\ I1Sshift' \\ I1Tshift' \end{bmatrix}$$

The remote currents after phase-shift:

$$\begin{bmatrix} I2Rshift' \\ I2Sshift' \\ I2Tshift' \end{bmatrix}$$

The outputs are the magnitude of the calculated currents:

The magnitudes of the differential currents after phase-shift:

$$\begin{bmatrix} M_IdR \\ M_IdS \\ M_IdT \end{bmatrix}$$

The magnitudes of the local currents after phase-shift:

$$\begin{bmatrix} M_I1Rshift' \\ M_I1Sshift' \\ M_I1Tshift' \end{bmatrix}$$

The magnitudes of the remote currents after phase-shift:

$$\begin{bmatrix} M_I2Rshift' \\ M_I2Sshift' \\ M_I2Tshift' \end{bmatrix}$$


The restraint (bias) current for all phases is calculated as the maximum of the six currents:

$$M_Ibias = \text{MAX}(M_I1Rshift'; M_I2Rshift'; M_I1Sshift'; M_I2Sshift'; M_I1Tshift'; M_I2Tshift')$$

Differential characteristics

This module evaluates the differential characteristics. It compares the magnitude of the differential currents and those of the restraint currents. Based on the values of the restraint current magnitudes (denoted generally as “Ibias”) and the values of the differential current magnitudes (denoted generally as “Idiff”) the differential protection characteristics are shown in figure below.

Figure. 6.3.14 - 80. Differential protection characteristics.




Unrestrained differential function

If the calculated differential current is very high then the differential characteristic is not considered anymore, because separate status-signals for the phases are set to “true” value if the differential currents in the individual phases are above the limit, defined by parameter setting.

The decisions of the phases are connected in OR gate to result the general start status signal.

Figure. 6.3.14 - 81. Principal scheme of evaluation of differential protection characteristics.



The inputs are the magnitude of the calculated currents:

The magnitudes of the differential currents after phase-shift:

$$\begin{bmatrix} M_IdR \\ M_IdS \\ M_IdT \end{bmatrix}$$

The magnitudes of the local currents after phase-shift:

$$\begin{bmatrix} M_I1Rshift' \\ M_I1Sshift' \\ M_I1Tshift' \end{bmatrix}$$

The magnitudes of the remote currents after phase-shift:

$$\begin{bmatrix} M_I2Rshift' \\ M_I2Sshift' \\ M_I2Tshift' \end{bmatrix}$$

Decision logic


The decision logic combines the following binary signals:

- Start signals of the differential characteristic module
- Unrestrained start signals of the differential characteristic module
- Harmonic restraint signals of the 2nd harmonic restraint decision
- Harmonic restraint signals of the 5th harmonic restraint decision
- Disabling status signals defined by the user, using graphic equation editor DIF87L_BlK_GrO

The inputs are the internal calculated status signals of the differential characteristics module, those of the 2nd harmonic restraint and 5th harmonic restraint modules and binary input parameters.

These signals are processed by the decision logic of the device described in the following figure.

Figure. 6.3.14 - 82. Decision logic schema of the differential protection function.



Setting calculation example

Example data

Settings for a 120 kV line and a transformer:

Transformer data:

$S_n = 125 \text{ MVA}$

$U_1/U_2 = 132/11.5 \text{ kV/kV}$

Yd11

Current transformer:

Substation "A" CT120 — 600/1 A/A

Substation "B" CT11.5 — 6000/1 A/A

The rated current of the transformer:

$I_{1np} = 546 \text{ A}$ (primary side)

$I_{1n} = 0.91 \text{ A}$ (secondary side)

Calculated current on the secondary side of the transformer:

$I_{2np} = 132/11.5 \cdot 546 \text{ A} = 6275 \text{ A}$

$I_{2n} = 1.05 \text{ A}$ (secondary side)

Example setting parameters

Substation "A", 120 kV

TR local = 91 %

(This is a free choice, giving the currents of the 120 kV side current transformer's current, related to the rated current of the CT.)

TR remote = 105 %

(This is a direct consequence of selecting TR local; this is the current of the secondary side current transformer related to the rated current of the CT.)

The code value of the transformer's connection group (see Table 1-1) (Yd11):

VGroup = Yd11

Substation "B", 11.5 kV

TR local = 105 %

(Opposite to substation "A".)

TR remote = 91 %

(Opposite to substation "A".)

The code value of the transformer's connection group seen from the location of the current transformer (reference is the d side)


VGroup = Dy1

(Mirrored as compared to substation "A".)

Function block

The function block of the line differential function with transformer within protected zone is shown in figure below. This block shows all binary input and output status signals that are applicable in the AQtivate 300 software.

Figure. 6.3.14 - 83. Function block of the line differential protection function with transformer within protected zone.



The binary input and output status signals of the line differential function with transformer within protected zone are listed in tables below.

Table. 6.3.14 - 45. The binary input signals of the line differential function with transformer within protected zone.

| Binary input signal | Explanation |
|----------------------|---|
| DIFF87L_DiffBlk_GrO_ | Block |
| DIFF87L_Send01_GrO_ | Free configurable signal to be sent via communication channel |
| ... | ... |
| DIFF87L_Send12_GrO_ | Free configurable signal to be sent via communication channel |

Table. 6.3.14 - 46. The binary output signals of the line differential function with transformer within protected zone.

| Binary output signal | Signal title | Explanation |
|--|-----------------|---|
| Trip command of the line differential protection function | | |
| DIFF87L_TrL1_GrL_ | Trip L1 | Trip command in line L1 |
| DIFF87L_TrL2_GrL_ | Trip L2 | Trip command in line L2 |
| DIFF87L_TrL3_GrL_ | Trip L3 | Trip command in line L3 |
| DIFF87L_GenTr_GrL_ | | General trip command |
| Harmonic blocking | | |
| DIFF87L_HarmBlk_GrL_ | Harmonic restr. | Harmonic blocking |
| Free configurable signals to be sent via communication channel | | |
| DIFF87L_Rec01_GrL_ | Received Ch01 | Free configurable signal received via communication channel |
| ... | ... | ... |


| Binary output signal | Signal title | Explanation |
|------------------------------|---------------|---|
| DIFF87L_Rec12_Grl_ | Received Ch12 | Free configurable signal received via communication channel |
| Communication failure signal | | |
| DIFF87L_CommFail_Grl_ | CommFail | Signal indicating communication failure |

Setting considerations of the line differential protection

Current distribution inside the Y/d transformers

For the explanation the following positive directions are applied:


Figure. 6.3.14 - 84. Positive directions.



Three-phase fault (or normal load state)

The figure below shows the current distribution inside the transformers in case of three-phase fault or at normal, symmetrical load state:

Figure. 6.3.14 - 85. Currents in case of normal load (or three-phase fault).



On this figure k is the current ratio. The positive directions are supposed to be directed out of the transformer on both sides, as it is supposed by the differential protection. (If the directions suppose currents flowing through the transformer, then

$$I_{2R\ input} = kI/\sqrt{3}(1-a^2)$$

This indicates that the connection group of this transformer is Yd11.)

Here the primary currents form a symmetrical system:

$$\begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = I \begin{bmatrix} 1 \\ a^2 \\ a \end{bmatrix}$$


The secondary currents can be seen on the figure (please consider the division factor $\sqrt{3}$ in the effective turn's ratio):

$$\begin{bmatrix} I2Rinput \\ I2Sinput \\ I2Tinput \end{bmatrix} = k * I \frac{1}{\sqrt{3}} \begin{bmatrix} (a^2 - 1) \\ (a - a^2) \\ (1 - a) \end{bmatrix}$$

Phase-to-phase fault on the Y side

Assume I current on the primary Y side between phases S and T.

Figure. 6.3.14 - 86. Currents inside the transformer at ST fault on the Y side.



On this figure k is the current ratio.

The Y side currents are:

$$\begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = I \begin{bmatrix} 0 \\ 1 \\ -1 \end{bmatrix}$$


The delta side currents can be seen on this figure:

$$\begin{bmatrix} I2Rinput \\ I2Sinput \\ I2Tinput \end{bmatrix} = k * \frac{1}{\sqrt{3}} * I \begin{bmatrix} 1 \\ -2 \\ 1 \end{bmatrix}$$

Phase-to-phase fault on the delta side

Assume I current on the secondary delta side between phases "s" and "t".

Figure. 6.3.14 - 87. Currents inside the transformer at "st" fault on the delta side.



On this figure k is the current ratio.

The secondary currents are:

$$\begin{bmatrix} I2Rinput \\ I2Sinput \\ I2Tinput \end{bmatrix} = I \begin{bmatrix} 0 \\ 1 \\ -1 \end{bmatrix}$$


These are distributed in the delta supposing 2/3: 1/3 distribution factor. So the primary Y side currents can be seen on this figure:

$$\begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = k * \frac{1}{\sqrt{3}} * I \begin{bmatrix} -1 \\ -1 \\ 2 \end{bmatrix}$$

Single phase external fault on the Y side

Assume I fault current on the phase R in case of solidly grounded network. No power supply is supposed at the delta side:

Figure. 6.3.14 - 88. Currents inside the transformer at single phase fault at the Y side (Bauch effect).



On this figure k is the current ratio.

The primary Y side currents are:


$$\begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = I \begin{bmatrix} 1 \\ 1 \\ 1 \end{bmatrix}$$

On the delta side there are no currents flowing out of the transformer:

$$\begin{bmatrix} I2Rinput \\ I2Sinput \\ I2Tinput \end{bmatrix} = I \begin{bmatrix} 0 \\ 0 \\ 0 \end{bmatrix}$$

Assume I fault current at the Y side in phase R in case of solidly grounded neutral. Assume the power supply at the delta side:

Figure. 6.3.14 - 89. Currents inside the transformer at single phase fault at the Y side, supply at the delta side.



On this figure k is the current ratio.

The primary Y side currents are:

$$\begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = I \begin{bmatrix} 1 \\ 0 \\ 0 \end{bmatrix}$$

The delta side currents can be seen on this figure:

$$\begin{bmatrix} I2Rinput \\ I2Sinput \\ I2Tinput \end{bmatrix} = k * \frac{1}{\sqrt{3}} * I \begin{bmatrix} -1 \\ 0 \\ 1 \end{bmatrix}$$

Checking in case of symmetrical rated load currents

For the checking the positive directions defined in the Appendix is applied:

Based on the figure "Currents in case of normal load (or three-phase fault)", the primary currents are:

$$\begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = I1np * \frac{1}{600} \begin{bmatrix} 1 \\ a^2 \\ a \end{bmatrix}$$

The transformed values of the primary side:

$$\begin{bmatrix} I1Rshift' \\ I1Sshift' \\ I1Tshift' \end{bmatrix} = \frac{100}{TR_local} \frac{1}{\sqrt{3}} \begin{bmatrix} 1 & -1 & 0 \\ 0 & 1 & -1 \\ -1 & 0 & 1 \end{bmatrix} \begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = \frac{1}{\sqrt{3}} I1np * \frac{1}{600} * \frac{100}{TR_local} \begin{bmatrix} (1-a^2) \\ (a^2-a) \\ (a-1) \end{bmatrix}$$

$$\begin{bmatrix} I1Rshift' \\ I1Sshift' \\ I1Tshift' \end{bmatrix} = \frac{1}{\sqrt{3}} I1np * 0.00183 \begin{bmatrix} (1-a^2) \\ (a^2-a) \\ (a-1) \end{bmatrix}$$

The secondary currents are drawn in the above-mentioned figure (consider the division by $\sqrt{3}$ as defined by the turn's ratio):

$$\begin{bmatrix} I2Rinput \\ I2Rinput \\ I2Rinput \end{bmatrix} = I1np * \frac{132}{11.5} * \frac{1}{\sqrt{3}} * \frac{1}{6000} \begin{bmatrix} (a^2-1) \\ (a-a^2) \\ (1-a) \end{bmatrix}$$

The secondary currents are transformed by the unit matrix. It means that only the turn's ratio is considered:

$$\begin{bmatrix} I2Rshift' \\ I2Sshift' \\ I2Tshift' \end{bmatrix} = \frac{100}{TR_remote} * I1np * \frac{132}{11.5} * \frac{1}{\sqrt{3}} * \frac{1}{6000} * \begin{bmatrix} (a^2-1) \\ (a-a^2) \\ (1-a) \end{bmatrix}$$

$$\begin{bmatrix} I2Rshift' \\ I2Sshift' \\ I2Tshift' \end{bmatrix} = -\frac{1}{\sqrt{3}} I1np * 0.00182 \begin{bmatrix} (1-a^2) \\ (a^2-a) \\ (a-1) \end{bmatrix}$$

These currents are the same (with the round-off errors of. 0.5%) as the primary transformed currents, but multiplied by „-1“. As the differential currents are the sum of the shifted phase currents, these all result zero, the differential protection is balanced.

Checking for Y side external phase-to-phase fault

Assume / fault current at the Y side of the transformer in phases S and T.

According to the figure titled "Currents inside the transformer at ST fault on the Y side", the input currents from the primary side of the transformer:

$$\begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = \frac{1}{600} * I * \begin{bmatrix} 0 \\ 1 \\ -1 \end{bmatrix}$$

Transforming these currents:

$$\begin{bmatrix} I1Rshift \\ I1Sshift \\ I1Tshift \end{bmatrix} = \frac{1}{\sqrt{3}} * \begin{bmatrix} 1 & -1 & 0 \\ 0 & 1 & -1 \\ -1 & 0 & 1 \end{bmatrix} \begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = \frac{1}{\sqrt{3}} * I * \frac{1}{600} * \frac{100}{TR_local} \begin{bmatrix} -1 \\ 2 \\ -1 \end{bmatrix}$$

$$\begin{bmatrix} I1Rshift \\ I1Sshift \\ I1Tshift \end{bmatrix} = \frac{1}{\sqrt{3}} * I * 0.00183 \begin{bmatrix} -1 \\ 2 \\ -1 \end{bmatrix}$$

The input currents from the secondary side of the transformer can be seen in the above-mentioned figure:

$$\begin{bmatrix} I2Rinput \\ I2Sinput \\ I2Tinput \end{bmatrix} = \frac{1}{6000} * \frac{132}{11.5} * \frac{1}{\sqrt{3}} * I * \begin{bmatrix} 1 \\ -2 \\ 1 \end{bmatrix}$$

These secondary side currents are transformed with the unit matrix, so only the turn's ratio has to be considered:

$$\begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix} = \frac{100}{TR_remote} * I * \frac{132}{11.5} * \frac{1}{\sqrt{3}} * \frac{1}{6000} * \begin{bmatrix} 1 \\ -2 \\ 1 \end{bmatrix}$$

$$\begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix} = -\frac{1}{\sqrt{3}} * I * 0.00182 \begin{bmatrix} -1 \\ 2 \\ -1 \end{bmatrix}$$

These currents are the same (with the round-off errors of 0.5%) as the primary transformed currents, but multiplied by „-1“. As the differential currents are the sum of the shifted phase currents, these all result zero, the differential protection is balanced.

Here the attention must be drawn to the multiplication factor „2“ in phase S. The consequences must be analyzed in a separate chapter.

Checking for D side external phase-to-phase fault

Assume I fault current at the D side of the transformer in phases S and T.

According to the figure titled "Currents inside the transformer at „st“ fault on the delta side", the input currents to the differential protection are:

$$\begin{bmatrix} I2Rinput \\ I2Sinput \\ I2Tinput \end{bmatrix} = \frac{1}{6000} * I * \begin{bmatrix} 0 \\ 1 \\ -1 \end{bmatrix}$$

These secondary side currents are transformed with the unit matrix, so only the turn's ratio has to be considered:

$$\begin{bmatrix} I2Rshift^* \\ I2Sshift^* \\ I2Tshift^* \end{bmatrix} = \frac{100}{TR_remote} * I \frac{1}{6000} * \begin{bmatrix} 0 \\ 1 \\ -1 \end{bmatrix}$$

$$\begin{bmatrix} I2Rshift^* \\ I2Sshift^* \\ I2Tshift^* \end{bmatrix} = 0.1587 * 10^{-3} * I \begin{bmatrix} 0 \\ 1 \\ -1 \end{bmatrix}$$

The input currents from the primary Y side can be seen in the above-mentioned figure:

$$\begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = \frac{1}{600} * \frac{11.5}{132} * \sqrt{3} * I * \frac{1}{3} \begin{bmatrix} -1 \\ -1 \\ 2 \end{bmatrix}$$

The transformation of these Y side currents:

$$\begin{bmatrix} I1Rshift^* \\ I1Sshift^* \\ I1Tshift^* \end{bmatrix} = \frac{1}{\sqrt{3}} * \begin{bmatrix} 1 & -1 & 0 \\ 0 & 1 & -1 \\ -1 & 0 & 1 \end{bmatrix} \begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = \frac{1}{\sqrt{3}} * I * \frac{1}{600} * \frac{100}{TR_local} * \frac{11.5}{132} \begin{bmatrix} 0 \\ -1 \\ 1 \end{bmatrix}$$

$$\begin{bmatrix} I1Rshift^* \\ I1Sshift^* \\ I1Tshift^* \end{bmatrix} = -I * 0.1596 * 10^{-3} * \begin{bmatrix} 0 \\ 1 \\ -1 \end{bmatrix}$$

These currents are the same (with the round-off errors of. 0.5%) as the secondary transformed currents, but multiplied by „-1“. As the differential currents are the sum of the shifted phase currents, these all result zero, the differential protection is balanced.

Here the attention must be drawn to the multiplication factor „-1“ and „1“ in phases S and T, respectively. The consequences must be analyzed in a separate chapter.

Checking for Y side external phase-to-ground fault

If the neutral point of the transformer is grounded, an R phase to ground primary I fault current can be supposed. Suppose additionally that no supply from the delta side can be expected.

Based on the figure titled "Currents inside the transformer at single phase fault at the Y side (Bauch effect)", the input currents from the Y side are:

$$\begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = \frac{1}{600} * I * \begin{bmatrix} 1 \\ 1 \\ 1 \end{bmatrix}$$

The transformation of the primary currents:

$$\begin{bmatrix} I1Rshift^* \\ I1Sshift^* \\ I1Tshift^* \end{bmatrix} = \frac{1}{\sqrt{3}} * \begin{bmatrix} 1 & -1 & 0 \\ 0 & 1 & -1 \\ -1 & 0 & 1 \end{bmatrix} \begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = \frac{1}{\sqrt{3}} * I * \frac{1}{600} * \frac{100}{TR_primary} \begin{bmatrix} 0 \\ 0 \\ 0 \end{bmatrix} = \begin{bmatrix} 0 \\ 0 \\ 0 \end{bmatrix}$$

The secondary currents can be seen in the above-mentioned figure:

$$\begin{bmatrix} I2Rinput \\ I2Sinput \\ I2Tinput \end{bmatrix} = \frac{1}{6000} * \frac{132}{11.5} * \frac{1}{\sqrt{3}} * I * \begin{bmatrix} 0 \\ 0 \\ 0 \end{bmatrix}$$

These secondary currents are transformed with the unit matrix, so only the turn's ratio is considered:

$$\begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix} = \frac{1}{\sqrt{3}} * I * \frac{1}{6000} * \frac{100}{TR_primary} * \frac{132}{11.5} \begin{bmatrix} 0 \\ 0 \\ 0 \end{bmatrix} = \begin{bmatrix} 0 \\ 0 \\ 0 \end{bmatrix}$$

Because of zero currents, the differential protection is stable.

Now suppose I fault current in phase R on the external primary side of the transformer, if the neutral is grounded. The fault is supplied in this case from the delta side:

Based on the figure titled "Currents inside the transformer at single phase fault at the Y side, supply at the delta side", the input currents from the primary side are:

$$\begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = \frac{1}{600} * I * \begin{bmatrix} 1 \\ 0 \\ 0 \end{bmatrix}$$

The transformation of these primary currents:

$$\begin{bmatrix} I1Rshift \\ I1Sshift \\ I1Tshift \end{bmatrix} = \frac{1}{\sqrt{3}} * \begin{bmatrix} 1 & -1 & 0 \\ 0 & 1 & -1 \\ -1 & 0 & 1 \end{bmatrix} \begin{bmatrix} I1Rinput \\ I1Sinput \\ I1Tinput \end{bmatrix} = \frac{1}{\sqrt{3}} * I * \frac{1}{600} * \frac{100}{TR_primary} \begin{bmatrix} 1 \\ 0 \\ -1 \end{bmatrix}$$

$$\begin{bmatrix} I1Rshift \\ I1Sshift \\ I1Tshift \end{bmatrix} = \frac{1}{\sqrt{3}} * I * 0.00183 \begin{bmatrix} 1 \\ 0 \\ -1 \end{bmatrix}$$

The input currents from the delta side, based on the above-mentioned figure:

$$\begin{bmatrix} I2Rinput \\ I2Sinput \\ I2Tinput \end{bmatrix} = \frac{1}{6000} * \frac{132}{11.5} * \frac{1}{\sqrt{3}} * I * \begin{bmatrix} -1 \\ 0 \\ 1 \end{bmatrix}$$

These secondary currents are transformed with the unit matrix, so only the turn's ratio is considered:

$$\begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix} = \frac{100}{TR_secondary} * I * \frac{132}{11.5} * \frac{1}{\sqrt{3}} * \frac{1}{6000} * \begin{bmatrix} -1 \\ 0 \\ 1 \end{bmatrix}$$

$$\begin{bmatrix} I2Rshift \\ I2Sshift \\ I2Tshift \end{bmatrix} = -\frac{1}{\sqrt{3}} I * 0.00182 \begin{bmatrix} 1 \\ 0 \\ -1 \end{bmatrix}$$

The currents are balanced; the differential protection does not generate a trip command.

Setting parameters

Table. 6.3.14 - 47. Setting parameters of the line differential protection with transformer within protected zone.

| Parameter | Setting range | Step | Default | Explanation |
|----------------------|---|--------|---------|---|
| Operation | On Off | - | Off | Setting parameter to enable the line differential protection function. |
| Base Sensitivity | 10...50 % | 1 % | 30 % | Base Sensitivity setting of the differential characteristics. |
| 1st Slope | 10...50 % | 1 % | 30 % | 1st Slope setting |
| 2nd Slope | 50...100 % | 1 % | 70 % | 2nd Slope setting |
| 1st Slope Bias Limit | 100...400 % | 1 % | 200 % | 1st Slope Bias Limit (second turning point) |
| UnRst Diff Current | 500...1 500 % | 1 % | 800 % | Unrestrained line differential protection current level |
| 2nd Harm Ratio | 5...50 % | 1 % | 15 % | 2nd harmonic restraint setting |
| 5th Harm Ratio | 5...50 % | 1 % | 25 % | 5th harmonic restraint setting |
| TR Local | 20...500 % | 0.01 % | 100 % | Local end current ratio compensation setting in percentage of the rated input current. |
| TR Remote | 20...500 % | 0.01 % | 100 % | Remote end current ratio compensation setting in percentage of the rated input current. |
| VGroup | Dy1, Dy5, Dy7, Dy11 Dd0, Dd6 Dz0, Dz2, Dz4, Dz6, Dz8, Dz10 Yy0, Yy6 Yd1, Yd5, Yd7, Yd11 Yz1, Yz5, Yz7, Yz11 | - | Dd0 | Transformer connection group of the coils in primary-secondary relation. |

6.3.15 Overfrequency protection (f>; 81O)

The deviation of the frequency from the rated system frequency indicates unbalance between the generated power and the load demand. If the available generation is large compared to the consumption by the load connected to the power system, then the system frequency is above the rated value.

The over-frequency protection function is usually applied to decrease generation to control the system frequency. Another possible application is the detection of unintended island operation of distributed generation and some consumers. In the island, there is low probability that the power generated is the same as consumption; accordingly, the detection of high frequency can be an indication of island operation. Accurate frequency measurement is also the criterion for the synchro-check and synchro-switch functions.

The frequency measurement is based on channel No. 1 (line voltage) and channel No. 4 (busbar voltage) of the voltage input module. In some applications, the frequency is measured based on the weighted sum of the phase voltages. The accurate frequency measurement is performed by measuring the time period between two rising edges at zero crossing of a voltage signal.

For the confirmation of the measured frequency, at least four subsequent identical measurements are needed. Similarly, four invalid measurements are needed to reset the measured frequency to zero. The basic criterion is that the evaluated voltage should be above 30% of the rated voltage value. The over-frequency protection function generates a start signal if at least five measured frequency values are above the preset level.

Table. 6.3.15 - 48. Setting parameters of the overfrequency protection function.

| Parameter | Setting value / range | Step | Default | Description |
|-------------------|--------------------------|---------|-------------|---|
| Operation | Off On | - | On | Operating mode selection for the function. Operation can be either enabled "On" or disabled "Off". |
| Start signal only | Activated Deactivated | - | Deactivated | Selection if the function issues either "Start" signal alone or both "Start" and after set time delay "Trip" signal. |
| Start frequency | 40.00...60.00 Hz | 0.01 Hz | 51 Hz | Pick-up setting of the function. When the measured frequency value exceeds the setting value function initiates "Start" signal. |
| Time delay | 0...60 000 ms | 1 ms | 200 ms | Operating time delay setting for the "Trip" signal from the "Start" signal. |

6.3.16 Underfrequency protection ($f < f_N$; 81U)

The deviation of the frequency from the rated system frequency indicates unbalance between the generated power and the load demand. If the available generation is small compared to the consumption by the load connected to the power system, then the system frequency is below the rated value.

The under-frequency protection function is usually applied to increase generation or for load shedding to control the system frequency. Another possible application is the detection of unintended island operation of distributed generation and some consumers. In the island, there is low probability that the power generated is the same as consumption; accordingly, the detection of low frequency can be an indication of island operation. Accurate frequency measurement is also the criterion for the synchro-check and synchro-switch functions. The frequency measurement is based on channel No. 1 (line voltage) and channel No. 4 (busbar voltage) of the voltage input module. In some applications, the frequency is measured based on the weighted sum of the phase voltages. The accurate frequency measurement is performed by measuring the time period between two rising edges at zero crossing of a voltage signal.

For the confirmation of the measured frequency, at least four subsequent identical measurements are needed. Similarly, four invalid measurements are needed to reset the measured frequency to zero. The basic criterion is that the evaluated voltage should be above 30% of the rated voltage value. The under-frequency protection function generates a start signal if at least five measured frequency values are below the setting value.

Table. 6.3.16 - 49. Setting parameters of the underfrequency protection function.

| Parameter | Setting value / range | Step | Default | Description |
|-------------------|--------------------------|---------|-------------|---|
| Operation | Off On | - | On | Operating mode selection for the function. Operation can be either enabled "On" or disabled "Off". |
| Start signal only | Activated Deactivated | - | Deactivated | Selection if the function issues either "Start" signal alone or both "Start" and after set time delay "Trip" signal. |
| Start frequency | 40.00...60.00 Hz | 0.01 Hz | 49 Hz | Pick-up setting of the function. When the measured frequency value exceeds the setting value function initiates "Start" signal. |
| Time delay | 0...60 000 ms | 1 ms | 200 ms | Operating time delay setting for the "Trip" signal from the "Start" signal. |

6.3.17 Rate-of-change of frequency protection (df/dt ; 81R)

The deviation of the frequency from the rated system frequency indicates unbalance between the generated power and the load demand. If the available generation is small compared to the consumption by the load connected to the power system, then the system frequency is below the rated value. If the unbalance is large, then the frequency changes rapidly. The rate of change of frequency protection function is usually applied to reset the balance between generation and consumption to control the system frequency. Another possible application is the detection of unintended island operation of distributed generation and some consumers. In the island, there is low probability that the power generated is the same as consumption; accordingly, the detection of a high rate of change of frequency can be an indication of island operation. Accurate frequency measurement is also the criterion for the synchro-switch function.

The source for the rate of change of frequency calculation is an accurate frequency measurement. The frequency measurement is based on channel No. 1 (line voltage) and channel No. 4 (busbar voltage) of the voltage input module. In some applications, the frequency is measured based on the weighted sum of the phase voltages. The accurate frequency measurement is performed by measuring the time period between two rising edges at zero crossing of a voltage signal.

For the confirmation of the measured frequency, at least four subsequent identical measurements are needed. Similarly, four invalid measurements are needed to reset the measured frequency to zero. The basic criterion is that the evaluated voltage should be above 30% of the rated voltage value. The rate of change of frequency protection function generates a start signal if the df/dt value is above the setting value. The rate of change of frequency is calculated as the difference of the frequency at the present sampling and at three cycles earlier.

Table. 6.3.17 - 50. Setting parameters of the rate-of-change of frequency function.

| Parameter | Setting value / range | Step | Default | Description |
|-----------|-----------------------|------|---------|--|
| Operation | Off On | - | On | Operating mode selection for the function. Operation can be either enabled "On" or disabled "Off". |

| Parameter | Setting value / range | Step | Default | Description |
|-------------------|--------------------------|-----------|-------------|---|
| Start signal only | Activated Deactivated | - | Deactivated | Selection if the function issues either "Start" signal alone or both "Start" and after set time delay "Trip" signal. |
| Start df/dt | -5...5 Hz/s | 0.01 Hz/s | 0.5 Hz/s | Pick-up setting of the function. When the measured frequency value exceeds the setting value function initiates "Start" signal. |
| Time delay | 0...60 000 ms | 1 ms | 200 ms | Operating time delay setting for the "Trip" signal from the "Start" signal. |

6.3.18 Pole slip (78)

The pole slipping protection function can be applied mainly for synchronous machines. If a machine falls out of synchronism, then the voltage vector induced by the machine rotates slower or with a higher speed as compared to voltage vectors of the network. The result is that according to the frequency difference of the two vector systems, the cyclical voltage difference on the current carrying elements of the network are overloaded cyclically. To protect the stator coils from the harmful effects of the high currents and to protect the network elements, a disconnection is required.


The pole slipping protection function is designed for this purpose.

Principle of operation

The principle of operation is the impedance calculation

When a machine falls out of synchronism, then the voltage vector induced by the machine rotates slower or with a higher speed as compared to voltage vectors of the network. The result is that according to the frequency difference of the two vector systems the cyclical voltage difference on the current carrying elements of the network draws cyclically high currents. The calculated impedance moves along lines "Pole slipping" as it is indicated in figure below on the impedance plane. (The stable swings return to the same quadrant of the impedance plane along lines "Stable swing".)

Figure. 6.3.18 - 90. Pole slipping.



The characteristic feature of pole slipping is that the impedance locus leaves the characteristic at a location, where the sign of the calculated resistance (e.g. $-R_{\text{leaving}}$) is opposite to that of the entering location (e.g. $+R_{\text{entering}}$). If basically other protections on the network are expected to stop the pole slipping, then more than one vector revolution is permitted. In this case the number of the revolution can be set higher than 1, and the subsequent revolution is expected within a defined "Dead time", also set by parameter. The duration of the generated trip pulse is a parameter value.

Main features


The main features of the pole slipping protection function are as follows:

- A full-scheme system provides continuous measurement of impedances separately in three independent phase-to-phase measuring loops.
- Impedance calculation is conditional on the values of the positive sequence currents being above a defined value.
- A further condition of the operation is that the negative sequence current component is less than 1/6 of the value defined for the positive sequence component.
- The operate decision is based on quadrilateral characteristics on the impedance plane using four setting parameters.
- The number of vector revolutions can be set by a parameter.
- The duration of the trip signal is set by a parameter.
- Blocking/enabling binary input signal can influence the operation.

Structure of the pole slipping protection

The figure below shows the structure of the pole slipping protection function with quadrilateral characteristic.

Figure. 6.3.18 - 91. Structure of the pole slipping algorithm.



The inputs are

- the Fourier components of three phase voltages
- the Fourier components of three phase currents
- binary inputs
- parameters.

The outputs are

- the binary output status signals.

The software modules of the pole slipping protection function are as follows:

Z_CALC calculates the impedances ($R+jX$) of the three phase-phase measuring current loops.

Quadrilateral characteristic compares the calculated impedances with the setting values of the quadrilateral characteristics. The result is the decision for all three measuring loops if the impedance is within the offset circle.

TRIP LOGIC is the algorithm to decide to generate the trip command.

I_COND calculates the current conditions necessary for the impedance calculation.

The following description explains the details of the individual components.

Impedance calculation (Z_CALC)

The impedance protection supplied by Arcteq Ltd. continuously measures the impedances in the three line-to-line measuring loops. The calculation is performed in the phase-to-phase loops based on the line-to-line voltages and the difference of the affected phase currents. The formulas are summarized in the table below. The result of this calculation is the positive sequence impedance of the current loops.

Table. 6.3.18 - 51. Formulas for the calculation of the impedance to fault.

| Loop | Calculation of Z |
|------|--|
| L1L2 | $Z_{L1L2} = (U_{L1} - U_{L2}) / (I_{L1} - I_{L2})$ |
| L2L3 | $Z_{L2L3} = (U_{L2} - U_{L3}) / (I_{L2} - I_{L3})$ |
| L3L1 | $Z_{L3L1} = (U_{L3} - U_{L1}) / (I_{L3} - I_{L1})$ |

The numerical processes apply the simple R-L model.

For the equivalent impedance elements of the measuring loop, the following differential equation can be written:

$$u = Ri + L \frac{di}{dt}$$

If current and voltage values sampled at two separate sampling points in time are substituted in this equation, two equations are derived with the two unknown values R and L, so they can be calculated.

This basic principle is realized in the algorithm by substituting the Fourier fundamental component values of the line-to-line voltages for u and the difference of the Fourier fundamental components of two phase currents:


$$u_{L2} - u_{L3} = R_1(i_{L2} - i_{L3}) + L_1 \frac{d(i_{L2} - i_{L3})}{dt}$$

where:

R_1 = the positive sequence resistance of the line or cable section between the fault location and the relay location
 L_1 = the positive sequence inductance of the line or cable section between the fault location and the relay location
 L_1, L_2, L_3 = the three phases

The applied numerical method is solving the differential equation of the faulty loop, based on the orthogonal components of the Fourier fundamental component vectors. The calculation results complex impedances on the network frequency.

Figure. 6.3.18 - 92. Principal scheme of the impedance calculation Z_CALC.



The inputs are the Fourier components of:

- the Fourier components of three phase voltages
- the Fourier components of three phase currents, parameters.

The outputs are the calculated positive sequence impedances ($R+jX$) of the three measuring loops:

- Impedances of the three phase-to-phase loops.

The calculated impedances of the Z_CALC module

Table. 6.3.18 - 52. The measured (calculated) values of the Z_CALC module.

| Calculated value | Dim. | Explanation |
|------------------|------|---|
| $RL1L2+jXL1L2$ | ohm | Measured positive sequence impedance in the L1L2 loop |
| $RL2L3+jXL2L3$ | ohm | Measured positive sequence impedance in the L2L3 loop |
| $RL3L1+jXL3L1$ | ohm | Measured positive sequence impedance in the L3L1 loop |

Z_CALC includes three practically identical software modules for impedance calculation. The three routines for the phase-to-phase loops get line-to-line voltages calculated from the sampled phase voltages and they get differences of the phase currents.


The characteristics of the pole slip protection function (Quadrilateral characteristics)

The method is an impedance-based comparison.

The operate decision is based on quadrilateral characteristics.


The calculated $R1$ and $X1 = L1$ co-ordinate values of the three measuring loops define three points on the complex impedance plane. These impedances are the positive sequence impedances. The protection compares these points with the quadrilateral characteristics of the pole slip protection, shown in the figure below. Parameter settings decide the size and the position of the rectangle. The parameters are: R forward, X forward, R backward, X backward.

Figure. 6.3.18 - 93. The quadrilateral characteristic.



If the measured impedance enters the rectangle, then the algorithm stores the sign of the R impedance component. At leaving, the sign of the R component is evaluated again. If it is opposite to the stored value then an instable power swing, i.e. pole slip is detected. At the moment the impedance leaves the rectangle at the opposite R side, a timer is started. If the setting requires more than one vector revolutions (according to parameter "Max. cycle number"), the subsequent impedance value is required to enter into the rectangle within the running time of the timer. The running time is a parameter setting ("Dead time"). The procedure is processed for each line-to-line loop. The result is the setting of three internal status variables. This indicates that the calculated impedance performed the required number of pole slips.

Figure. 6.3.18 - 94. Principal scheme of the quadrilateral characteristic decision.



Input values

The input values are calculated by the module Z_CALC.

Table. 6.3.18 - 53. The input calculated impedances of the quadrilateral characteristics module.

| Calculated value | Dim. | Explanation |
|------------------|------|---|
| RL1L2+j XL1L2 | ohm | Calculated impedance in the fault loop L1L2 |
| RL2L3+j XL2L3 | ohm | Calculated impedance in the fault loop L2L3 |
| RL3L1+j XL3L1 | ohm | Calculated impedance in the fault loop L3L1 |

Output values

Table. 6.3.18 - 54. The output status signals of the quadrilateral characteristic module.

| Output value | Explanation |
|--------------|--|
| PsL1L2_1 | The impedance in the fault loop L1L2 performed the given number of pole slips. |
| PsL2L3_1 | The impedance in the fault loop L2L3 performed the given number of pole slips. |
| PsL3L1_1 | The impedance in the fault loop L3L1 performed the given number of pole slips. |

The parameters needed in the characteristic evaluation procedure of the pole slip function are explained in the following Tables.

Table. 6.3.18 - 55. Parameters needed in the characteristic evaluation procedure.

| Parameter | Setting value / range | Step | Description |
|-------------------|------------------------|---------------|---|
| Max. cycle number | 1...10 cycles | 1 | Definition of the number of the vector revolution up to the trip command. |
| R forward | 0.10...150.00 Ω | 0.01 Ω | R setting of the impedance characteristics in forward direction |
| X forward | 0.10...150.00 Ω | 0.01 Ω | X setting of the impedance characteristics in forward direction |
| R backward | 0.10...150.00 Ω | 0.01 Ω | R setting of the impedance characteristics in backward direction |
| X backward | 0.10...150.00 Ω | 0.01 Ω | X setting of the impedance characteristics in backward direction |

The trip logic (TRIP LOGIC) and timing

Table. 6.3.18 - 56. Dead time parameter of the trip logic.

| Parameter | Setting value / range | Step | Description |
|-----------|-----------------------|------|--|
| Dead time | 1 000...60 000 ms | 1 ms | Time delay for waiting the subsequent revolution |

The trip logic module decides to generate the trip command. The condition is that at least two out of three phase-to-phase loops detect pole slip in a number required by parameter setting. And the function is not blocked or disabled.

The duration of the trip pulse is defined by parameter setting

Table. 6.3.18 - 57. Trip pulse parameter setting.

| Parameter | Setting value / range | Description |
|-----------|-----------------------|---------------------------------------|
| Operation | Off On | Parameter for disabling the function. |

Table. 6.3.18 - 58. The input values.

| Input value | Explanation |
|---|--|
| Operation signals from the quadrilateral characteristics module (these signals are not published) | |
| PsL1L2_1 | The impedance in the fault loop L1L2 performed the given number of pole slips. |
| PsL2L3_1 | The impedance in the fault loop L2L3 performed the given number of pole slips. |
| PsL3L1_1 | The impedance in the fault loop L3L1 performed the given number of pole slips. |
| Impedance function start conditions generated by I_COND module (these signals are not published) | |
| PSLIP78_cL1_GrI_ | The current in phase L1 is sufficient for impedance calculation. |
| PSLIP78_cL2_GrI_ | The current in phase L2 is sufficient for impedance calculation. |
| PSLIP78_cL3_GrI_ | The current in phase L3 is sufficient for impedance calculation. |
| Binary status signal | Explanation |
| Start | Start signal of the function |
| Trip | Trip command of the function |
| Block | Blocking of the pole slipping function |

The current conditions of the pole slip function

The pole slip protection function can operate only if the positive sequence current component is above a certain value, defined for by a parameter value. A further condition of the operation is that the negative sequence current component is less than 1/6 of the value defined for the positive sequence component. This condition excludes the operation in case of asymmetrical faults. This module performs this preliminary decision.

Table. 6.3.18 - 59. Binary output signals.

| Binary output signal | Explanation |
|---|---|
| Impedance function start conditions generated by the I_COND module (these signal are not published) | |
| I L1 condition | The current in phase L1 is sufficient for impedance calculation |
| I L2 condition | The current in phase L2 is sufficient for impedance calculation |
| I L3 condition | The current in phase L3 is sufficient for impedance calculation |

Table. 6.3.18 - 60. Minimal current enabling.

| Parameter | Setting value / range | Step | Description |
|---------------|-----------------------|------|--|
| IPh Base Sens | 10...30 | 1 | Definition of minimal current enabling impedance calculation |

The positive sequence current is considered to be sufficient if it is above the level set by parameter PSLIP78_Imin_IPar_ (IPh Base Sens). At the same time the negative sequence component should be below 1/6 of this parameter value.

The symbol of the function in the AQtivate 300 software

Figure. 6.3.18 - 95. The function block of the pole slip function.




Table. 6.3.18 - 61. Binary I/O signals.

| Parameter | Explanation |
|-----------|--|
| Start | Start signal of the function |
| Trip | Trip command of the function |
| Block | Blocking of the pole slipping function |

6.3.19 Teleprotection (85)

The non-unit protection functions, generally distance protection, can have two, three or even more zones available. These are usually arranged so that the shortest zone corresponds to impedance slightly smaller than that of the protected section (underreach) and is normally instantaneous in operation. Zones with longer reach settings are normally time-delayed to achieve selectivity. As a consequence of the underreach setting, faults near the ends of the line are cleared with a considerable time delay. To accelerate this kind of operation, protective devices at the line ends exchange logic signals (teleprotection).

These signals can be direct trip command, blocking or permissive signals. In some applications even the shortest zone corresponds to impedance larger than that of the protected section (overreach). As a consequence of the overreach setting, faults outside the protected line would also cause an immediate trip command that is not selective. To prevent such unselective tripping, protective devices at the line ends exchange blocking logic signals. The combination of the underreach – overreach settings with direct trip command, permissive or blocking signals facilitates several standard solutions, with the aim of accelerating the trip command while maintaining selectivity.

The teleprotection function block is pre-programmed for some of these modes of operation. The required solution is selected by parameter setting; the user has to assign the appropriate inputs by graphic programming. Similarly, the user has to assign the “send” signal to a relay output and to transmit it to the far end relay. The trip command is directed graphically to the appropriate input of the trip logic, which will energize the trip coil. Depending on the selected mode of operation, the simple binary signal sent and received via a communication channel can have several meanings:

- Direct trip command
- Permissive signal
- Blocking signal.

To increase the reliability of operation, in this implementation of the telecommunication function the sending end generates a signal, which can be transmitted via two different channels.

**NOTICE!**

The type of the communication channel is not considered here. It can be one of the following: pilot wire, fiber optic channel, high frequency signal over transmission line, radio or microwave, binary communication network, etc.

The function receives the binary signal via optically isolated inputs. It is assumed that the signal received through the communication channel is converted to a DC binary signal matching the binary input requirements.

Principle of operation

For the selection of one of the standard modes of operation, the function offers two enumerated parameters. With the parameter SCH85_Op_EPar_ (Operation) the following options are available:

- PUTT
- POTT
- Dir. Comparison
- Dir. Blocking
- DUTT.

Permissive Underreach Transfer Trip (PUTT)

The IEC standard name of this mode of operation is Permissive Underreach Protection (PUP). The protection system uses telecommunication, with underreach setting at each section end. The signal is transmitted when a fault is detected by the underreach protection. Receipt of the signal at the other end initiates tripping if other local permissive conditions are also fulfilled, depending on parameter setting.

For trip command generation using the parameter SCH85_PUTT_EPar_ (PUTT Trip), the following options are available: with Pickup, and with Overreach.

Permissive Underreach Transfer Trip with Pickup

The protection system uses telecommunication, with underreach setting at each section end. The signal is transmitted when a fault is detected by the underreach protection. The signal is prolonged by a drop-down timer. Receipt of the signal at the other end initiates tripping in the local protection if it is in a started state.

Figure. 6.3.19 - 96. Permissive Underreach Transfer Trip with Pickup: Send signal generation.





Figure. 6.3.19 - 97. Permissive Underreach Transfer Trip with Pickup: Trip command generation.



Permissive Underreach Transfer Trip with Overreach

The protection system uses telecommunication, with underreach setting at each section end. The signal is transmitted when a fault is detected by the underreach protection. The signal is prolonged by a drop-down timer. Receipt of the signal at the other end initiates tripping if the local overreaching zone detects fault.

Figure. 6.3.19 - 98. Permissive Underreach Transfer Trip with Overreach: Send signal generation.





Figure. 6.3.19 - 99. Permissive Underreach Transfer Trip with Overreach: Trip command generation.



Permissive Overreach Transfer Trip (POTT)

The IEC standard name of this mode of operation is Permissive Overreach Protection (POP). The protection system uses telecommunication, with overreach setting at each section end. The signal is transmitted when a fault is detected by the overreach protection. This signal is prolonged if a general trip command is generated. Receipt of the signal at the other end permits the initiation of tripping by the local overreach protection.

Figure. 6.3.19 - 100. Permissive Overreach Transfer Trip: Send signal generation.





Figure. 6.3.19 - 101. Permissive Overreach Transfer Trip: Trip command generation.



Directional comparison (Dir.Comparison)

The protection system uses telecommunication. The signal is transmitted when a fault is detected in forward direction. This signal is prolonged if a general trip command is generated. Receipt of the signal at the other end permits the initiation of tripping by the local protection if it detected a fault in forward direction.

Figure. 6.3.19 - 102. Directional comparison: Send signal generation.





Figure. 6.3.19 - 103. Directional comparison: Trip command generation.



Blocking directional comparison (Dir.Blocking)

The IEC standard name of this mode of operation is Blocking Overreach Protection (BOP). The protection system uses telecommunication, with overreach setting at each section end. The blocking signal is transmitted when a reverse external fault is detected. The signal is prolonged by a drop-down timer. For the trip command, the forward fault detection is delayed to allow time for a blocking signal to be received from the opposite end. Receipt of the signal at the other end blocks the initiation of tripping of the local protection. The blocking signal received is prolonged if the duration of the received signal is longer than a specified minimal duration.

Figure. 6.3.19 - 104. Directional blocking: Send signal generation.





Figure. 6.3.19 - 105. Directional blocking: Trip command generation.



Direct underreaching transfer trip (DUTT)

The IEC standard name of this mode of operation is Intertripping Underreach Protection (IUP). The protection system uses telecommunication, with underreach setting at each section end. The signal is transmitted when a fault is detected by the underreach protection. Receipt of the signal at the other end initiates tripping, independent of the local protection.

Figure. 6.3.19 - 106. Directional Underreaching Transfer Trip: Send signal generation.





Figure. 6.3.19 - 107. Directional Underreaching Transfer Trip: Trip command generation.



Function block

Figure. 6.3.19 - 108. The function block of the teleprotection protection function.




Table. 6.3.19 - 62. The input and output signals of the teleprotection function block.

| Signal title | Explanation |
|----------------|--|
| Block | Blocking signal |
| Carrier fall | Signal indicating the failure of the communication channel |
| Receive opp. 1 | Signal1 received from the opposite end |

| Signal title | Explanation |
|--------------------|--|
| Receive opp. 2 | Signal2 received from the opposite end |
| Z Gen.start Fw | Protection start in forward direction |
| Z Underreach Start | Start of the underreaching zone (e.g. Z1) |
| Z Overreach Start | Start of the overreaching zone (e.g. Z2) |
| General Trip | General protection trip |
| Z Gen.start Bw | Protection start in backward direction |
| Z Teleprot. Trip | Teleprotection trip command |
| Send signal | Teleprotection signal to be transmitted to the far end |

Setting parameters

Table. 6.3.19 - 63. Setting parameters of the teleprotection function.

| Parameter | Setting value / range | Step | Default | Description |
|---------------------------|---|------|-------------------|--|
| Operation | Off PUTT POTT Dir.comparison Dir.blocking DUTT | - | Off | Operating mode of the function. |
| PUTT trip | with Pickup with Overreach | - | with Overreach | Tripping command generation setting |
| Send prolong time | 1...10 000 ms | 1 ms | 10 ms | Setting for prolonging the teleprotection signal on the sending end. |
| Direct Trip delay PUTT | 1...10 000 ms | 1 ms | 10 ms | Setting for direct delay for PUTT function. |
| Z start delay (block) | 1...10 000 ms | 1 ms | 10 ms | Setting for underimpedance start delay. |
| Min.Block time | 1...10 000 ms | 1 ms | 10 ms | Setting for minimum block time for the teleprotection. |
| Prolong Block time | 1...10 000 ms | 1 ms | 10 ms | Setting for prolonging the blocked time of teleprotection function. |

6.3.20 Inrush current detection (68)

The current can be high during transformer energizing due to the current distortion caused by the transformer iron core asymmetrical saturation. In this case, the second harmonic content of the current is applied to disable the operation of the desired protection function(s).

The inrush current detection function block analyses the second harmonic content of the current, related to the fundamental harmonic. If the content is high, then the assigned status signal is set to “true” value. If the duration of the active status is at least 25 ms, then the resetting of the status signal is delayed by an additional 15 ms. Inrush current detection is applied to residual current measurement also with dedicated separate function.

Table. 6.3.20 - 64. Setting parameters of the inrush current function.

| Parameter | Setting value / range | Step | Default | Description |
|-------------------|--|------|---------|---|
| Operation | Off Current Contact Current/ Contact | - | Current | Operating mode selection for the function. Operation can be either disabled “Off” or monitoring either measured current or contact status or both current and contact status. |
| Start current Ph | 20...200 % | 1 % | 30 % | Pick-up current for the phase current monitoring. |
| Start current N | 10...200 % | 1 % | 30 % | Pick-up current for the residual current monitoring. |
| Backup Time Delay | 60...1 000 ms | 1 ms | 200 ms | Time delay for CBFP tripping command for the back-up breakers from the pick-up of the CBFP function monitoring. |
| Pulse length | 0...60 000 ms | 1 ms | 100 ms | CBFP pulse length setting. |

6.3.21 Stub protection

There are short sections of the current path within a substation that are not properly protected by the general protection system. These sections are called stubs and they are usually between the circuit breaker and the current transformer. The general protection system measures the current of the current transformer and if fault is detected, a command is generated to open the circuit breaker.

If, however, the fault is between the circuit breaker and the current transformer, then opening the circuit breaker cannot clear the fault; it is fed via the current transformer from the other side of the protected object. This location is within the back-up zone of the other side protection and, accordingly, it is cleared by a considerable time delay.

The task of the stub protection function is to detect the fault current in the open state of the circuit breaker and to generate a quick trip command to the other side circuit breaker.

Another usual application is in the one-and-a-half circuit breaker arrangement. Here the current transformers are located either before or after the circuit breakers. Additionally, the voltage transformer is either on the bus side or on the line side of the isolator. In the last case the stub is also the section between the circuit breakers and the open line isolator, since if a fault occurs in this section, the detected voltage is independent of the fault; it is unchanged and cannot be applied for the distance protection.

The stub protection function is basically a high-speed overcurrent protection function that is enabled by the open state of a circuit breaker or maybe an isolator.

The inputs of the stub protection function are

- The Fourier components of three phase currents

- Binary inputs for enabling and activating the operation
- Parameters.

The output of the stub protection function is

- A binary output trip command to be directed to the appropriate circuit breaker(s).

If any of the phase currents is above the start current and the binary status signal activates the operation, then after a user-defined time delay the function generates a trip command.

The function can be disabled by programming the blocking signal.

Figure. 6.3.21 - 109. The function block of the stub protection function.




Table. 6.3.21 - 65. The binary output status signals.

| Binary output signal | Signal title | Explanation |
|---|---------------|---|
| Indication of starting the function in phase L1 | | |
| STB50_StL1_GrL_ | Start L1 | Indication of starting the function in phase L1 |
| Indication of starting the function in phase L2 | | |
| STB50_StL2_GrL_ | Start L2 | Indication of starting the function in phase L2 |
| Indication of starting the function in phase L3 | | |
| STB50_StL3_GrL_ | Start L3 | Indication of starting the function in phase L3 |
| General indication of starting the function | | |
| STB50_GenSt_GrL_ | General Start | OR connection of the phase starting indications |
| General trip command | | |
| STB50_GenTr_GrL_ | General Trip | Trip command generated at time-out of the dedicated timer |

Table. 6.3.21 - 66. The binary input status signals.

| Binary input signal | Signal title | Explanation |
|-------------------------|--------------|--|
| Disabling the function | | |
| STB50_BlK_GrO_ | Disable | The programmed True state of this input disables the operation of the function |
| Activating the function | | |

| Binary input signal | Signal title | Explanation |
|---------------------|--------------|---|
| STB50_Activate_GrO_ | Activate | The programmed True state of this signal indicates the open state of the circuit breaker or maybe the isolator. |

Table. 6.3.21 - 67. Setting parameters of the function.

| Parameter | Setting value/range | Step | Default | Description |
|---------------|---------------------|------|---------|--|
| Operation | Off On | - | Off | Operating mode selection for the function. Operation can be either disabled "Off" or enabled "On". |
| Start current | 10...400 % | 1 % | 50 % | Maximum current setting. |
| Time delay | 0...60 000 ms | 1 ms | 100 ms | Definite time delay of the trip command. |

6.3.22 Distance protection

The AQ 300 series distance protection can be configured to function either on polygon characteristics or Mho characteristics. The default configuration is based on polygon characteristics and if the Mho is required the corresponding function block needs to be added into configuration using AQtivate 300 software. This chapter explains the function for both polygon and Mho characteristic.

The distance protection function provides main protection for overhead lines and cables of solidly grounded networks. Its main features are as follows:

- A full-scheme system provides continuous measurement of impedance separately in three independent phase-to-phase measuring loops as well as in three independent phase-to-earth measuring loops.
- Analogue input processing is applied to the zero sequence current of the parallel line.
- Full-scheme faulty phase identification and directional signaling is provided.
- Distance-to-fault evaluation is implemented.
- Five independent distance protection zones are configured.
- The operate decision is based on polygon-shaped or Mho characteristics Mho or on offset circle characteristics (configurable using AQtivate 300 software)
- Load encroachment characteristics can be selected.

The directional decision is dynamically based on:

- Measured loop voltages if they are sufficient for decision
- Healthy phase voltages if they are available for asymmetrical faults
- Voltages stored in the memory if they are available
- Optionally the decision can be non-directional in case of switching to fault or if non-directional operation is selected.


Binary input signals and conditions can influence the operation:

- Blocking/enabling
- VT failure signal.

Detection of power swing condition and out-of-step operation are available.

The structure of the distance protection algorithm is described in figure below.

Figure. 6.3.22 - 110. Structure of the distance protection.



The inputs are:

- Sampled values and Fourier components of three phase voltages
- Sampled values and Fourier components of three phase currents
- Sampled values and Fourier components of (3I_{0p}) the zero sequence current of the parallel line
- Binary inputs
- Setting parameters

The outputs are:

- Binary output status signals
- Measured values for displaying.

The software modules of the distance protection function are as follows:

- **Z_CALC** calculates the impedances ($R+jX$) of the six measuring current loops:
 - three phase-phase loops
 - three phase-ground loops.
- **POLY** compares the calculated impedances with the setting values of the five polygon characteristics. The result is the decision for all six measuring loops and for all five polygons if the impedance is within the polygon.
- **SELECT** is the phase selection algorithm for all five zones to decide which decision is caused by a faulty loop and to exclude the false decisions in healthy loops.
- **I_COND** calculates the current conditions necessary for the phase selection logic.
- **FAULT LOCATOR** calculates the distance to fault after the trip command. The following description explains the details of the individual components.

Principle of the impedance calculation

The distance protection continuously measures the impedances in the six possible fault loops. The calculation is performed in the phase-to-phase loops based on the line-to-line voltages and the difference of the affected phase currents, while in the phase-to-earth loops the phase voltage is divided by the phase current compounded with the zero sequence current. These equations are summarized in following table for different types of faults. The result of this calculation is the positive sequence impedance of the fault loop, including the positive sequence fault resistance at the fault location. For simplicity, the influence of the zero sequence current of the parallel line is not considered in these equations.

Table. 6.3.22 - 68. Impedance calculation formulas.

| Fault | Calculation of Z | Other possible calculations |
|-----------|--|---|
| L1L2L3(N) | $Z_{L2L3} = (U_{L2} - U_{L3}) / (I_{L2} - I_{L3})$ | $Z_{L1L2}, Z_{L2L3}, Z_{L3L1}$ $Z_{L1N}, Z_{L2N}, Z_{L3N}$ |
| L1L2 | $Z_{L1L2} = (U_{L1} - U_{L2}) / (I_{L1} - I_{L2})$ | |
| L2L3 | $Z_{L2L3} = (U_{L2} - U_{L3}) / (I_{L2} - I_{L3})$ | |
| L3L1 | $Z_{L3L1} = (U_{L3} - U_{L1}) / (I_{L3} - I_{L1})$ | |
| L1L2N | $Z_{L1L2} = (U_{L1} - U_{L2}) / (I_{L1} - I_{L2})$ | Z_{L1N}, Z_{L2N} |
| L2L3N | $Z_{L2L3} = (U_{L2} - U_{L3}) / (I_{L2} - I_{L3})$ | Z_{L2N}, Z_{L3N} |
| L3L1N | $Z_{L3L1} = (U_{L3} - U_{L1}) / (I_{L3} - I_{L1})$ | Z_{L3N}, Z_{L1N} |
| L1N | $Z_{L1N} = U_{L1} / (I_{L1} + 3I_0K_N)$ | |
| L2N | $Z_{L2N} = U_{L2} / (I_{L2} + 3I_0K_N)$ | |
| L3N | $Z_{L3N} = U_{L3} / (I_{L3} + 3I_0K_N)$ | |

The central column of table contains the formula for calculation. The formulas referred to in the right-hand-side column yield the same impedance value.

$$K_N = \frac{Z_0 - Z_1}{3Z_1} = \frac{1}{3} \left(\frac{Z_0}{Z_1} - 1 \right)$$

Equation presents the earth fault compensation factor.

Table above shows that the formula containing the complex earth fault compensation factor yields the correct impedance value in case of phase-to-earth faults only; the other formula can be applied in case of phase-to-phase faults without ground. In case of other kinds of faults (three-phase (-to-earth), phase-to-phase-to-earth) both formulas give the correct impedance value if the appropriate voltages and currents are applied.


The separation of the two types of equation is based on the presence or absence of the earth (zero sequence) current. In case of a fault involving the earth (on a solidly grounded network), and if the earth current is over a certain level, the formula containing the complex earth fault compensation factor will be applied to calculate the correct impedance, which is proportional to the distance-to-fault.

It can be proven that if the setting value of the complex earth fault compensation factor is correct, the appropriate application of the formulas in the table will always yield the positive sequence impedance between the fault location and the relay location.

General method of calculation of the impedances of the fault loops

If the sampled values are suitable for the calculation (after a zero crossing there are three sampled values above a defined limit ($\sim 0.1 I_n$), and the sum of the phase currents ($3I_0$) is above $I_{phase}/4$), then the numerical processes apply the following equations.

Figure. 6.3.22 - 111. Equivalent circuit of the fault loop.



For the equivalent impedance elements of the fault loop on figure above, the following differential equation can be written:

$$u = Ri + L \frac{di}{dt}$$

If current and voltage values sampled at two separate sampling points in time are substituted in this equation, two equations are derived with the two unknown values R and L , so they can be calculated.

This basic principle is realized in the algorithm by substituting the sampled values of the line-to-line voltages for u and the difference of two phase currents in case of two- or three-phase faults without ground for i . For example, in case of an L2L3 fault:

$$u_{L2} - u_{L3} = R_1(i_{L2} - i_{L3}) + L_1 \frac{d(i_{L2} - i_{L3})}{dt}$$

In case of a phase-to-earth fault, the sampled phase voltage and the phase current modified by the zero sequence current have to be substituted:

$$u_{L1} = R_1(i_{L1} + \alpha_R 3i_0 + \beta_R 3i_{op}) + L_1 \frac{d}{dt}(i_{L1} + \alpha_L 3i_0 + \beta_L 3i_{op})$$

where:

R_1 = the positive sequence resistance of the line or cable section between the fault location and the relay location

L_1 = the positive sequence inductance of the line or cable section between the fault location and the relay location

L_1 = the faulty phase

$3i_o = iL_1 + iL_2 + iL_3$ = the sampled value of the zero sequence current of the protected line

$3i_{op} = iL_{1p} + iL_{2p} + iL_{3p}$ = the sampled value of the zero sequence current in parallel line

$\alpha_R = (R_0 - R_1)/3R_1$

$\alpha_L = (L_0 - L_1)/3L_1 = (X_0 - X_1)/3X_1$

$\beta_R = R_m/3R_1$

R_m = the real part of the mutual impedance between the protected and the parallel line

$\beta_L = L_m/3L_1 = X_m/3X_1$

L_m = the mutual inductance between the protected and the parallel line


The formula above shows that the factors for multiplying the R and L values contain different “ α ” and “ β ” factors but they are real (not complex) numbers.

The applied numerical method is solving the differential equation of the faulty loop, based on three consecutive samples.

The calculation for Zone1 is performed using two different methods in parallel:

- To achieve a better filtering effect, Fourier basic harmonic components are substituted for the components of the differential equations.
- To avoid the influence of current transformer saturation, the differential equation is solved directly with sampled currents and voltages. Under this method, sections of the current wave where the form is not distorted by CT saturation are selected for the calculation. The result of this calculation is matched to a quadrilateral characteristic, which is 85% of the parameter setting value. In case of CVT swing detection; this calculation method has no effect on the operation of the distance protection function.

Figure. 6.3.22 - 112. Impedance calculation principal scheme.



The inputs are the sampled values and Fourier components of:

- Three phase voltages
- Three phase currents
- (3lop) zero sequence current of the parallel line
- Binary inputs
- Parameters.

The binary inputs influencing the operation of the distance protection function can be selected by the user.

The outputs are the calculated positive-sequence impedances ($R+jX$) of the six measuring current loops and, as different zero sequence current compensation factors can be set for the individual zones, the impedances are calculated for each zone separately:

- Impedances of the three phase-phase loops
- Impedances of the three phase-ground loops.

Z_CALC includes six practically identical software modules for impedance calculation:


- The three members of the phase group are activated by phase voltages, phase currents and the zero sequence current calculated from the phase current and the zero sequence currents of the parallel line, as measured in a dedicated input.
- The three routines for the phase-to-phase loops get line-to-line voltages calculated from the sampled phase voltages and they get differences of the phase currents. They do not need zero sequence currents for the calculation.

Table. 6.3.22 - 69. Calculated values of the impedance module.

| Measured value | Dim. | Explanation |
|----------------|------|--|
| RL1+j XL1 | ohm | Measured positive sequence impedance in the L1N loop, using the zero sequence current compensation factor for zone 1 |
| RL2+j XL2 | ohm | Measured positive sequence impedance in the L2N loop, using the zero sequence current compensation factor for zone 1 |
| RL3+j XL3 | ohm | Measured positive sequence impedance in the L3N loop, using the zero sequence current compensation factor for zone 1 |
| RL1L2+j XL1L2 | ohm | Measured positive sequence impedance in the L1L2 loop |
| RL2L3+j XL2L3 | ohm | Measured positive sequence impedance in the L2L3 loop |
| RL3L1+j XL3XL1 | ohm | Measured positive sequence impedance in the L1L3L1 loop |

Internal logic of the impedance calculation

Figure. 6.3.22 - 113. Impedance calculation internal logic.



The decision needs logic parameter settings and, additionally, internal logic signals. The explanation of these signals is as follows:

Table. 6.3.22 - 70. Internal logic parameters of the impedance calculation.

| Parameter | Explanation |
|-----------|---|
| P_nondir_ | This logic variable is true if no directionality is programmed, i.e. the DIS21_Zn_EPar_(Operation Zone1) parameter (where n = 1...5) is set to "NonDirectional" for the individual zones. |

Table. 6.3.22 - 71. Binary input signals for the impedance calculation.

| Input status signal | Explanation |
|---------------------|--|
| CURRENT_OK_ | The current is suitable for impedance calculation in the processed loop if, after a zero crossing, there are three sampled values above a defined limit (~0.1In). For a phase-ground loop calculation, it is also required that the sum of the phase currents (3I0) should be above Iphase/4. This status signal is generated within the Z_CALC module based on the parameter DIS21_Imin_IPar_ (I minimum) and in case of phase-ground loops on parameters DIS21_I0Base_IPar_ (I0 Base sens.) and DIS21_I0Bias_IPar_ (I0 Bias). |
| VTS Block | Binary blocking signal due to error in the voltage measurement. |

| Input status signal | Explanation |
|---------------------|---|
| VOLT_OK_HIGH | The voltage is suitable for the calculation if the most recent ten sampled values include a sample above the defined limit (35 % of the nominal loop voltage). This status signal is generated within the Z_CALC module. |
| VOLT_OK_LOW | The voltage can be applied for the calculation of the impedance if the three most recent sampled three values include a sample above the defined lower limit (5 % of the nominal loop voltage), but in this case the direction is to be decided using the voltage samples stored in the memory because the secondary swings of the capacitive voltage divider distort the sampled voltage values. Below this level, the direction is decided based on the sign either of the real part of the impedance or that of the imaginary part of the impedance, whichever is higher. This status signal is generated within the Z_CALC module. |
| MEM_AVAIL | This status signal is true if the voltage memory is filled up with available samples above the defined limit for 80 ms. This status signal is generated within the Z_CALC module. |
| HEALTHY_PHASE_AVAIL | This status signal is true if there are healthy phase voltages (in case of asymmetrical faults) that can be applied to directional decision. This status signal is generated within the Z_CALC module. |

The outputs of the scheme are calculation methods applied for impedance calculation for the individual zones.

Table. 6.3.22 - 72. Calculation methods applied in the impedance calculation module.

| Calculation method | Explanation |
|--------------------|---|
| Calc(A) | No current is available, the impedances are supposed to be higher than the possible maximum setting values $R=1\,000\,000\text{ m}\Omega$, $X=1\,000\,000\text{ m}\Omega$. |
| Calc(B) | The currents and voltages are suitable for the correct impedance calculation and directional decision $R, X=f(u, i)$ |
| Calc(C) | The currents are suitable but the voltages are in the range of the CVT swings, so during the first 35 ms the directional decision is based on pre-fault voltages stored in the memory $R, X=f(u, i)$ direction = $f(U_{\text{mem}}, i)$ /in the first 35 ms/ $R, X=f(u, i)$ direction = $f(u, i)$ /after 35 ms/ |
| Calc(D) | The currents are suitable but the voltages are too low. The directional decision is based on pre-fault voltages stored in the memory $R, X=f(u, i)$ direction = $f(\max\{R(U_{\text{mem}}, i), X(U_{\text{mem}}, i)\})$ |
| Calc(E) | If no directional decision is required, the decision is based on the absolute value of the impedance $R=\text{abs}(R)$, $X=\text{abs}(X)$ |
| Calc(F) | If the decision is not possible (no voltage, no pre-fault voltage), the impedance is set to a value above the possible impedance setting $R = 1\,000\,500\text{ m}\Omega$, $X = 1\,000\,500\text{ m}\Omega$ |
| Calc(G) | If no directional decision is required, then the decision is based on the absolute value of the impedance (forward fault is supposed) $R = \text{abs}(R)$, $X = \text{abs}(X)$ |
| Calc(H) | If the decision is not possible (no voltage, no pre-fault voltage, no healthy phase voltage but directional decision is required), then the impedance is set to a value above the possible impedance setting $R = 1\,000\,500\text{ m}\Omega$, $X = 1\,000\,500\text{ m}\Omega$ |

The impedance calculation methods

The short explanation of the internal logic for the impedance calculation is as follows:

Calculation method Calc(A)

If the CURRENT_OK status signal is false, the current is very small, therefore no fault is possible. In this case, the impedance is set to extreme high values and no further calculation is performed:

$$R = 1\,000\,000, X = 1\,000\,000.$$

The subsequent decisions are performed if the current is sufficient for the calculation.

Calculation method Calc(B)

If the CURRENT_OK status signal is true and the VOLT_OK_HIGH status signal is true as well, then the current is suitable for calculation and the voltage is sufficient for the directionality decision. In this case, normal impedance calculation is performed based on the sampled currents and voltages. (The calculation method - the function "f"- is explained later.)

$$R, X = f(u, i)$$

Calculation method Calc(C)

If the CURRENT_OK status signal is true but the VOLT_OK_HIGH status signal is false or there are voltage swings, the directionality decision cannot be performed based on the available voltage signals temporarily. In this case, if the voltage is above a minimal level (in the range of possible capacitive voltage transformer swings), then the VOLT_OK_LOW status is "true", the magnitude of R and X is calculated based on the actual currents and voltages but the direction of the fault (the +/- sign of R and X) must be decided based on the voltage value stored in the memory 80 ms earlier. (The high voltage level setting assures that during the secondary swings of the voltage transformers, no distorted signals are applied for the decision). This procedure is possible only if there are stored values in the memory for 80 ms and these values were sampled during a healthy period.

$$R, X = f(u, i) \text{ direction} = f(U_{\text{mem}}, i) \text{ /in the first 35 ms/}$$

After 35 ms (when the secondary swings of the voltage transformers decayed), the directional decision returns to the measured voltage signal again:

$$R, X = f(u, i) \text{ direction} = f(u, i) \text{ /after 35 ms/}$$

Calculation method Calc(D)

If the voltage is below the minimal level, then the VOLT_OK_LOW status is "false" but if there are voltage samples stored in the memory for 80 ms, then the direction is decided based on the sign either of the real part of the impedance or that of the imaginary part of the impedance, whichever is higher.

$$R, X = f(u, i) \text{ direction} = f(\max\{R(U_{\text{mem}}, i), X(U_{\text{mem}}, i)\})$$

Calculation method Calc(E)

If no directional decision is required, the decision is based on the absolute value of the impedance (forward fault is supposed)

$$R = \text{abs}(R), X = \text{abs}(X)$$

Calculation method Calc(F)

If the voltage is not sufficient for a directional decision and no stored voltage samples are available, the impedance is set to a high value:

$R = 1\ 000\ 500$, $X = 1\ 000\ 500$

Calculation method Calc(G)

If no directional decision is required, then the decision is based on the absolute value of the impedance (forward fault is supposed)

$R = \text{abs}(R)$, $X = \text{abs}(X)$

Calculation method Calc(H)

If the voltage is not sufficient for a directional decision and no stored voltage samples are available, then the impedance is set to a high value:


$R = 1\ 000\ 500$, $X = 1\ 000\ 500$

Polygon and Mho characteristics

Polygon

The calculated R_1 and $X_1=L_1$ co-ordinate values define six points on the complex impedance plane for the six possible measuring loops. These impedances are the positive sequence impedances. The protection compares these points with the „polygon” characteristics of the distance protection. The main setting values of R and X refer to the positive sequence impedance of the fault loop, including the positive sequence fault resistance of the possible electric arc and, in case of a ground fault, the positive sequence resistance of the tower grounding as well. (When testing the device using a network simulator, the resistance of the fault location is to be applied to match the positive sequence setting values of the characteristic lines.)

Figure. 6.3.22 - 114. The characteristics of the distance protection in complex plane.




If a measured impedance point is inside the polygon, the algorithm generates the true value of the related output binary signal.

Mho

The calculated R_1 and $X_1 = \omega L_1$ co-ordinate values define six points on the complex impedance plane for the six possible measuring loops. These impedances are the positive sequence impedances. The protection compares these points with the Mho characteristics of the distance protection.

Figure. 6.3.22 - 115. The MHO characteristics of the distance protection function on the complex plane.



If a measured impedance point is inside the Mho circle, the algorithm generates the true value of the related output binary signal.

The procedure is processed for each line-to-ground loop and for each line-to-line loop. Then this is repeated for all five impedance stages. The result is the setting of 6 x 5 status variables, which indicate that the calculated impedance is within the processed Mho circle, meaning that the impedance stage has started.

Polygon and Mho characteristics logic

The calculated impedance values are compared one by one with the setting values of the corresponding characteristics. This procedure is shown schematically in figures below.

The procedure is processed for each line-to-ground loop and for each line-to-line loop. Then this is repeated for all five impedance stages. The result is the setting of 6 x 5 status variables, which indicate that the calculated impedance is within the processed characteristic, meaning that the impedance stage has started.

Figure. 6.3.22 - 116. Polygon characteristics logic.




Figure. 6.3.22 - 117. Mho characteristics logic.




Table. 6.3.22 - 73. Input impedances for the characteristics logic.

| Input values | Zones | Explanation |
|---------------|-------|--|
| RL1+j XL1 | 1...5 | Calculated impedance in the fault loop L1N using parameters of the zones individually |
| RL2+j XL2 | 1...5 | Calculated impedance in the fault loop L2N using parameters of the zones individually |
| RL3+j XL3 | 1...5 | Calculated impedance in the fault loop L3N using parameters of the zones individually |
| RL1L2+j XL1L2 | 1...5 | Calculated impedance in the fault loop L1L2 using parameters of the zones individually |
| RL2L3+j XL2L3 | 1...5 | Calculated impedance in the fault loop L2L3 using parameters of the zones individually |

| Input values | Zones | Explanation |
|------------------|-------|--|
| RL3L1+j XL3L1 | 1...5 | Calculated impedance in the fault loop L3L1 using parameters of the zones individually |

Table. 6.3.22 - 74. Output signals of the characteristics logic.

| Output values | Zones | Explanation |
|---------------|-------|--|
| ZL1_n | 1...5 | The impedance in the fault loop L1N is inside the characteristics |
| ZL2_n | 1...5 | The impedance in the fault loop L2N is inside the characteristics |
| ZL3_n | 1...5 | The impedance in the fault loop L3N is inside the characteristics |
| ZL1L2_n | 1...5 | The impedance in the fault loop L1L2 is inside the characteristics |
| ZL2L3_n | 1...5 | The impedance in the fault loop L2L3 is inside the characteristics |
| ZL3L1_n | 1...5 | The impedance in the fault loop L3L1 is inside the characteristics |


Current conditions of the distance protection function

The distance protection function can operate only if the current is sufficient for impedance calculation. Additionally, a phase-to-ground fault is detected only if there is sufficient zero sequence current. This function performs these preliminary decisions.

The current is considered to be sufficient for impedance calculation if it is above the level set by parameter DIS21_Imin_IPar_ (IPh Base Sens).

To decide the presence or absence of the zero sequence current, biased characteristics are applied. The minimal setting current DIS21_IoBase_IPar_ (Io Base sens.) and a percentage biasing DIS21_IoBias_IPar_ (Io bias) must be set. The biasing is applied for the detection of zero sequence current in the case of increased phase currents.

Figure. 6.3.22 - 118. Percentage characteristic for earth fault detection.



The distance-to-fault calculation

The distance protection function selects the faulty loop impedance (its positive sequence component) and calculates the distance to fault based on the measured positive sequence reactance and the total reactance of the line. This reference value is given as a parameter setting DIS21_LReact_FPar_. The calculated percentage value facilitates displaying the distance in kilometers if the total length of the line is correctly set by the parameter DIS21_Lgth_FPar_.

Table. 6.3.22 - 75. Setting parameters of the distance to fault calculation.

| Parameter | Title | Dim. | Min | Max | Default |
|--------------------|----------------|------|------|-------|---------|
| DIS21_Lgth_FPar_ | Line length | km | 0.1 | 1 000 | 100 |
| DIS21_LReact_FPar_ | Line reactance | ohm | 0.01 | 150 | 10 |

Online measured values of the distance protection function

Table. 6.3.22 - 76. Measured magnitudes of the distance protection function.

| Name | Title | Explanation |
|-------------------|-----------------|---|
| DIS21_HTXkm_OLM_ | Fault location | Measured distance to fault in kilometers |
| DIS21_HTXohm_OLM_ | Fault reactance | Measured reactance to fault |
| DIS21_L1N_R_OLM_ | L1N loop R | Measured positive sequence resistance in L1N loop |
| DIS21_L1N_X_OLM_ | L1N loop X | Measured positive sequence reactance in L1N loop |
| DIS21_L2N_R_OLM_ | L2N loop R | Measured positive sequence resistance in L2N loop |
| DIS21_L2N_X_OLM_ | L2N loop X | Measured positive sequence reactance in L2N loop |
| DIS21_L3N_R_OLM_ | L3N loop R | Measured positive sequence resistance in L3N loop |
| DIS21_L3N_X_OLM_ | L3N loop X | Measured positive sequence reactance in L3N loop |
| DIS21_L12N_R_OLM_ | L12 loop R | Measured positive sequence resistance in L12 loop |
| DIS21_L12N_X_OLM_ | L12 loop X | Measured positive sequence reactance in L12 loop |
| DIS21_L23N_R_OLM_ | L23 loop R | Measured positive sequence resistance in L23 loop |
| DIS21_L23N_X_OLM_ | L23 loop X | Measured positive sequence reactance in L23 loop |
| DIS21_L31N_R_OLM_ | L31 loop R | Measured positive sequence resistance in L31 loop |
| DIS21_L31N_X_OLM_ | L31 loop X | Measured positive sequence reactance in L31 loop |

Table. 6.3.22 - 77. Calculated analogue values of the distance protection function.

| Measured value | Dim. | Explanation |
|---------------------------|------|--|
| $ZL1 = RL1 + j XL1$ | ohm | Measured positive sequence impedance in the L1N loop, using the zero sequence current compensation factor for zone 1 |
| $ZL2 = RL2 + j XL2$ | ohm | Measured positive sequence impedance in the L2N loop, using the zero sequence current compensation factor for zone 1 |
| $ZL3 = RL3 + j XL3$ | ohm | Measured positive sequence impedance in the L3N loop, using the zero sequence current compensation factor for zone 1 |
| $ZL1L2 = RL1L2 + j XL1L2$ | ohm | Measured positive sequence impedance in the L1L2 loop |

| Measured value | Dim. | Explanation |
|---------------------------|------|---|
| $ZL2L3 = RL2L3 + j XL2L3$ | ohm | Measured positive sequence impedance in the L2L3 loop |
| $ZL3L1 = RL3L1 + j XL3L1$ | ohm | Measured positive sequence impedance in the L3L1 loop |
| Fault location | km | Measured distance to fault |
| Fault reactance | ohm | Measured impedance in the fault loop |

Function block

Figure. 6.3.22 - 119. The function block of the distance protection function with polygon characteristic.





Figure. 6.3.22 - 120. The function block of the distance protection function with MHO characteristic.



The binary input and output status signals of the dead line detection function are listed in tables below.

Table. 6.3.22 - 78. The binary input signals of the distance protection function.

| Binary input signal | Signal title | Explanation |
|---------------------|----------------|---|
| DIS21_VTS_GrO_ | Block from VTS | Blocking signal due to error in the voltage measurement |

| Binary input signal | Signal title | Explanation |
|---------------------|--------------|--------------------|
| DIS21_Z1Blk_GrO_ | Block Z1 | Blocking of Zone 1 |
| DIS21_Z2Blk_GrO_ | Block Z2 | Blocking of Zone 2 |
| DIS21_Z3Blk_GrO_ | Block Z3 | Blocking of Zone 3 |
| DIS21_Z4Blk_GrO_ | Block Z4 | Blocking of Zone 4 |
| DIS21_Z5Blk_GrO_ | Block Z5 | Blocking of Zone 5 |

Table. 6.3.22 - 79. The binary output status signals of the distance protection function.

| Binary output signal | Signal title | Explanation |
|----------------------|--------------|----------------------------------|
| Distance Zone 1 | | |
| DIS21_Z1St_GrL_ | Start Z1 | General start of Zone 1 |
| DIS21_Z1Tr_GrL_ | Trip Z1 | Trip command generated in Zone 1 |
| Distance Zone 2 | | |
| DIS21_Z2St_GrL_ | Start Z2 | General start of Zone 2 |
| DIS21_Z2Tr_GrL_ | Trip Z2 | Trip command generated in Zone 2 |
| Distance Zone 3 | | |
| DIS21_Z3St_GrL_ | Start Z3 | General start of Zone 3 |
| DIS21_Z3Tr_GrL_ | Trip Z3 | Trip command generated in Zone 3 |
| Distance Zone 4 | | |
| DIS21_Z4St_GrL_ | Start Z4 | General start of Zone 4 |
| DIS21_Z4Tr_GrL_ | Trip Z4 | Trip command generated in Zone 4 |
| Distance Zone 5 | | |
| DIS21_Z5St_GrL_ | Start Z5 | General start of Zone 5 |
| DIS21_Z5Tr_GrL_ | Trip Z5 | Trip command generated in Zone 5 |
| Distance Trip | | |
| DIS21_GenSt | GenStart | General start |

6.4 Control, monitoring and measurements

6.4.1 Common function

The AQ300 series devices – independently of the configured protection functions – have some common functionality. The Common function block enables certain kind of extension this common functionality:

1. The WARNING signal of the device

The AQ300 series devices have several LED-s on the front panel. The upper left LED indicates the state of the device:

- Green means normal operation
- Yellow means WARNING state
 - The device is booting while the protection functions are operable
 - No time synchron signal is received
 - There are some setting errors such as the rated frequency setting does not correspond to the measured frequency, mismatch in vector group setting in case of transformer with three voltage levels, etc.
 - Wrong phase-voltage v.s. line-to-line voltage assignment
 - No frequency source is assigned for frequency related functions
 - The device is switched off from normal mode to Blocked or Test or Off mode
 - The device is in simulation mode
 - There is some mismatch in setting the rated values of the analog inputs.
- Red means ERROR state. (This state is indicated also by the dedicated binary output of the power supply module.

The list of the sources of the WARNING state can be extended using the Common function block. This additional signal is programmed by the user with the help of the graphic logic editor.

2. The latched LED signals

The latched LED signals can be reset:

- By the dedicated push button below the LED-s on the front panel of the device
- Using the computer connection and generating a LED reset command
- Via SCADA system, if it is configured
 - The list of the sources of the LED reset commands can be extended using the Common function block. This additional signal is programmed by the user with the help of the graphic logic editor.

The list of the sources of the LED reset commands can be extended using the Common function block. This additional signal is programmed by the user with the help of the graphic logic editor.

3. The Local/Remote state for generating command to or via the device

The Local/Remote state of the device can be toggled:

- From the local front-panel touch-screen of the device

The Local/Remote selection can be extended using the Common function block. There is possibility to apply up to 4 groups, the Local/Remote states of which can be set separately. These additional signals are programmed by the user with the help of the graphic logic editor.

4. AckButton output

AckButton output of the common function block generates a signal whenever the “X” button in the front panel of the relay has been pressed.

5. FixFalse/True

FixFalse/True can be used to write continuous 0 or 1 into an input of a function block or a logic gate.

The Common function block has binary input signals. The conditions are defined by the user applying the graphic logic editor.

Figure. 6.4.1 - 121. The function block of the common function block.




Table. 6.4.1 - 80. The binary output status signals.

| Binary output status signal | Title | Explanation |
|-----------------------------|------------|---|
| Common_ExtWarning_GrO_ | ExtWarning | Input to generate a Warning state of the device. |
| Common_ExtLoc1_GrO_ | ExtLoc1 | Input1 to set the state of group 1 to Local |
| Common_ExtRem1_GrO_ | ExtRem1 | Input1 to set the state of group 1 to Remote |
| Common_ExtLoc2_GrO_ | ExtLoc2 | Input2 to set the state of group 2 to Local |
| Common_ExtRem2_GrO_ | ExtRem2 | Input2 to set the state of group 2 to Remote |
| Common_ExtLoc3_GrO_ | ExtLoc3 | Input3 to set the state of group 3 to Local |
| Common_ExtRem3_GrO_ | ExtRem3 | Input3 to set the state of group 3 to Remote |
| Common_ExtLoc4_GrO_ | ExtLoc4 | Input4 to set the state of group 4 to Local |
| Common_ExtRem4_GrO_ | ExtRem4 | Input4 to set the state of group 4 to Remote |
| LEDReset | LED reset | Input to reset the LEDs on the front panel of the device. |

Table. 6.4.1 - 81. The binary input status signals.

| Binary input status signal | Title | Explanation |
|----------------------------|----------|---|
| Common_Local1_GrI_ | Local 1 | Output 1 to indicate the state of group 1 as Local |
| Common_Remote1_GrI_ | Remote 1 | Output 1 to indicate the state of group 1 as Remote |
| Common_Local2_GrI_ | Local 2 | Output 2 to indicate the state of group 2 as Local |
| Common_Remote2_GrI_ | Remote 2 | Output 2 to indicate the state of group 2 as Remote |
| Common_Local3_GrI_ | Local 3 | Output 3 to indicate the state of group 3 as Local |
| Common_Remote3_GrI_ | Remote 3 | Output 3 to indicate the state of group 3 as Remote |
| Common_Local4_GrI_ | Local 4 | Output 4 to indicate the state of group 4 as Local |

| Binary input status signal | Title | Explanation |
|----------------------------|---------------|--|
| Common_Remote4_Grl_ | Remote 4 | Output 4 to indicate the state of group 4 as Remote |
| Common_FixFalse_Grl_ | False | Fix signal FALSE to be applied in the graphic logic editor, if needed |
| Common_FixTrue_Grl_ | True | Fix signal TRUE to be applied in the graphic logic editor, if needed |
| Common_AckButton_Grl_ | AckButton | This is the composed signal which resets the LEDs, for further processing |
| Common_SysWarning_Grl_ | SystemWarning | This is the composed signal with the meaning "WARNING state", for further processing |

The Common function block has a single Boolean parameter. The role of this parameter is to enable or disable the external setting of the Local/Remote state.


Table. 6.4.1 - 82. Setting parameters.

| Parameter | Setting value/ range | Description |
|------------------|-------------------------|---|
| Ext LR Source | 0 | "0" means no external local/remote setting is enabled, the local LCD touch-screen is the only source of toggling. |

6.4.2 Trip logic (94)

The simple trip logic function operates according to the functionality required by the IEC 61850 standard for the "Trip logic logical node". This simplified software module can be applied if only three-phase trip commands are required, that is, phase selectivity is not applied. The function receives the trip requirements of the protective functions implemented in the device and combines the binary signals and parameters to the outputs of the device.


Figure. 6.4.2 - 122. Operation logic of the trip logic function.



The trip requirements can be programmed by the user. The aim of the decision logic is to define a minimal impulse duration even if the protection functions detect a very short-time fault.


Application example

Figure. 6.4.2 - 123. Example picture where two I> TOC51 and IO> TOC51N trip signals are connected to two trip logic function blocks.




In this example we have a transformer protection supervising phase and residual currents on both sides of the transformer. So in this case the protection function trips have been connected to their individual trip logic blocks (for high voltage side and low voltage side). After connecting the trip signals into trip logic block the activation of trip contacts have to be assigned. The trip assignment is done in Software configuration → Trip signals → Trip assignment.

Figure. 6.4.2 - 124. Trip logic block #1 has been assigned as HV side trip to activate trip contact E02. Trip logic block #2 has been assigned as MV side trip to activate trip contact E04.



The trip contact assignments can be modified or the same trip logic can activate multiple contacts by adding a new trip assignment.

Figure. 6.4.2 - 125. Instructions on adding/modifying trip assignment.



Trip contact connections for wirings can be found in Hardware configuration under Rack designer → Preview or in Connection allocations.

During the parameter setting phase it should be taken care that the trip logic blocks are activated. The parameters are described in the following table.

Setting parameters

Table. 6.4.2 - 83. Setting parameters of the trip logic function.

| Parameter | Setting value/range | Step | Default | Description |
|------------------|---------------------|------|---------|--|
| Operation | On Off | - | On | Operating mode selection for the function. Operation can be either disabled "Off" or enabled "On". |
| Min pulse length | 50...60 000 ms | 1 ms | 150 ms | Minimum duration of the generated tripping impulse. |

6.4.3 Dead line detection (DLD)

The “Dead Line Detection” (DLD) function generates a signal indicating the dead or live state of the line. Additional signals are generated to indicate if the phase voltages and phase currents are above the pre-defined limits.

The task of the “Dead Line Detection” (DLD) function is to decide the Dead line/Live line state.


Criteria of “Dead line” state: all three phase voltages are below the voltage setting value AND all three currents are below the current setting value.

Criteria of “Live line” state: all three phase voltages are above the voltage setting value.

Dead line detection function is used in the voltage transformer supervision function also as an additional condition.


In the figure below is presented the operating logic of the dead line detection function.

Figure. 6.4.3 - 126. Principal scheme of the dead line detection function.



The function block of the dead line detection function is shown in figure bellow. This block shows all binary input and output status signals that are applicable in the AQtivate 300 software.

Figure. 6.4.3 - 127. The function block of the dead line detection function.



The binary input and output status signals of the dead line detection function are listed in tables below.

Table. 6.4.3 - 84. The binary input status signals.

| Binary status signal | Explanation |
|----------------------|--|
| DLD_BlK_GrO_ | Output status defined by the user to disable the dead line detection function. |

Table. 6.4.3 - 85. The binary output status signals.

| Binary output signal | Signal title | Explanation |
|----------------------|--------------------|--|
| DLD function | | |
| DLD_StUL1_GrI_ | Start UL1 | The voltage of phase L1 is above the setting limit |
| DLD_StUL2_GrI_ | Start UL2 | The voltage of phase L2 is above the setting limit |
| DLD_StUL3_GrI_ | Start UL3 | The voltage of phase L3 is above the setting limit |
| DLD_StIL1_GrI_ | Start IL1 | The current of phase L1 is above the setting limit |
| DLD_StIL2_GrI_ | Start IL2 | The current of phase L2 is above the setting limit |
| DLD_StIL3_GrI_ | Start IL3 | The current of phase L3 is above the setting limit |
| DLD_DeadLine_GrI_ | DeadLine condition | The requirements of "DeadLine condition" are fulfilled |
| DLD_LineOK_GrI_ | LineOK condition | The requirements of "Live line condition" (LineOK) are fulfilled |

Table. 6.4.3 - 86. Setting parameters of the dead line detection function.

| Parameter | Setting value/ range | Step | Default | Description |
|----------------------|-------------------------|------|---------|--|
| Operation | On Off | - | On | Operating mode selection for the function. Operation can be either disabled "Off" or enabled "On". |
| Min. operate voltage | 10...100 % | 1 % | 60 % | Minimum voltage threshold for detecting the live line status. All measured phase to ground voltages have to be under this setting level. |

| Parameter | Setting value/ range | Step | Default | Description |
|----------------------|-------------------------|------|---------|---|
| Min. operate current | 8...100 % | 1 % | 10 % | Minimum current threshold for detecting the dead line status. If all the phase to ground voltages are under the setting "Min. operate voltage" and also all the phase currents are under the "Min. operate current" setting the line status is considered "Dead". |

6.4.4 Voltage transformer supervision (VTS)

The voltage transformer supervision function generates a signal to indicate an error in the voltage transformer secondary circuit. This signal can serve, for example, a warning, indicating disturbances in the measurement, or it can disable the operation of the distance protection function if appropriate measured voltage signals are not available for a distance decision.

The voltage transformer supervision function is designed to detect faulty asymmetrical states of the voltage transformer circuit caused, for example, by a broken conductor in the secondary circuit. The voltage transformer supervision function can be used for either tripping or alarming purposes.


The voltage transformer supervision function can be used in three different modes of application:

- Zero sequence detection (for typical applications in systems with grounded neutral): "VT failure" signal is generated if the residual voltage ($3U_0$) is above the preset voltage value AND the residual current ($3I_0$) is below the preset current value.
- Negative sequence detection (for typical applications in systems with isolated or resonant grounded (Petersen) neutral): "VT failure" signal is generated if the negative sequence voltage component (U_2) is above the preset voltage value AND the negative sequence current component (I_2) is below the preset current value.
- Special application: "VT failure" signal is generated if the residual voltage ($3U_0$) is above the preset voltage value AND the residual current ($3I_0$) AND the negative sequence current component (I_2) are below the preset current values.

The voltage transformer supervision function can be triggered if "Live line" status is detected for at least 200 ms. The purpose of this delay is to avoid mal-operation at line energizing if the poles of the circuit breaker make contact with a time delay. The function is set to be inactive if "Dead line" status is detected. If the conditions specified by the selected mode of operation are fulfilled then the voltage transformer supervision function is triggered and the operation signal is generated. When the conditions for operation are no longer fulfilled, the resetting of the function depends on the mode of operation of the primary circuit:


- If the "Live line" state is valid, then the function resets after approx. 200 ms of time delay.
- If the "Dead line" state is started and the "VTS Failure" signal has been continuous for at least 100 ms, then the "VTS failure" signal does not reset; it is generated continuously even when the line is in a disconnected state. Thus, the "VTS Failure" signal remains active at reclosing.
- If the "Dead line" state is started and the "VTS Failure" signal has not been continuous for at least 100 ms, then the "VTS failure" signal resets.

Figure. 6.4.4 - 128. Operation logic of the voltage transformer supervision and dead line detection.



The voltage transformer supervision logic operates through decision logic presented in the following figure.

Figure. 6.4.4 - 129. Decision logic of the voltage transformer supervision function.




NOTICE!

For the operation of the voltage transformer supervision function the “Dead line detection function” must be operable as well: it must be enabled by binary parameter.

The function block of voltage transformer supervision function is shown in figure below. This block shows all binary input and output status signals that are applicable in the graphic equation editor.

Figure. 6.4.4 - 130. The function block of the voltage transformer supervision function.



The binary input and output status signals of voltage transformer supervision function are listed in tables below.

Table. 6.4.4 - 87. The binary input and output signals of the VTS function.

| Binary status signal | Title | Explanation |
|----------------------|------------|---|
| VTS_Blz_GrO_ | - | Output status defined by the user to disable the voltage transformer supervision function |
| VTS_Fail_Grl_ | VT Failure | Failure status signal of the VTS function |

Table. 6.4.4 - 88. Setting parameters of the VTS function.

| Parameter | Setting value/ range | Step | Default | Description |
|------------|--|------|------------------|---|
| Operation | Off Neg. Sequence Zero sequence Special | - | Neg. Sequence | Operating mode selection for the function. Operation can be either disabled "Off" or enabled with criteria "Neg. Sequence", "Zero sequence" or "Special". |
| Start URes | 5...50 % | 1 % | 30 % | Residual voltage setting limit. |
| Start IRes | 10...50 % | 1 % | 10 % | Residual current setting limit. |
| Start UNeg | 5...50 % | 1 % | 10 % | Negative sequence voltage setting limit. |
| Start INeg | 10...50 % | 1 % | 10 % | Negative sequence current setting limit. |

6.4.5 Current transformer supervision (CTS)

The current transformer supervision function can be applied to detect unexpected asymmetry in current measurement.


The function block selects maximum and minimum phase currents (fundamental Fourier components). If the difference between them is above the setting limit, the function generates a start signal. For function to be operational the highest measured phase current shall be above 10 % of the rated current and below 150% of the rated current.

The function can be disabled by parameter setting, and by an input signal programmed by the user.

The failure signal is generated after the defined time delay.

The function block of the current transformer supervision function is shown in figure bellow. This block shows all binary input and output status signals that are applicable in the AQtivate300 software.

Figure. 6.4.5 - 131. The function block of the current transformer supervision function.



The binary input and output status signals of the dead line detection function are listed in tables below.

Table. 6.4.5 - 89. The binary input and output status signals.

| Binary status signal | Title | Explanation |
|----------------------|--------|--------------------------|
| CTSuperV_BlK_GrO_ | Block | Blocking of the function |
| CTSuperV_CtFail_GrI_ | CtFail | CT failure signal |

Table. 6.4.5 - 90. Setting parameters.

| Parameter | Setting value/range | Step | Default | Description |
|-------------|---------------------|---------|-------------|--|
| Operation | On Off | - | On | Operating mode selection for the function. Operation can be either disabled "Off" or enabled "On". |
| IPhase Diff | 50...90 % | 1 % | 80 % | Phase current difference setting. |
| Time delay | 100...60 000 ms | 1 ms | 1 000 ms | CT supervision time delay. |

6.4.6 Synchrocheck (dV/da/df; 25)

Several problems can occur in the power system if the circuit breaker closes and connects two systems operating asynchronously. The high current surge can cause damage in the interconnecting elements, the accelerating forces can overstress the shafts of rotating machines or the actions taken by the protective system can result in the eventual isolation of parts of the power system.

To prevent such problems, this function checks if the systems to be interconnected are operating synchronously. If yes, then the close command is transmitted to the circuit breaker. In case of asynchronous operation, the close command is delayed to wait for the appropriate vector position of the voltage vectors on both sides of the circuit breaker. If the conditions for safe closing cannot be fulfilled within an expected time, then closing is declined.



NOTICE!

For capacitive reference voltage measurement, the voltage measurement card can be ordered with <50 mVA burden special input.

The conditions for safe closing are as follows:

- The difference of the voltage magnitudes is below the set limit.
- The difference of the frequencies is below the set limit.
- The angle difference between the voltages on both sides of the circuit breaker is within the set limit.

The function processes both automatic reclosing and manual close commands.

The limits for automatic reclosing and manual close commands can be set independently of each other.

The function compares the voltage of the line and the voltage of one of the busbar sections (Bus1 or Bus2). The bus selection is made automatically based on a binary input signal defined by the user.

For the reference of the synchrocheck any phase-to-ground or phase-to-phase voltage can be selected.

The function processes the signals of the voltage transformer supervision function and enables the close command only in case of plausible voltages.

The synchrocheck function monitors three modes of conditions:

- Energizing check:
 - Dead bus, live line
 - Live bus, dead line
 - Any Energizing case (including Dead bus, dead line)
- Synchro check (Live line, live bus)
- Synchro switch (Live line, live bus)

If the conditions for “Energizing check” and “Synchro check” are fulfilled, then the function generates the release command, and in case of a manual or automatic close request, the close command is generated.


If the conditions for energizing and synchronous operation are not met when the close request is received, then synchronous switching is attempted within the set time-out. In this case, the rotating vectors must fulfill the conditions for safe switching within the set waiting time: at the moment the contacts of the circuit breaker are closed, the voltage vectors must match each other with appropriate accuracy. For this mode of operation, the expected operating time of the circuit breaker must be set as a parameter value, to generate the close command in advance taking the relative vector rotation into consideration.

Started closing procedure can be interrupted by a cancel command defined by the user.

In “bypass” operation mode, the function generates the release signals and simply transmits the close command.

In the following figure is presented the operating logic of the synchrocheck function.

Figure. 6.4.6 - 132. Operation logic of the synchrocheck function.




The synchro check/synchro switch function contains two kinds of software blocks:

- SYN25_Com = a common block for manual switching and automatic switching.
- SYN25_EVA = an evaluation block, duplicated for manual switching and for automatic switching.

The SYN25_Com block selects the appropriate voltages for processing and calculates the voltage difference, the frequency difference and the phase angle difference between the selected voltages. The magnitude of the selected voltages is passed for further evaluation.

These values are further processed by the evaluation software blocks. The function is disabled if the binary input (Block) signal is TRUE. The activation of voltage transformer supervision function of the line voltage blocks the operation (VTS Block). The activation of voltage transformer supervision function of the selected bus section blocks the operation (VTS Bus1 Block or VTS Bus2 Block).

Figure. 6.4.6 - 133. Synchrocheck common difference calculation function structure.




If the active bus section changes the function is dynamically blocked for 1000ms and no release signal or switching command is generated. The processed line voltage is selected based on the preset parameter (Voltage select). The choice is: L1-N, L2-N, L3-N, L1-L2, L2-L3 or L3-L1. The parameter value must match the input voltages received from the bus sections. The active bus section is selected by the input signal (Bus select). If this signal is logic TRUE, then the voltage of Bus2 is selected for evaluation.

The software block SYN25_Eva is applied separately for automatic and manual commands. This separation allows the application to use different parameter values for the two modes of operation.

The structure of the evaluation software block is shown in the following figure.

Figure. 6.4.6 - 134. Synchrocheck evaluation function structure.




This evaluation software block is used for two purposes: for the automatic reclosing command (the signal names have the suffix "A") and for the manual close request (the signal names have the suffix "M"). As the first step, based on the selected line voltage and bus voltage, the state of the required switching is decided (Dead bus-Dead line, Dead bus-Live line, Live bus-Dead line or Live bus- Live line). The parameters for decision are (U Live) and (U Dead). The parameters (Energizing Auto/Manual) enable the operation individually. The choice is: (Off, DeadBus LiveLine, LiveBus DeadLine, Any energ case). In simple energizing modes, no further checking is needed. This mode selection is bypassed if the parameter (Operation Auto/Manual) is set to "ByPass". In this case the command is transmitted without any further checking.

First, the function tries switching with synchro check. This is possible if: the voltage difference is within the defined limits (Udiff SynChk Auto/Manual)) the frequency difference is within the defined limits (FrDiff SynChk Auto) and the phase angle difference is within the defined limits (MaxPhaseDiff Auto/Manual)).

If the conditions are fulfilled for at least 45 ms, then the function generates a release output signal (Release Auto/Manual). If the conditions for synchro check operation are not fulfilled and a close request is received as the input signal (SySwitch Auto/Manual), then synchro switching is attempted. This is possible if: the voltage difference is within the defined limits (Udiff SynSW Auto /Manual)) the frequency difference is within the defined limits (FrDiff SynSW Auto).

These parameters are independent of those for the synchro check function. If the conditions for synchro check are not fulfilled and the conditions for synchro switch are OK, then the relative rotation of the voltage vectors is monitored. The command is generated before the synchronous position, taking the breaker closing time into consideration (Breaker Time). The pulse duration is defined by the parameter (Close Pulse). In case of slow rotation and if the vectors are for long time near-opposite vector positions, no switching is possible, therefore the waiting time is limited by the preset parameter (Max.Switch Time).

Figure. 6.4.6 - 135. The function block of the synchrocheck/synchroswitch function.



The progress is indicated by the output status signal (SynInProgr Auto/Manual). The started command can be canceled using the input signal (Cancel Auto/Manual).

The binary input and output status signals of the dead line detection function are listed in tables below.

Table. 6.4.6 - 91. The binary input signals.

| Binary status signal | Title | Explanation |
|-----------------------|-----------------|--|
| SYN25_BusSel_GrO_ | Bus Select | If this signal is logic TRUE, then the voltage of Bus2 is selected for evaluation. |
| SYN25_VTSBlk_GrO_ | VTS Block | Blocking signal of the voltage transformer supervision function evaluating the line voltage. |
| SYN25_Bus1VTSBlk_GrO_ | VTS Bus1 Block | Blocking signal of the voltage transformer supervision function evaluating the Bus1 voltage. |
| SYN25_Bus2VTSBlk_GrO_ | VTS Bus2 Block | Blocking signal of the voltage transformer supervision function evaluating the Bus2 voltage. |
| SYN25_SwStA_GrO_ | SySwitch Auto | Switching request signal initiated by the automatic reclosing function. |
| SYN25_CancelA_GrO_ | Cancel Auto | Signal to interrupt (cancel) the automatic switching procedure. |
| SYN25_Blk_GrO_ | Block | Blocking signal of the function. |
| SYN25_SwStM_GrO_ | SySwitch Manual | Switching request signal initiated by manual closing. |

| Binary status signal | Title | Explanation |
|----------------------|---------------|--|
| SYN25_CancelM_GrO_ | Cancel Manual | Signal to interrupt (cancel) the manual switching procedure. |

Table. 6.4.6 - 92. The binary output signals.

| Binary status signal | Title | Explanation |
|----------------------|------------------|--|
| SYN25_RelA_GrI_ | Release Auto | Releasing the close command initiated by the automatic reclosing function. |
| SYN25_InProgA_GrI_ | SynInProgr Auto | Switching procedure is in progress, initiated by the automatic reclosing function. |
| SYN25_UOKA_GrI_ | Udiff OK Auto | The voltage difference is appropriate for automatic closing command. |
| SYN25_FrOKA_GrI_ | FreqDiff OK Auto | The frequency difference is appropriate for automatic closing command, evaluated for synchrocheck. |
| SYN25_AngOKA_GrI_ | Angle OK Auto | The angle difference is appropriate for automatic closing request. |
| SYN25_RelM_GrI_ | Release Man | Releasing the close command initiated by manual closing request. |
| SYN25_InProgM_GrI_ | SynInProgr Man | Switching procedure is in progress, initiated by the manual closing command. |
| SYN25_UOKM_GrI_ | Udiff OK Man | The voltage difference is appropriate for automatic closing command. |
| SYN25_FrOKM_GrI_ | FreqDiff OK Man | The frequency difference is appropriate for manual closing command, evaluated for synchrocheck. |
| SYN25_AngOKM_GrI_ | Angle OK Man | The angle difference is appropriate for manual closing command. |

Table. 6.4.6 - 93. Setting parameters.

| Parameter | Setting value/ range | Step | Default | Description |
|----------------|---|------|---------|--|
| Voltage select | L1-N L2-N L3-N L1-L2 L2-L3 L3-L1 | - | L1-N | Reference voltage selection. The function will monitor the selected voltage for magnitude, frequency and angle differences. |
| U Live | 60...110 % | 1 % | 70 % | Voltage setting limit for "Live Line" detection. When measured voltage is above the setting value the line is considered "Live". |
| U Dead | 10...60 % | 1 % | 30 % | Voltage setting limit for "Dead line" detection. When measured voltage is below the setting value the line is considered "Dead". |

| Parameter | Setting value/ range | Step | Default | Description |
|--------------------|---|---------|---------------------|---|
| Breaker Time | 0...500 ms | 1 ms | 80 ms | Breaker operating time at closing. This parameter is used for the synchroswitch closing command compensation and it describes the breaker travel time from open position to closed position from the close command. |
| Close Pulse | 10...60 000 ms | 1 ms | 1 000 ms | Close command pulse length. This setting defines the duration of close command from the IED to the circuit breaker. |
| Max Switch Time | 100...60 000 ms | 1 ms | 2 000 ms | Maximum allowed switching time. In case synchrocheck conditions are not fulfilled and the rotation of the networks is slow this parameter defines the maximum waiting time after which the close command is failed. |
| Operation Auto | On Off ByPass | - | On | Operation mode for automatic switching. Selection can be automatic switching off, on or bypassed. If the Operation Auto is set to "Off" automatic switch checking is disabled. If selection is "ByPass" Automatic switching is enabled with bypassing the bus and line energization status checking. When the selection is "On" also the energization status of bus and line are checked before processing the command. |
| SynSW Auto | On Off | - | On | Automatic synchroswitching selection. Selection may be enabled "On" or disabled "Off". |
| Energizing Auto | Off DeadBus LiveLine LiveBus DeadLine Any energ case | - | DeadBus LiveLine | Energizing mode of automatic synchroswitching. Selections consist of the monitoring of the energization status of the bus and line. If the operation is wanted to be LiveBus LiveLine or DeadBus DeadLine, the selection is "Any energ case". |
| Udiff SynChk Auto | 5...30 % | 1 % | 10 % | Voltage difference checking of the automatic synchrocheck mode. If the measured voltage difference is below this setting the condition applies. |
| Udiff SynSW Auto | 5...30 % | 1 % | 10 % | Voltage difference checking of the automatic synchroswitch mode. If the measured voltage difference is below this setting the condition applies. |
| MaxPhasediff Auto | 5...80 deg | 1 deg | 20 deg | Phase difference checking of the automatic synchroswitch mode. If the measured phase difference is below this setting the condition applies. |
| FrDiff SynChk Auto | 0.02...0.50 Hz | 0.01 Hz | 0.02 Hz | Frequency difference checking of the automatic synchrocheck mode. If the measured phase difference is below this setting the condition applies. |
| FrDiff SynSW Auto | 0.10...1.00 Hz | 0.01 Hz | 0.2 Hz | Frequency difference checking of the automatic synchroswitch mode. If the measured phase difference is below this setting the condition applies. |
| Operation Man | On Off ByPass | - | On | Operation mode for manual switching. Selection can be manual switching off, on or bypassed. If the Operation Man is set to "Off" manual switch checking is disabled. If selection is "ByPass" manual switching is enabled with bypassing the bus and line energization status checking. When the selection is "On" also the energization status of bus and line are checked before processing the command. |

| Parameter | Setting value/ range | Step | Default | Description |
|-------------------|---|---------|---------------------|---|
| SynSW Man | On Off | - | On | Manual synchroswitching selection. Selection may be enabled "On" or disabled "Off". |
| Energizing Man | Off Deadbus LiveLine LiveBus DeadLine Any energ case | - | DeadBus LiveLine | Energizing mode of manual synchroswitching. Selections consist of the monitoring of the energization status of the bus and line. If the operation is wanted to be LiveBus LiveLine or DeadBus DeadLine the selection is "Any energ case". |
| Udiff SynChk Man | 5...30 % | 1 % | 10 % | Voltage difference checking of the manual synchrocheck mode. If the measured voltage difference is below this setting the condition applies. |
| Udiff SynSW Man | 5...30 % | 1 % | 10 % | Voltage difference checking of the manual synchroswitch mode. If the measured voltage difference is below this setting the condition applies. |
| MaxPhaseDiff Man | 5...80 deg | 1 deg | 20 deg | Phase difference checking of the manual synchroswitch mode. If the measured phase difference is below this setting the condition applies. |
| FrDiff SynChk Man | 0.02...0.50 Hz | 0.01 Hz | 0.02 Hz | Frequency difference checking of the manual synchroswitch mode. If the measured phase difference is below this setting the condition applies. |
| FrDiff SynSW Man | 0.10...1.00 Hz | 0.01 Hz | 0.2 Hz | Frequency difference checking of the manual synchroswitch mode. If the measured phase difference is below this setting the condition applies. |

6.4.7 Auto-reclosing (MV) (79)

Operation

The automatic reclosing function for medium-voltage networks can perform up to four shots of reclosing. The dead time can be set individually for each reclosing and separately for earth faults and for multi-phase faults.

The starting signal of the cycles can be generated by any combination of the protection functions or external signals of the binary inputs defined by user.

The automatic reclosing function is triggered if as a consequence of a fault a protection function generates a trip command to the circuit breaker and the protection function resets because the fault current drops to zero and/or the circuit breakers auxiliary contact signals open state. According to the preset parameter values, either of these two conditions starts counting the dead time, at the end of which the automatic reclosing function generates a close command. If the fault still exist or reappears, then within the "Reclaim time" (according to parameter setting, started at the close command) the auto-reclose function picks up again and the subsequent cycle is started. If no pickup is detected within this time, then the automatic reclosing function resets and a new fault will start the procedure with the first cycle again.

Following additional requirements apply to performing automatic reclosing:

- The automatic reclosing function can be blocked with any available signal or combination of signals defined by user.

- After a pickup of the protection function, a timer starts to measure the “**Action time**” (the duration depends on parameter setting (Action time)). The trip command must be generated within this time to start reclosing cycles, or else the automatic function enters blocked state.
- At the moment of generating the close command, the circuit breaker must be ready for operation, which is signaled via binary input (CB Ready). The preset parameter value (CB Supervision time) decides how long the automatic reclosing function is allowed to wait at the end of the dead time for this signal. If the signal is not received during this dead time extension, then the automatic reclosing function terminates and after a “**dynamic blocking time**” (depending on the preset parameter value (Dynamic Blocking time)) the function resets.

In case of a manual close command (which is assigned to the logic variable (Manual Close) using equation programming), a preset parameter value decides how long the MV autorecloser function should be disabled **after the manual** close command.

The **duration of the close command** depends on preset parameter value (Close command time), but the close command terminates if any of the protection functions issues a trip command.

Cycles

The automatic reclosing function can control up to four reclosing cycles, separately for earth faults and for multi-phase faults. Depending on the preset parameter values (EarthFaults Rec,Cycle) and (PhaseFaults Rec,Cycle), there are different modes of operation, both for earth faults and for multi-phase faults:

- Disabled = no automatic reclosing is selected
- 1. Enabled = only one automatic reclosing cycle is selected
- 1.2. Enabled = two automatic reclosing cycles are activated
- 1.2.3. Enabled = three automatic reclosing cycles are activated
- 1.2.3.4. Enabled = all automatic reclosing cycles are activated.

The MV automatic reclosing function enters into the dynamic blocking state:

- If the parameter selection for (Reclosing started by) is “Trip reset” and the trip impulse is too long.
- If the parameter selected for (Reclosing started by) is “CB open”, then during the runtime of the timer CB open signal is received).

The start of dead time counter of any reclosing cycle can be delayed. The delay is activated if the value of the (Dead Time St.Delay) status signal is TRUE. This delay is defined by the timer parameter (DeadTime Max.Delay).

For all four reclosing cycles, separate dead times can be defined for line-to-line faults and for earth faults. The timer parameters for line-to-line faults are:

1. Dead Time Ph
2. Dead Time Ph
3. Dead Time Ph
4. Dead Time Ph

The timer parameters for earth faults are:

1. Dead Time EF
2. Dead Time EF
3. Dead Time EF
4. Dead Time EF

In case of evolving faults, the dead times depend on the first fault detection.

The automatic reclosing function is prepared to generate three-phase trip commands only. The applied dead time setting depends on the first detected fault type indicated by the input signal (EarthFaultTrip NoPhF). (This signal is TRUE in case of an earth fault.) The subsequent cycles do not change this decision.

If the circuit breaker is not ready, the controller function waits for a pre-programmed time for this state. The waiting time is defined by the user as parameter value (CB Supervision time). If circuit breaker ready signal does not activate during the waiting time, then the automatic reclosing function enters into "Dynamic blocked" state.

Synchro-check conditions

Reclosing is possible only if the conditions required by the "synchro-check" function are fulfilled. This state is signaled by the binary variable (SYNC Release). The automatic reclosing function waits for a pre-programmed time for this signal. This time is defined by the user as parameter value (Sync-check Max.Tim). If the "SYNC Release" signal is not received during the running time of this timer, then the "synchronous switch" operation is started and the signal (CloseRequ.SynSwitch) is generated.

If the conditions of the synchronous state are not fulfilled, another timer starts. The waiting time is defined by the user as parameter value (Sync-switch Max.Tim). This separate function controls the generation of the close command in case of relatively rotating voltage vectors for the circuit breaker to make contact at the synchronous state of the rotating vectors. For this calculation, the closing time of the circuit breaker must be defined. This mode of operation is indicated by the output variable (CloseRequ. SynSwitch).

If no switching is possible during the running time of this timer, then the automatic reclosing function enters "Dynamic blocked" state and resets. When the close command is generated, a timer is started to measure the "Reclaim time". The duration is defined by the parameter value (Reclaim time), but it is prolonged up to the reset of the close command (if the close command duration is longer than the reclaim time set). If the fault is detected again during this time, then the sequence of the automatic reclosing cycles continues. If no fault is detected, then at the expiry of the reclaim time the reclosing is considered successful and the function resets. If fault is detected after the expiry of this timer, then the cycles restart with the first reclosing cycle.

If the user programmed the status variable (Protection Start) and it gets TRUE during the Reclaim time, then the automatic reclosing function continues even if the trip command is received after the expiry of the Reclaim time.

After a manual close command, the automatic reclosing function enters "Not Ready" state for the time period defined by parameter (Block after Man.Close). If the manual close command is received during the running time of any of the cycles, then the automatic reclosing function enters into "Dynamic blocked" state and resets.

If the fault still exists at the end of the last cycle, the automatic reclosing function trips and generates the signal for final trip: (Final Trip). The same final trip signal is generated in case of an evolving fault if "Block Reclosing" is selected. After final trip, the automatic reclosing function enters "Dynamic blocked" state. A final trip command is also generated if, after a multi-phase fault, a fault is detected again during the dead time.

There are several conditions to cause dynamic blocked state of the automatic reclosing function. This state becomes valid if any of the conditions of the dynamic blocking changes to active during the running time of any of the reclosing cycles. At the time of the change a timer is started. Timer duration is defined by the time parameter (Dynamic Blocking time). During this time, no reclosing command is generated.

The conditions to start the dynamic blocked state are:

- There is no trip command during the "Action time".
- The duration of the starting impulse for the MV automatic reclosing function is too long.

- If no “CB ready” signal is received at the intended time of reclosing command.
- The dead time is prolonged further then the preset parameter value (DeadTime Max.Delay).
- The waiting time for the “SYNC Release” signal is too long.
- After the final trip command.
- In case of a manual close command or a manual open command (if the status variable (CB OPEN single-pole) gets TRUE without (AutoReclosing Start)).
- In case of a general block (the device is blocked).

In a dynamic blocked state, the (Blocked) status signal is TRUE (similar to “Not ready” conditions).

There are several conditions that must be satisfied before the automatic reclosing function enters “Not Ready” state. This state becomes valid if any of the conditions of the blocking get TRUE outside the running time of the reclosing cycles.

- Reclosing is disabled by the parameter if it is selected to “Off”.
- The circuit breaker is not ready for operation.
- After a manual close command.
- If the parameter (CB State Monitoring) is set to TRUE and the circuit breaker is in Open state, i.e., the value of the (CB OPEN position) status variable gets TRUE.
- The starting signal for automatic reclosing is selected by parameter (Reclosing started by) to be “CB open” and the circuit breaker is in Open state.
- In case of a general block (the device is blocked).

Setting parameters

Table. 6.4.7 - 94. Setting parameters.

| Parameter | Setting value/ range | Step | Default | Description |
|-------------------------|---|----------|--------------------|---|
| Operation | On Off | - | On | Enabling / Disabling of the autorecloser function. |
| EarthFault RecCycle | Disabled 1. Enabled 1.2. Enabled 1.2.3. Enabled 1.2.3.4. Enabled | - | 1. Enabled | Selection of the number of reclosing sequences for earth faults. |
| PhaseFault RecCycle | Disabled 1. Enabled 1.2. Enabled 1.2.3. Enabled 1.2.3.4. Enabled | - | 1. Enabled | Selection of the number of reclosing sequences for line-to-line faults. |
| Reclosing started by | Trip reset CB Open | - | Trip reset | Selection of triggering the dead time counter (trip signal reset or circuit breaker open position). |
| Evolving fault | Block Reclosing, Start 3Ph Rec. | - | Block Reclosing | Selection of behavior in case of evolving fault (block reclosing or perform three-phase automatic reclosing cycle). |
| CB State monitoring | Enabled Disabled | - | Disabled | Enable CB state monitoring for "Not Ready" state. |
| Reclaim time | 100...100 000 ms | 10 ms | 2 000 ms | Reclaim time setting. |

| Parameter | Setting value/ range | Step | Default | Description |
|-----------------------|-------------------------|-------|-----------|---|
| Close Command time | 10...10 000 ms | 10 ms | 100 ms | Pulse duration setting for the CLOSE command from the IED to circuit breaker. |
| Dynamic Blocking time | 0...100 000 ms | 10 ms | 1 500 ms | Setting of the dynamic blocking time. |
| Block after Man.Close | 0...100 000 ms | 10 ms | 1 000 ms | Setting of the blocking time after manual close command. |
| Action time | 0...20 000 ms | 10 ms | 1 000 ms | Setting of the action time. |
| Start-signal Max.Tim | 0...10 000 ms | 10 ms | 1 000 ms | Time limitation of the starting signal. |
| DeadTime Max.Delay | 0...1 000 000 ms | 10 ms | 3 000 ms | Delaying the start of the dead-time counter. |
| CB Supervision Time | 10...1 000 000 ms | 10 ms | 1 000 ms | Waiting time for circuit breaker ready signal. |
| Sync-check Max.Tim | 500...100 000 ms | 10 ms | 10 000 ms | Waiting time for synchronous state signal. |
| Sync-switch Max.Tim | 500...100 000 ms | 10 ms | 10 000 ms | Waiting time for synchronous switching. |
| 1.Dead Time 3Ph | 0...100 000 ms | 10 ms | 500 ms | Dead time setting for the first reclosing cycle for multi-phase fault. |
| 2.Dead Time 3Ph | 10...100 000 ms | 10 ms | 600 ms | Dead time setting for the second reclosing cycle for multi-phase fault. |
| 3.Dead Time 3Ph | 10...100 000 ms | 10 ms | 700 ms | Dead time setting for the third reclosing cycle for multi-phase fault. |
| 4.Dead Time 3Ph | 10...100 000 ms | 10 ms | 800 ms | Dead time setting for the fourth reclosing cycle for multi-phase fault. |
| 1.Dead Time 1 PH | 0...100 000 ms | 10 ms | 1 000 ms | Dead time setting for the first reclosing cycle for single-phase fault. |
| 2.Dead Time 1 PH | 10...100 000 ms | 10 ms | 2 000 ms | Dead time setting for the second reclosing cycle for single-phase fault. |
| 3.Dead Time 1 PH | 10...100 000 ms | 10 ms | 3 000 ms | Dead time setting for the third reclosing cycle for single-phase fault. |
| 4.Dead Time 1 PH | 10...100 000 ms | 10 ms | 4 000 ms | Dead time setting for the fourth reclosing cycle for single-phase fault. |
| Accelerate 1. Trip | Enabled Disabled | - | Disabled | Acceleration of the 1 st reclosing cycle trip command. |
| Accelerate 2. Trip | Enabled Disabled | - | Disabled | Acceleration of the 2 nd reclosing cycle trip command. |

| Parameter | Setting value/ range | Step | Default | Description |
|--------------------------|-------------------------|------|----------|---|
| Accelerate 3. Trip | Enabled Disabled | - | Disabled | Acceleration of the 3 rd reclosing cycle trip command. |
| Accelerate 4. Trip | Enabled Disabled | - | Disabled | Acceleration of the 4 th reclosing cycle trip command. |
| Accelerate final Trip | Enabled Disabled | - | Disabled | Acceleration of the final trip command. |

6.4.8 Auto-reclosing (HV) (79)

Operation

The HV automatic reclosing function for high voltage networks can realize up to four shots of reclosing. The dead time can be set individually for each reclosing and separately for singlephase faults and for multi-phase faults.

The starting signal of the cycles can be generated by any combination of the protection functions or external signals of the binary inputs. The selection is made by graphic equation programming.

The automatic reclosing function is triggered if as a consequence of a fault a protection function generates a trip command to the circuit breaker and the protection function resets because the fault current drops to zero or the circuit breaker's auxiliary contact signals open state. According to the preset parameter values, either of these two conditions starts counting the dead time, at the end of which the HV automatic reclosing function generates a close command automatically. If the fault still exists or reappears, then within the "Reclaim time" (according to parameter setting REC79_Rec_TPar_), started at the close command, the protection functions picks up again and the subsequent cycle is started. If no pickup is detected within this time, then the HV automatic reclosing cycle resets and a new fault will start the procedure with the first cycle again.

There are some additional requirements to perform automatic reclosing:

- The HV automatic reclosing function can be blocked by the variable REC79_BlK_GrO_, for which the user has to compose a graphic logical equation.
- After a pickup of the protection function, a timer starts to measure the "Action time" (the duration of which depends on parameter setting REC79_Act_TPar_ (Action time)). The trip command must be generated within this time to start reclosing cycles, or else the HV automatic function enters dynamic blocked state.
- At the moment of generating the close command, the circuit breaker must be ready for operation, which is signaled via binary input REC79_CBRdy_GrO_ (CB Ready). The preset parameter value REC79_CBTO_TPar_ (CB Supervision time) decides how long the HV automatic reclosing function is allowed to wait when the function is in "In Progress" state. If the signal is not received during this time, then the HV automatic reclosing function terminates and after a "dynamic blocking time" (depending on the preset parameter value REC79_DynBlk_TPar_ (Dynamic Blocking time)) the function resets.

Depending on the preset parameter value, the HV automatic reclosing function can influence the operation of the protection functions as well. The binary outputs of the HV automatic reclosing function, including the "In progress" (Run) state, can be applied for this purpose in the graphic equation editor.

In case of a manual close command which is assigned to the logic variable REC79_ManCl_GrO_ (Manual Close) using graphic equation programming, a preset parameter value decides how long the HV automatic reclosing function should be disabled after the manual close command.

Cycles

The HV automatic reclosing function can control up to four reclosing cycles. Depending on the preset parameter value REC79_CycEn_EPar_ (Reclosing cycles), there are different modes of operation:

- Disabled = no automatic reclosing is selected
- 1. Enabled = only one automatic reclosing cycle is selected
- 1.2. Enabled = two automatic reclosing cycles are activated
- 1.2.3. = three automatic reclosing cycles are activated
- 1.2.3.4. = all four automatic reclosing cycles are activated.

The function can be switched Off /On using the parameter REC79_Op_EPar_ (Operation).

The user can also block the HV automatic reclosing function applying the graphic equation editor. The binary status variable to be programmed is REC79_BlK_GrO_ (Block).

If the device is generally blocked, then the HV automatic reclosing function is also blocked.

Depending on the present parameter value REC79_St_EPar_ (Reclosing started by), the HV automatic reclosing function can be started either by resetting of the TRIP command (setting: Trip reset) or by the binary signal indicating the open state of the circuit breaker (setting: CB open).

If the reset state of the TRIP command is selected to start the HV automatic reclosing function, then the conditions are defined by the user applying the graphic equation editor. The binary status variable to be programmed is: REC79_Tr_GrO_ (AutoReclosing Start).

If the open state of the circuit breaker is selected to start the HV automatic reclosing function, then additionally to programming the REC79_Tr_GrO_ (AutoReclosing Start) signal, the conditions for detecting the open state of the CB are defined by the user applying the graphic equation editor. The binary status variable to be programmed is: REC79_CBOpen_GrO_ (CB OPEN single-pole). This signal is TRUE if at least one of the poles is open.

The HV automatic reclosing function gets the trip commands of the protection functions intended to trigger the reclosing function. The conditions for detecting the triggered state of the protection functions are defined by the user applying the graphic equation editor. The binary status variable to be programmed is: REC79_Tr_GrO_ (AutoReclosing Start). This signal starts a dedicated timer, the elapsed time of which is compared to the preset parameter value REC79_MaxSt_TPar_ (Start-signal Max.Tim).

The HV automatic reclosing function enters the dynamic blocking state:

- If the parameter selected for REC79_St_EPar_ (Reclosing started by) is "Trip reset", and the trip impulse is too long.
- If the parameter selected for REC79_St_EPar_ (Reclosing started by) is "CB open", then during the runtime of the timer CB open signal is not received.

In the base case, the dead time counter of any reclosing cycle is started by the starting signal but starting can be delayed. The delay is activated if the value of the REC79_DtDel_GrO_ (Dead Time St.Delay) status signal is TRUE. The conditions are defined by the user applying the graphic equation editor. This delay is limited by the timer parameter REC79_DtDel_TPar_ (DeadTime Max.Delay).

For all four reclosing cycles, separate dead times can be defined for single-phase trip commands (as a consequence of single-phase faults) and for three-phase trip commands (as a consequence of multi-phase faults).

The timer parameters for single-phase trip commands are:

- REC79_1PhDT1_TPar_ 1. Dead Time 1Ph
- REC79_1PhDT2_TPar_ 2. Dead Time 1Ph

- REC79_1PhDT3_TPar_ 3. Dead Time 1Ph
- REC79_1PhDT4_TPar_ 4. Dead Time 1Ph

The timer parameters for three-phase trip commands are:

- REC79_3PhDT1_TPar_ 1. Dead Time 3Ph
- REC79_3PhDT2_TPar_ 2. Dead Time 3Ph
- REC79_3PhDT3_TPar_ 3. Dead Time 3Ph
- REC79_3PhDT4_TPar_ 4. Dead Time 3Ph

The different dead time settings can be justified as follows: in case of a single-phase fault, only the circuit breakers of the faulty phase open. In this case, due to the capacitive coupling of the healthy phases, the extinction of the secondary electric arc at the fault location can be delayed. Consequently, a longer dead time is needed for the fault current to die out than in the case of a three-phase open state, when no coupled voltage can sustain the fault current.

From other point of view, in case of a transmission line connecting two power systems, only a shorter dead time is allowed for the three-phase open state because, due to the possible power unbalance between the interconnected systems, a large angle difference can be reached if the dead time is too long. If only a single phase is open, then the two connected healthy phases and the ground can sustain the synchronous operation of both power systems.

Special dead time for the first cycle

This special dead time can be necessary for the following reason:

Assume a line between substations A and B, and a protection system without tele-protection. In the event of a three-phase fault near substation B, the protection at A generates a trip command according to the second zone's time setting only, and starts measuring the dead time with considerable delay as compared to the protection at B, which generates a trip command immediately due to the close-in fault.

If the three-phase dead time is too short, the HV automatic reclosing at B may attempt to close the circuit breaker during the running time of the second zone trip at A, which means that the fault is not cleared yet. Consequently, a prolonged dead time is needed if the fault was detected in the first zone.

The preset timer parameter value is REC79_3PhDT1_TPar_2 (1. special DT 3Ph). The special dead time is valid if the REC79_1cyc3PhFlt_GrO_ (3PhFault for Spec.DT1) status signal is TRUE. The conditions are defined by the user applying the graphic equation editor.

Reduced dead time

Dead time reduction may be applicable under the following circumstances:

If healthy voltage is measured in all three phases during the dead time, this means that no fault exists on the line. In this case, the expiry of the normal dead time need not be waited for, a reclosing attempt can be initiated immediately.

The dead time is terminated immediately if the REC79_RDT_GrO_ (Reduced DeadTime) status signal is TRUE. The conditions are defined by the user applying the graphic equation editor.

Three-phase trip

The HV automatic reclosing function is prepared to get the general trip command as programmed to the binary input status variable REC79_Tr_GrO_ (AutoReclosing Start) and the three-phase trip signal REC79_3PhTr_GrO_ (3Ph Trip). If no three-phase trip signal is received, then it performs automatic reclosing cycles with the dead times according to the setting for single phase cycles. The three-phase cycles are controlled by the status variable REC79_3PhTr_GrO_ (3Ph Trip). If this is TRUE, three-phase cycles are performed. The conditions are defined by the user applying the graphic equation editor.

If, during the cycles, the three-phase dead time is applied once, then all subsequent cycles will consider the three-phase dead time settings, too.

Three-phase reclosing can be disabled by the preset parameter value REC79_3PhRecBlk_BPar_ (Disable 3Ph Rec.). If the value of this parameter is TRUE, then if a three-phase trip command is received, the HV automatic reclosing function enters "Dynamic blocked" state.

Checking the ready state of the circuit breaker

At the end of the dead time, reclosing is possible only if the circuit breaker can perform the command. The binary variable REC79_CBRdy_GrO_ (CB Ready) indicates this state. The conditions are defined by the user applying the graphic equation editor. If the circuit breaker is not ready, the controller functions wait for a pre-programmed time for this state. The waiting time is defined by the user as parameter value REC79_CBTO_TPar_ (CB Supervision time). If this condition is not fulfilled during the waiting time, then the HV automatic reclosing function enters "Dynamic blocked" state.

Reclosing with synchronous state supervision

Reclosing is possible only if the conditions required by the "synchro-check" function are fulfilled. This state is signaled by the binary variable REC79_SynRel_GrO_ (SYNC Release). The conditions are defined by the user applying the graphic equation editor. The HV automatic reclosing function waits for a pre-programmed time for this signal. This time is defined by the user as parameter value REC79_SYN1_TPar_ (SynCheck Max Time). If the "SYNC Release" signal is not received during the running time of this timer, then the "synchronous switch" operation is started and the signal REC79_ClReq_GrI_ (CloseRequ.SynSwitch) is generated.

Reclosing with synchronous switching

If the conditions of the synchronous state are not fulfilled, another timer starts. This waiting time is defined by the user as parameter value REC79_SYN2_TPar_ (SynSW Max Time).

This separate function controls the generation of the close command in case of relatively rotating voltage vectors on both sides of the circuit breaker to make contact at the synchronous state of the rotating vectors. For this calculation, the closing time of the circuit breaker must be defined.

This mode of operation is indicated by the output variable REC79_ClReq_GrI_ (CloseRequ. SynSwitch).

If no switching is possible during the running time of this timer, then the HV automatic reclosing function enters "Dynamic blocked" state and resets.

Impulse duration of the CLOSE command

The "Close" impulse is generated as one of the output status signals of the HV automatic reclosing function REC79_Close_GrI_ (Close command). This signal is common to all three phases. The impulse duration is defined by the user setting the timer parameter REC79_Close_TPar_ (Close command time).

Behavior after reclosing

When the close command is generated, a timer is started to measure the "Reclaim time". The duration is defined by the parameter value REC79_Rec_TPar_ (Reclaim time), but it is prolonged up to the reset of the close command (if the close command duration is longer than the reclaim time set). If the fault is detected again during this time, then the sequence of the HV automatic reclosing cycles continues. If no fault is detected, then at the expiry of the reclaim time the reclosing is evaluated as successful and the function resets. If fault is detected after the expiry of this timer, then the cycles restart with the first reclosing cycle.

If the user programmed the status variable REC79_St_GrO_ (Protection Start) and it gets TRUE during the Reclaim time, then the HV automatic reclosing function continues even if the trip command is received after the expiry of the Reclaim time.

Behavior after manual CLOSE command

This state of manual close command is signaled by the binary variable REC79_ManCl_GrO_ (Manual Close). The conditions are defined by the user applying the graphic equation editor.

After a manual close command, the HV automatic reclosing function enters “Not Ready” state for the time period defined by parameter REC79_MC_TPar_ (Block after Man.Close).

If the manual close command is received during the running time of any of the cycles, then the HV automatic reclosing function enters “Dynamic blocked” state and resets.

Behavior in case of evolving fault

In case of evolving faults (when a single-phase fault detected changes to multi-phase fault), the behavior of the automatic reclosing function is controlled by the preset parameter value REC79_EvoFit_EPar_ (Evolving fault).

The options are:

- “Block Reclosing”
- “Start 3Ph Rec”

If “Block Reclosing” is selected, the HV automatic reclosing function enters dynamic blocked state and the subsequent reclosing command is not generated.

If “Start 3Ph Rec.” is selected, the HV automatic reclosing function goes on performing the subsequent cycle according to the three-phase parameters.

The final trip

If the fault still exists at the end of the last cycle, the HV automatic reclosing function trips and generates the signal for final trip: REC79_FinTr_GrI_ (Final Trip). The same final trip signal is generated in case of an evolving fault if “Block Reclosing” is selected. After final trip, the HV automatic reclosing function enters “Dynamic blocked” state.

A final trip command is also generated if, after a multi-phase fault, a fault is detected again during the dead time.

Action time

The user can compose a binary status variable to indicate the start of the protection functions, the operation of which is related to the HV automatic reclosing function. This status variable is REC79_St_GrO_ (Protection Start). This signal starts the “Action time”, the duration of which is defined by the preset parameter value REC79_Act_TPar_ (Action time). During the running time, the HV automatic reclosing function waits for the trip command. If no trip command is received, then the HV automatic reclosing function enters “Dynamic blocked” state.

Accelerating trip commands

Depending on binary parameter settings, the automatic reclosing function block can accelerate trip commands of the individual reclosing cycles. This means that the output “TrAcc” of the function block gets active for the first starting state of the protection function or at the end of the dead time of the running cycle, if the dedicated parameter enables acceleration. This signal needs user-programmed graphic equations to generate the accelerated trip command.

Dynamic blocking conditions

There are several conditions to result dynamic blocked state of the HV automatic reclosing function. This state becomes valid if any of the conditions of the dynamic blocking get TRUE during the running time of any of the reclosing cycles.

At the time of the change to start the dynamic blocked state a timer is started, the running duration of which is defined by the time parameter REC79_DynBlk_TPar_ (Dynamic Blocking time). During its running time the function is blocked, no reclosing command is generated.

The conditions to start the dynamic blocked state are:

- There is no trip command during the “Action time”.
- The duration of the starting impulse for the HV automatic reclosing function is too long.
- If no “CB ready” signal is received at the intended time of reclosing command.
- The dead time is prolonged further then the preset parameter value REC79_DtDel_TPar_ (DeadTime Max.Delay).
- The waiting time for the “SYNC Release” signal is too long.
- After the final trip command.
- AR is started during the blocking time after a manual close command.
- While CB State Monitoring is on, a manual open command (the status variable REC79_CBOpen_GrO_ (CB OPEN single-pole) gets TRUE without REC79_Tr_GrO_ (AutoReclosing Start)).
- In case of a three-phase trip command if the preset parameter REC79_3PhRecBlk_BPar_ (Disable 3Ph Rec.) is set to TRUE.
- In case of evolving faults, if the parameter setting for REC79_EvoFlt_EPar_ (Evolving fault) is “Block Reclosing”.
- AR is started during a general block.

In a dynamic blocked state, the REC79_Blocked_GrI_ (Blocked) status signal is TRUE (similar to “Not ready” conditions).

"Not ready" conditions

There are several conditions to result “Not Ready” state of the HV automatic reclosing function. This state becomes valid if any of the conditions of the blocking get TRUE outside the running time of the reclosing cycles.

- Reclosing is disabled by the parameter REC79_Op_EPar_ (Operation) if it is selected to “Off”.
- No reclosing cycles are selected by the parameter REC79_CycEn_EPar_ (Reclosing cycles) if it is set to “Disabled”.
- The circuit breaker is not ready for operation: the result of the graphic programming of the binary variable REC79_CBRdy_GrO_ (CB Ready) is FALSE.
- After a manual close command.
- If the parameter REC79_CBState_BPar_ (CB State Monitoring) is set to TRUE and the circuit breaker is in Open state, i.e., the value of the REC79_CBOpen_GrO_ (CB OPEN single-pole) status variable gets TRUE.
- The starting signal for automatic reclosing is selected by parameter REC79_St_EPar_ (Reclosing started by) to be “CB open” and the circuit breaker is in Open state.
- In case of a general block.

In a “Not ready” state, the REC79_Blocked_GrI_ (Blocked) status signal is TRUE (similar to “Dynamic blocking” conditions).

Setting parameters

Table. 6.4.8 - 95. Setting parameters.

| Parameter | Setting value/ range | Step | Default | Description |
|-----------------------------|---|----------|--------------------|---|
| Operation | On Off | - | On | Enabling / Disabling of the autorecloser function. |
| EarthFault RecCycle | Disabled 1. Enabled 1.2. Enabled 1.2.3. Enabled 1.2.3.4. Enabled | - | 1. Enabled | Selection of the number of reclosing sequences for earth faults. |
| PhaseFault RecCycle | Disabled 1. Enabled 1.2. Enabled 1.2.3. Enabled 1.2.3.4. Enabled | - | 1. Enabled | Selection of the number of reclosing sequences for line-to-line faults. |
| Reclosing started by | Trip reset CB Open | - | Trip reset | Selection of triggering the dead time counter (trip signal reset or circuit breaker open position). |
| Evolving fault | Block Reclosing, Start 3Ph Rec. | - | Block Reclosing | Selection of behavior in case of evolving fault (block reclosing or perform three-phase automatic reclosing cycle). |
| CB State monitoring | Enabled Disabled | - | Disabled | Enable CB state monitoring for "Not Ready" state. |
| Reclaim time | 100...100 000 ms | 10 ms | 2 000 ms | Reclaim time setting. |
| Close Command time | 10...10 000 ms | 10 ms | 100 ms | Pulse duration setting for the CLOSE command from the IED to circuit breaker. |
| Dynamic Blocking time | 0...100 000 ms | 10 ms | 1 500 ms | Setting of the dynamic blocking time. |
| Block after Man.Close | 0...100 000 ms | 10 ms | 1 000 ms | Setting of the blocking time after manual close command. |
| Action time | 0...20 000 ms | 10 ms | 1 000 ms | Setting of the action time. |
| Start-signal Max.Tim | 0...10 000 ms | 10 ms | 1 000 ms | Time limitation of the starting signal. |
| DeadTime Max.Delay | 0...1 000 000 ms | 10 ms | 3 000 ms | Delaying the start of the dead-time counter. |
| CB Supervision Time | 10...1 000 000 ms | 10 ms | 1 000 ms | Waiting time for circuit breaker ready signal. |

| Parameter | Setting value/ range | Step | Default | Description |
|--------------------------|-------------------------|----------|--------------|--|
| Sync-check Max.Tim | 500...100 000 ms | 10 ms | 10 000 ms | Waiting time for synchronous state signal. |
| Sync-switch Max.Tim | 500...100 000 ms | 10 ms | 10 000 ms | Waiting time for synchronous switching. |
| 1.Dead Time 3Ph | 0...100 000 ms | 10 ms | 500 ms | Dead time setting for the first reclosing cycle for multi-phase fault. |
| 2.Dead Time 3Ph | 10...100 000 ms | 10 ms | 600 ms | Dead time setting for the second reclosing cycle for multi-phase fault. |
| 3.Dead Time 3Ph | 10...100 000 ms | 10 ms | 700 ms | Dead time setting for the third reclosing cycle for multi-phase fault. |
| 4.Dead Time 3Ph | 10...100 000 ms | 10 ms | 800 ms | Dead time setting for the fourth reclosing cycle for multi-phase fault. |
| 1.Dead Time 1 PH | 0...100 000 ms | 10 ms | 1 000 ms | Dead time setting for the first reclosing cycle for single-phase fault. |
| 2.Dead Time 1 PH | 10...100 000 ms | 10 ms | 2 000 ms | Dead time setting for the second reclosing cycle for single-phase fault. |
| 3.Dead Time 1 PH | 10...100 000 ms | 10 ms | 3 000 ms | Dead time setting for the third reclosing cycle for single-phase fault. |
| 4.Dead Time 1 PH | 10...100 000 ms | 10 ms | 4 000 ms | Dead time setting for the fourth reclosing cycle for single-phase fault. |
| Accelerate 1. Trip | Enabled Disabled | - | Disabled | Acceleration of the 1 st reclosing cycle trip command. |
| Accelerate 2. Trip | Enabled Disabled | - | Disabled | Acceleration of the 2 nd reclosing cycle trip command. |
| Accelerate 3. Trip | Enabled Disabled | - | Disabled | Acceleration of the 3 rd reclosing cycle trip command. |
| Accelerate 4. Trip | Enabled Disabled | - | Disabled | Acceleration of the 4 th reclosing cycle trip command. |
| Accelerate final Trip | Enabled Disabled | - | Disabled | Acceleration of the final trip command. |

6.4.9 Switch-on-to-fault

Some protection functions, e.g. distance protection, directional overcurrent protection, etc. need to decide the direction of the fault. This decision is based on the angle between the voltage and the current. In case of close-in faults, however, the voltage of the faulty loop is near zero: it is not sufficient for a directional decision. If there are no healthy phases, then the voltage samples stored in the memory are applied to decide if the fault is forward or reverse.

If the protected object is energized, the close command for the circuit breaker is received in “dead” condition. This means that the voltage samples stored in the memory have zero values. In this case the decision on the trip command is based on the programming of the protection function for the “switch-onto-fault” condition.


This “switch-onto-fault” (SOTF) detection function prepares the conditions for the subsequent decision. The function can handle both automatic and manual close commands.

The function receives the “Dead line” status signal from the DLD (dead line detection) function block. After dead line detection, the binary output signal AutoSOTF is delayed by a timer with a constant 200 ms time delay. After voltage detection (resetting of the dead line detection input signal), the drop-off of this output signal is delayed by a timer (SOTF Drop Delay) set by the user. The automatic close command is not used it is not an input for this function.

The manual close command is a binary input signal. The drop-off of the binary output signal ManSOTF is delayed by a timer (SOTF Drop Delay) set by the user. The timer parameter is common for both the automatic and manual close command.

The operation of the “switch-onto-fault” detection function is shown in Figure below.

Figure. 6.4.9 - 136. The scheme of the switch-on-to-fault preparation.



The binary input signals of the “switch-onto-fault” detection function are:

- CBClose Manual close command to the circuit breaker.
- DeadLine Dead line condition detected; this is usually the output signal of the DLD (dead line detection) function block.

The binary output signals of the “switch-onto-fault” detection function are:

- AutoSOTF cond Signal enabling switch-onto-fault detection as a consequence of an automatic close command.
- ManSOTF cond Signal enabling switch-onto-fault detection as a consequence of a manual close command.

Figure. 6.4.9 - 137. The function block of the switch-on-to-fault function.




Table. 6.4.9 - 96. The timer parameter of the function.

| Parameter | Title | Unit | Min | Max | Step | Default |
|---|-------|------|-----|-----|------|---------|
| Drop-off time delay for the output signals. | | | | | | |

| Parameter | Title | Unit | Min | Max | Step | Default |
|--------------------|-----------------|------|-----|--------|------|---------|
| SOTF_SOTFDeI_TPar_ | SOTF Drop Delay | ms | 100 | 10 000 | 1 | 1000 |

Table. 6.4.9 - 97. The binary input and output status signals of the function.


| Binary status signal | Signal title | Explanation |
|----------------------|---------------|---|
| SOTF_AutoSOTF_GrI_ | AutoSOTF cond | Signal enabling switch-on-to-fault detection as a consequence of automatic close command. |
| SOTF_Man_SOTF_GrI_ | ManSOTF cond | Signal enabling switch-on-to-fault detection as a consequence of manual close command. |
| SOTF_CBClose_GrO_ | CBClose | Manual close command to the circuit breaker. |
| SOTF_DeadLine_GrO_ | DeadLine | Dead line condition detected. |

6.4.10 Voltage variation (voltage sag and swell)

Short duration voltage variations have an important role in the evaluation of power quality. Short duration voltage variations can be:


- Voltage sag, when the RMS value of the measured voltage is below a level defined by a dedicated parameter and at the same time above a minimum level specified by another parameter setting. For the evaluation, the duration of the voltage sag should be between a minimum and a maximum time value defined by parameters.

Figure. 6.4.10 - 138. Voltage sag.



- Voltage swell, when the RMS value of the measured voltage is above a level defined by a dedicated parameter. For the evaluation, the duration of the voltage swell should be between a minimum and a maximum time value defined by parameters.

Figure. 6.4.10 - 139. Voltage swell.



- Voltage interruption, when the RMS value of the measured voltage is below a minimum level specified by a parameter. For the evaluation, the duration of the voltage interruption should be between a minimum and a maximum time value defined by parameters.

Figure. 6.4.10 - 140. Voltage interruption.



Voltage sag is detected if any of the three phase-to-phase voltages falls to a value between the “Sag limit” setting and the “Interruption Limit” setting. In this state, the binary output “Sag” signal is activated. The signal resets if all of the three phase-to-phase voltages rise above the “Sag limit”, or if the set time “Maximum duration” elapses. If the voltage returns to normal state after the set “Minimum duration” and before the time “Maximum duration” elapses, then the “Sag Counter” increments by 1, indicating a short-time voltage variation.

The report generated includes the duration and the minimum value. A voltage swell is detected if any of the three phase-to-phase voltages increases to a value above the “Swell limit” setting. In this state, the binary output “Swell” signal is activated. The signal resets if all of the three phase-to-phase voltages fall below the “Swell limit”, or if the set time “Maximum duration” elapses. If the voltage returns to normal state after the “Minimum duration” and before the time “Maximum duration” elapses, then the “Swell Counter” increments by 1, indicating a short-time voltage variation.

The report generated includes the duration and the maximum value. A voltage interruption is detected if all three phase-to-phase voltages fall to a value below the “Interruption Limit” setting. In this state, the binary output “Interruption” is activated. The signal resets if any of the three phase-to-phase voltages rises above the “Interruption limit”, or if the time “Maximum duration” elapses. No counter is assigned to this state.

The inputs of the sag and swell detection function are:

- RMS values of the of three phase-to-phase voltages
- Binary input
- Setting parameters.

The outputs of the sag and swell detection function are:

- Sag detection
- Swell detection
- Interruption detection
- Counters.

**NOTICE!**

if all three phase-to-phase voltages do not fall below the specified “Interruption Limit” value, then the event is classified as “sag” but the reported minimum value is set to zero. The sag and swell detection algorithm measures the duration of the short-time voltage variation. The last variation is displayed.

The sag and swell detection algorithm offers measured values, status signals and counter values for displaying:

- The duration of the latest detected short-time voltage variation
- Binary signals:
 - Swell
 - Sag
 - Interruption
- Timer values:
 - Sag counter
 - Swell counter

Figure. 6.4.10 - 141. Sag and swell monitoring window in the AQtivate 300 setting tool.

| | | |
|--------------------------------|--------------------------|---------------|
| [-] Voltage variation | | |
| Duration | 0 | |
| Swell | <input type="checkbox"/> | |
| Sag | <input type="checkbox"/> | |
| Interruption | <input type="checkbox"/> | |
| Sag Counter | 1 | Counter reset |
| Swell Counter | 2 | Counter reset |

The sag and swell detection algorithm offers event recording, which can be displayed in the “Event list” window of the user interface software.

Figure. 6.4.10 - 142. Example sag and swell.

```

2010-12-20 13:19:45.667 : Voltage variation : Swell Counter : 0
2010-12-20 13:19:49.784 : Voltage variation : Sag Counter : 0
2010-12-20 13:20:10.160 : Voltage variation : Sag : On
2010-12-20 13:20:13.168 : Voltage variation : Sag : Off
2010-12-20 13:20:13.168 : Voltage variation : Sag Counter : 1
2010-12-20 13:20:13.168 : Voltage variation : Last Duration : 3007
2010-12-20 13:20:13.168 : Voltage variation : Last value 1 : 86 %
2010-12-20 13:20:13.168 : Voltage variation : Last value 2 : 86 %
2010-12-20 13:20:13.168 : Voltage variation : Last value 3 : 86 %
2010-12-20 13:20:50.019 : Voltage variation : Swell : On
2010-12-20 13:20:53.028 : Voltage variation : Swell : Off
2010-12-20 13:20:53.028 : Voltage variation : Swell Counter : 1
2010-12-20 13:20:53.028 : Voltage variation : Last Duration : 3009
2010-12-20 13:20:53.028 : Voltage variation : Last value 1 : 112 %
2010-12-20 13:20:53.028 : Voltage variation : Last value 2 : 112 %
2010-12-20 13:20:53.028 : Voltage variation : Last value 3 : 112 %

```

6.4.11 Disturbance recorder

The disturbance recorder function can record analog signals and binary status signals. These signals are user configurable. The disturbance recorder function has a binary input signal, which serves the purpose of starting the function. The conditions of starting are defined by the user. The disturbance recorder function keeps on recording during the active state of this signal but the total recording time is limited by the timer parameter setting. The pre-fault time, max-fault time and post-fault time can be defined by parameters.

If the conditions defined by the user - using the graphic equation editor – are satisfied, then the disturbance recorder starts recording the sampled values of configured analog signals and binary signals. The analog signals can be sampled values (voltages and currents) received via input modules or they can be calculated analog values (such as negative sequence components, etc.) The number of the configured binary signals for recording is limited to 64. During the operation of the function, the pre-fault signals are preserved for the time duration as defined by the parameter “PreFault”. The fault duration is limited by the parameter “MaxFault” but if the triggering signal resets earlier, this section is shorter. The post-fault signals are preserved for the time duration as defined by the parameter “PostFault”. During or after the running of the recording, the triggering condition must be reset for a new recording procedure to start.


The records are stored in standard COMTRADE format:

- The configuration is defined by the file .cfg
- The data are stored in the file .dat
- Plain text comments can be written in the file .inf.

The procedure for downloading the records includes a downloading of a single compressed. zip-file. Downloading can be initiated from a web browser tool or from the software tools. This procedure assures that the three component files (.cfg, .dat and .inf) are stored in the same location. The evaluation can be performed using any COMTRADE evaluator software, e.g. Arcteq’s AQview software. Consult your nearest Arcteq representative for availability.

The function block of the disturbance recorder function is shown in figure bellow. This block shows all binary input and output status signals that are applicable in the AQtivate 300 software.

Figure. 6.4.11 - 143. The function block of the disturbance recorder function.



The binary input and output status signals of the dead line detection function are listed in tables below.

Table. 6.4.11 - 98. The binary input signal of the function.

| Binary status signal | Explanation |
|----------------------|---|
| DRE_Start_GrO_ | Output status of a graphic equation defined by the user to start the disturbance recorder function. |

Table. 6.4.11 - 99. Setting parameters.

| Parameter | Setting value/range | Step | Default | Description |
|-----------|---------------------|------|---------|--|
| Operation | On Off | - | On | Function enabling / disabling. |
| PreFault | 100...500 ms | 1 ms | 200 ms | Pre triggering time included in the recording. |
| PostFault | 100...1 000 ms | 1 ms | 200 ms | Post fault time included in the recording. |

| Parameter | Setting value/range | Step | Default | Description |
|-----------|---------------------|------|----------|--|
| MaxFault | 500...10 000 ms | 1 ms | 1 000 ms | Overall maximum time limit in the recording. |

6.4.12 Event recorder

The events of the device and those of the protection functions are recorded with a time stamp of 1 ms time resolution. This information with indication of the generating function can be checked on the touch-screen of the device in the “Events” page, or using an Internet browser of a connected computer.

Table. 6.4.12 - 100. List of events.

| Event | Explanation |
|---|--|
| Voltage transformer supervision function (VTS) | |
| VT Failure | Error signal of the voltage transformer supervision function |
| Common | |
| Mode of device | Mode of device |
| Health of device | Health of device |
| Three-phase instantaneous overcurrent protection function (IOC50) | |
| Trip L1 | Trip command in phase L1 |
| Trip L2 | Trip command in phase L2 |
| Trip L3 | Trip command in phase L3 |
| General Trip | General trip command |
| Residual instantaneous overcurrent protection function (IOC50N) | |
| General Trip | General trip command |
| Directional overcurrent protection function (TOC67) low setting stage | |
| Start L1 | Start signal in phase L1 |
| Start L2 | Start signal in phase L2 |
| Start L3 | Start signal in phase L3 |
| Start | Start signal |
| Trip | Trip command |
| Directional overcurrent protection function (TOC67) high setting stage | |
| Start L1 | Start signal in phase L1 |
| Start L2 | Start signal in phase L2 |
| Start L3 | Start signal in phase L3 |
| Start | Start signal |

| | |
|--|---|
| Trip | Trip command |
| Residual directional overcurrent protection function (TOC67N) low setting stage | |
| Start | Start signal |
| Trip | Trip command |
| Residual directional overcurrent protection function (TOC67N) high setting stage | |
| Start | Start signal |
| Trip | Trip command |
| Line thermal protection function (TTR49L) | |
| Alarm | Line thermal protection alarm signal |
| General Trip | Line thermal protection trip command |
| Current unbalance protection function | |
| General Start | General Start |
| General Trip | General Trip |
| Current unbalance protection function | |
| 2.Harm Restraint | Second harmonic restraint |
| Definite time overvoltage protection function (TOV59) | |
| Low Start L1 | Low setting stage start signal in phase L1 |
| Low Start L2 | Low setting stage start signal in phase L2 |
| Low Start L3 | Low setting stage start signal in phase L3 |
| Low General Start | Low setting stage general start signal |
| Low General Trip | Low setting stage general trip command |
| High Start L1 | High setting stage start signal in phase L1 |
| High Start L2 | High setting stage start signal in phase L2 |
| High Start L3 | High setting stage start signal in phase L3 |
| High General Start | High setting stage general start signal |
| High General Trip | High setting stage general trip command |
| Definite time undervoltage protection function (TUV27) | |
| Low Start L1 | Low setting stage start signal in phase L1 |
| Low Start L2 | Low setting stage start signal in phase L2 |
| Low Start L3 | Low setting stage start signal in phase L3 |
| Low General Start | Low setting stage general start signal |
| Low General Trip | Low setting stage general trip command |

| | |
|--|---|
| High Start L1 | High setting stage start signal in phase L1 |
| High Start L2 | High setting stage start signal in phase L2 |
| High Start L3 | High setting stage start signal in phase L3 |
| High General Start | High setting stage general start signal |
| High General Trip | High setting stage general trip command |
| Overfrequency protection function (TOF81) | |
| Low General Start | Low setting stage general start signal |
| Low General Trip | Low setting stage general trip command |
| High General Start | High setting stage general start signal |
| High General Trip | High setting stage general trip command |
| Underfrequency protection function (TUF81) | |
| Low General Start | Low setting stage general start signal |
| Low General Trip | Low setting stage general trip command |
| High General Start | High setting stage general start signal |
| High General Trip | High setting stage general trip command |
| Rate-of-change of frequency protection function (FRC81) | |
| Low General Start | Low setting stage general start signal |
| Low General Trip | Low setting stage general trip command |
| High General Start | High setting stage general start signal |
| High General Trip | High setting stage general trip command |
| Breaker failure protection function (BRF50) | |
| Backup Trip | Repeated trip command |
| Trip logic function (TRC94) | |
| General Trip | General Trip |
| Synchrocheck function (SYN25) | |
| Released Auto | The function releases automatic close command |
| In progress Auto | The automatic close command is in progress |
| Close_Auto | Close command in automatic mode of operation |
| Released Man | The function releases manual close command |
| In progress Man | The manual close command is in progress |
| Close_Man | Close command in manual mode of operation |
| Automatic reclosing function (REC79) | |

| | |
|-----------------------------------|--|
| Blocked | Blocked state of the automatic reclosing function |
| Close Command | Close command of the automatic reclosing function |
| Status | State of the automatic reclosing function |
| Actual cycle | Running cycle of the automatic reclosing function |
| Final Trip | Definite trip command at the end of the automatic reclosing cycles |
| Measurement function (MXU) | |
| Current L1 | Current violation in phase L1 |
| Current L2 | Current violation in phase L2 |
| Current L3 | Current violation in phase L3 |
| Voltage L12 | Voltage violation in phase L12 |
| Voltage L23 | Voltage violation in phase L23 |
| Voltage L31 | Voltage violation in phase L31 |
| Active Power – P | Active Power – P violation |
| Reactive Power – Q | Reactive Power – Q violation |
| Apparent Power – S | Apparent Power – S violation |
| Frequency | Frequency violation |
| CB1Pol | |
| Status value | Status of the circuit breaker |
| Enable Close | Close command is enabled |
| Enable Open | Open command is enabled |
| Local | Local mode of operation |
| Operation counter | Operation counter |
| CB OPCap | |
| Disconnecter Line | |
| Status value | Status of the circuit breaker |
| Enable Close | Close command is enabled |
| Enable Open | Open command is enabled |
| Local | Local mode of operation |
| Operation counter | Operation counter |
| DC OPCap | |
| Disconnecter Earth | |
| Status value | Status of the earthing switch |

| | |
|-------------------------|--------------------------------|
| Enable Close | Close command is enabled |
| Enable Open | Open command is enabled |
| Local | Local mode of operation |
| Operation counter | Operation counter |
| DC OPCap | |
| Disconnecter Bus | |
| Status value | Status of the bus disconnecter |
| Enable Close | Close command is enabled |
| Enable Open | Open command is enabled |
| Local | Local mode of operation |
| Operation counter | Operation counter |
| DC OPCap | |

6.4.13 Measured values

The measured values can be checked on the touch-screen of the device in the “On-line functions” page, or using an Internet browser of a connected computer. The displayed values are secondary voltages and currents, except the block “Line measurement”. This specific block displays the measured values in primary units, using the VT and CT primary value settings.

Table. 6.4.13 - 101. Analogue value measurements.

| Analog value | Explanation |
|-------------------|--|
| VT4 module | |
| Voltage Ch – U1 | RMS value of the Fourier fundamental harmonic voltage component in phase L1 |
| Angle Ch – U1 | Phase angle of the Fourier fundamental harmonic voltage component in phase L1* |
| Voltage Ch – U2 | RMS value of the Fourier fundamental harmonic voltage component in phase L2 |
| Angle Ch – U2 | Phase angle of the Fourier fundamental harmonic voltage component in phase L2* |
| Voltage Ch – U3 | RMS value of the Fourier fundamental harmonic voltage component in phase L3 |
| Angle Ch – U3 | Phase angle of the Fourier fundamental harmonic voltage component in phase L3* |
| Voltage Ch – U4 | RMS value of the Fourier fundamental harmonic voltage component in Channel U4 |
| Angle Ch – U4 | Phase angle of the Fourier fundamental harmonic voltage component in Channel U4* |
| CT4 module | |
| Current Ch – I1 | RMS value of the Fourier fundamental harmonic current component in phase L1 |
| Angle Ch – I1 | Phase angle of the Fourier fundamental harmonic current component in phase L1* |
| Current Ch – I2 | RMS value of the Fourier fundamental harmonic current component in phase L2 |

| Analog value | Explanation |
|--|--|
| Angle Ch – I2 | Phase angle of the Fourier fundamental harmonic current component in phase L2* |
| Current Ch – I3 | RMS value of the Fourier fundamental harmonic current component in phase L3 |
| Angle Ch – I3 | Phase angle of the Fourier fundamental harmonic current component in phase L3* |
| Current Ch – I4 | RMS value of the Fourier fundamental harmonic current component in Channel I4 |
| Angle Ch – I4 | Phase angle of the Fourier fundamental harmonic current component in Channel I4* |
| Values for the directional measurement | |
| L12 loop R | Resistance of loop L1L2 |
| L12 loop X | Reactance of loop L1L2 |
| L23 loop R | Resistance of loop L2L3 |
| L23 loop X | Reactance of loop L2L3 |
| L31 loop R | Resistance of loop L3L1 |
| L31 loop X | Reactance of loop L3L1 |
| Line thermal protection | |
| Calc. Temperature | Calculated line temperature |
| Synchrocheck | |
| Voltage Diff | Voltage magnitude difference |
| Frequency Diff | Frequency difference |
| Angle Diff | Angle difference |
| Line measurement (here the displayed information means primary value) | |
| Active Power – P | Three-phase active power |
| Reactive Power – Q | Three-phase reactive power |
| Apparent Power – S | Three-phase power based on true RMS voltage and current measurement |
| Current L1 | True RMS value of the current in phase L1 |
| Current L2 | True RMS value of the current in phase L2 |
| Current L3 | True RMS value of the current in phase L3 |
| Voltage L1 | True RMS value of the voltage in phase L1 |
| Voltage L2 | True RMS value of the voltage in phase L2 |
| Voltage L3 | True RMS value of the voltage in phase L3 |
| Voltage L12 | True RMS value of the voltage in phase L1L2 |
| Voltage L23 | True RMS value of the voltage in phase L2L3 |
| Voltage L31 | True RMS value of the voltage in phase L3L1 |

| Analog value | Explanation |
|--------------|-------------|
| Frequency | Frequency |

6.4.14 Status monitoring for switching devices

The status of circuit breakers and the disconnectors (line disconnector, bus disconnector, earthing switch) are monitored continuously. This function also enables operation of these devices using the screen of the local LCD. To do this the user can define the user screen and the active scheme.

6.4.15 Trip circuit supervision

All four fast acting trip contacts contain build-in trip circuit supervision function. The output voltage of the circuit is 5V (+/-1V). The pickup resistance is 2.5kohm (+/-1kohm).



CAUTION!

Pay attention to the polarity of the auxiliary voltage supply as outputs are polarity dependent.

7 Line differential communication applications


This chapter is intended to explain different line differential protection communication methods with AQ 300 devices.

7.1 Peer-to-peer communication

Direct link


If dark fiber is available between two substations the peer-to-peer communication mode is recommended. For short-haul applications that are limited to 2 km the multi-mode fiber can be used. Long-haul applications up to 35 dB line attenuation, that is 100...120 km in practice, the single mode 1550 nm fiber can be used.

Figure. 7.1 - 144. Direct link communication scheme.



Via LAN/Telecom network

Figure. 7.1 - 145. LAN/Telecom network communication scheme.



7.2 Pilot wire application

Pilot wire application allows protection devices to communicate with each other via traditional copper wire. The xDSL technology supports high speed and reliable communication channel establishment via 2-8 wire copper lines. The AQ 300 is connected to an industrial grade Ethernet/SHDSL MODEM via an Ethernet 100Base-Fx interface.

Figure. 7.2 - 146. Pilot wire communication scheme.




Table. 7.2 - 102. SHDSL interface specification.

| | |
|------------------------|--|
| Specification | ITU-T G.991.2-G.shdsl, ITU-T G.991.2-G.shdsl.bis |
| Line Code | TC-PAM16/32, Extended: TC-PAM4/8/64/128 |
| Impedance | 135 Ω |
| Transmit Power | 13.5 (Annex A) or 14.5 (Annex B) dBm @ 135 Ω |
| Number of Pairs | 1.2 or 4 |
| Bit Rate | 192 to 5704 kbit/s, Extended: 128 to 15,232 kbit/s |
| Distance | Max. 8 km @ 0.8 mm (AWG 20) wire Max. 6 km @ 0.6 mm (AWG 23) wire Max. 4 km @ 0.4 mm (AWG 26) wire |
| Connector Type | RJ-45, 8 pin |
| Overvoltage Protection | ITU-T Rec. K.20/K.21 |
| Wetting Current | 2...4 mA @ 47 V DC |

Table. 7.2 - 103. Ethernet interface specification.

| | |
|---|---|
| Standard | IEEE 802.3, VLAN IEEE 802.1Q, QoS IEEE 802.1P |
| Data Rate | 100Base-TX, Full/Half Duplex |
| Interface/connector Type @ Europrot+ side | Multi-mode 1310 nm, ST connector |


| | |
|---------------------------------------|--------------------------------------|
| Interface/connector Type @ MODEM side | SFP multi-mode 1310 nm, LC connector |
|---------------------------------------|--------------------------------------|

7.3 Line differential communication via telecom networks

Communication via G.703 64 kbit/s co-directional interface (E0)

The AQ 300 device also supports line differential communication via telecom networks using G.703.1 64kbit/s co-directional interface type. This type of communication is performed via 2*2 wire isolated galvanic type interface. The protection device is connected to a multiplexer or gateway which is responsible for protocol/speed conversion.

Figure. 7.3 - 147. G.703 co-directional communication scheme.




Connector type: Weidmüller
Impedance: 120 Ω
Cable length: 50 m
Interface type: G.703.1 64 kbit/s (E0) co-directional, selectable grounding

Communication via C37.94 N×64 kbit/s interface

The IEEE C37.94 standard describes the N time 64 kbit/s optical fiber interface between teleprotection and multiplexer equipment. The data rate can be 1...12×64 kbit/s with 64 kbit/s steps.

Figure. 7.3 - 148. IEEE C37.94 communication scheme.




Connector type: ST
Wavelength: 850 nm
Optical output power: -15 dBm
Optical input sensitivity: -34 dBm
Data rate: 64...768 kbit/s

Communication via 2.048 Mbit/s (E1/T1) N×64 kbit/s interface

AQ 300 device supports line differential communication via telecom networks with G.703/704 2.048 Mbit/s interface (E1). Besides E1 in European networks, the T1 interface (1.54 Mbit/s) in America is also available.

Figure. 7.3 - 149. G.703/704 communication scheme.



Connector type: Weidmüller
Impedance: 75/120 Ω
Cable length: 50 m
Interface type: G.703 1.544 Mbit/s (T1) or 2.048 Mbit/s (E1), selectable grounding


7.4 Redundant line differential communication

The data interchange over the two communication channels is carried out in parallel way which enables hot standby operation. In case of single point of failure in one of the links the algorithm processes the data from the other link without switchover time.

G.703 and 100Base-FX redundancy

Redundant communication also supported by AQ 300 devices. The high speed 100Base-FX link is used as main channel and G.703.1 leased or dedicated line as backup link. An extra communication card needs to be added to the AQ 300 IED for this kind of redundancy, consult your nearest Arcteq representative for availability.


Figure. 7.4 - 150. G.703 and 100Base redundant communication scheme.



100Base-FX redundancy

Both communication links are Ethernet 100Base-FX type and the connection type can be direct link (dark fiber) and/or a service from a telecom operator. An extra communication card needs to be added to the configuration for this kind of redundancy, consult your nearest Arcteq representative for availability.


Figure. 7.4 - 151. 100Base redundant communication scheme.



7.5 Three terminal line differential communication

With an additional communication card added to AQ 300 device a three terminal line differential communication between IEDs can be implemented. Communication channel in this case is Ethernet 100Base-Fx. The three terminal line differential protection scheme can tolerate the link failure of one of the three communication channels between the devices.

Figure. 7.5 - 152. Three terminal line differential communication scheme.



8 System integration

The AQ L3x9 contains two ports for communicating to upper level supervisory system and one for process bus communication. The physical media or the ports can be either serial fiber optic or RJ 45 or Ethernet fiber optic. Communication ports are always in the CPU module of the device.

The AQ L3x9 line protection IED communicates using IEC 61850, IEC 101, IEC 103, IEC 104, Modbus RTU, DNP3.0 and SPA protocols. For details of each protocol refer to respective interoperability lists.

For IRIG-B time synchronization binary input module O12 channel 1 can be used.

9 Connections

9.1 Block diagrams




NOTICE!

The structure of both AQ-L359 (the half-rack version) and AQ-L399 (the full rack version) is the same, except AQ-L399 has more option card slots available.


Block diagram of AQ-L359 with minimum options

Figure. 9.1 - 153. Block diagram of AQ-L359 with minimum options installed.



Block diagram of AQ-L359 with all options

Figure. 9.1 - 154. Block diagram of AQ-L359 with all options installed.




9.2 Connection example



NOTICE!

While the connection example below is for AQ-L359, AQ-L399 is connected in the same way.

Figure. 9.2 - 155. Connection example of AQ-L359 line protection IED.



10 Construction and installation

10.1 Construction

The Arcteq AQ-L3x9 line protection IED consists of hardware modules. Due to its modular structure the optional positions for the slots can be user defined in the ordering of the IED to include I/O modules and other types of additional modules. An example module arrangement configuration of AQ-L359 and AQ-L399 are shown in the figures below. Visit <https://configurator.arcteq.fi/> to see all of the available options.

Figure. 10.1 - 156. An example module arrangement configuration for the AQ-L359 IED.




Table. 10.1 - 104. Descriptions of the hardware modules for AQ-L359.

| Position | Module identifier | Explanation |
|----------|-------------------|--|
| A–B | PS+ 1030 | Power supply unit, 85...265 V AC, 88...300 V DC |
| C | CT+ 5151 | Analog current input module |
| D | VT+ 2211 | Analog voltage input module |
| E | TRIP+ 1101 | Trip relay output module, 4 tripping contacts |
| F | O12+ 2101 | Binary input module, 12 inputs, threshold 110 V DC |
| G | R8+ 80 | Signaling output module, 8 output contacts (7 NO + 1 NC) |

| Position | Module identifier | Explanation |
|----------|-------------------|------------------------------------|
| J | CPU+ 1201 | Processor and communication module |
| H, I | Spare | — |

Figure. 10.1 - 157. An example module arrangement configuration for the AQ-L399 IED.




Table. 10.1 - 105. Descriptions of the hardware modules for AQ-L399.

| Position | Module identifier | Explanation |
|----------|-------------------|--|
| A–B | PS+ 1301 | Power supply unit, 85...265 V AC, 88...300 V DC |
| D | CT+ 5151 | Analog current input module |
| F | VT+ 2211 | Analog voltage input module |
| H | TRIP+ 2101 | Trip relay output module, 4 tripping contacts |
| K | O12+ 1101 | Binary input module, 12 inputs, threshold 110 V DC |
| O | R8+ 00 | Signaling output module, 8 output contacts (7 NO + 1 NC) |
| V | CPU+ 1201 | Processor and communication module |
| Others | Spare | Empty slots which can be used for additional DI or DO slots. |

10.2 CPU module

The CPU module contains all the protection, control and communication functions of the AQ-x3xx device. Dual 500 MHz high-performance Analog Devices Blackfin processors separates relay functions (RDSP) from communication and HMI functions (CDSP). Reliable communication between processors is performed via high-speed synchronous serial internal bus (SPORT).

Each processor has its own operative memory such as SDRAM and flash memories for configuration, parameter and firmware storage. CDSP's operating system (uClinux) utilizes a robust JFFS flash file system, which enables fail-safe operation and the storage of disturbance record files, configuration and parameters.

After power-up the RDSP processor starts up with the previously saved configuration and parameters. Generally, the power-up procedure for the RDSP and relay functions takes approx. 1 sec. That is to say, it is ready to trip within this time. CDSP's start-up procedure is longer, because its operating system needs time to build its file system, initializing user applications such as HMI functions and the IEC 61850 software stack.

The built-in 5- port Ethernet switch allows the AQ-x3xx device to connect to IP/Ethernet- based networks. The following Ethernet ports are available:


- Station bus (100Base-FX Ethernet).
- Redundant Station bus (100Base-FX Ethernet).
- Process bus (100Base-FX Ethernet).
- EOB (Ethernet over Board) user interface.
- Optional 100Base-TX port via RJ-45 connector.

Other communication:

- R422/RS485/RS232 interfaces.
- Plastic or glass fiber interfaces to support legacy protocols.
- Process-bus communication controller on COM+ card.

10.3 Power supply module

Figure. 10.3 - 158. Connector allocation of the 30 W power supply unit.




The power supply module converts primary AC and/or DC voltage to required system voltages. Redundant power supply cards extend system availability in case of the outage of any power source and can be ordered separately if required.

Main features of the power supply module:

- 30 W input.
- Maximum 100 ms power interruption time: measured at nominal input voltage with nominal power consumption.
- IED system fault contacts (NC and NO): device fault contact and also assignable to user functions. All the three relay contact points (NO, NC, COM) are accessible to users 80...300 V DC input range, AC power is also supported.
- Redundant applications which require two independent power supply modules can be ordered optionally.
- On-board self-supervisory circuits: temperature and voltage monitors.
- Short-circuit-protected outputs.
- Efficiency: >70 %.
- Passive heat sink cooling.
- Early power failure indication signals to the CPU the possibility of power outage, thus the CPU has enough time to save the necessary data to non-volatile memory.

10.4 Binary input module(s)

Figure. 10.4 - 159. The binary input module O12+ 1101.



The inputs are galvanic isolated and the module converts high-voltage signals to the voltage level and format of the internal circuits. This module is also used as an external IRIG-B synchronization input. Dedicated synchronization input (input channel 1) is used for this purpose.

The binary input modules are:

- Rated input voltage: 110/220 V DC.
- Clamp voltage: falling 0.75 U_n , rising 0.78 U_n .
- Digitally filtered per channel.
- Current drain approx.: 2 mA per channel.
- 12 inputs.
- IRIG-B timing and synchronization input.

10.5 Binary output module(s)

Figure. 10.5 - 160. The binary output module R8+ 80.



The signaling output modules can be ordered as 8 relay outputs with dry contacts.

The binary output modules are:

- Rated voltage: 250 V AC/DC.
- Continuous carry: 8 A.
- Breaking capacity, (L/R = 40 ms) at 220 V DC: 0.2 A
- 8 contacts: 7 NO and 1 NC

10.6 Tripping module

Figure. 10.6 - 161. The tripping module TRIP+ 2101.




The tripping module applies direct control of a circuit breaker. The module provides fast operation and is rated for heavy duty controlling.

The main characteristics of the trip module:

- 4 independent tripping circuits.
- High-speed operation.
- Rated voltage: 110 V, 220 V DC.
- Continuous carry: 8 A.
- Making capacity: 0.5 s, 30 A.
- Breaking capacity (L/R = 40 ms) at 220 V DC: 4A.
- Trip circuit supervision for each trip contact.

10.7 Voltage measurement module

Figure. 10.7 - 162. The voltage measurement module VT+ 2211.



For voltage related functions (over- /under -voltage, directional functions, distance function, power functions) or disturbance recorder functionality this module is needed. This module also has capability for frequency measurement.


For capacitive voltage measurement of the synchrocheck reference, the voltage measurement module can be ordered with reduced burden in channel VT4. In this module the burden is < 50 mVA.

The main characteristics of the voltage measurement module:

- Number of channels: 4.
- Rated frequency: 50 Hz, 60 Hz.
- Selectable rated voltage (U_n): 100/ $\sqrt{3}$, 100 V, 200/ $\sqrt{3}$, 200 V by parameter.
- Voltage measuring range: 0.05 U_n – 1.2 U_n .
- Continuous voltage withstand: 250 V.
- Power consumption of voltage input: ≤ 1 VA at 200 V (with special CVT module the burden is < 50 mVA for VT4 channel).
- Relative accuracy: ± 0.5 %.
- Frequency measurement range: ± 0.01 % at U_x 25 % of rated voltage.
- Measurement of phase angle: 0.5° U_x 25 % of rated voltage.

10.8 Current measurement module

Figure. 10.8 - 163. Connector allocation of the current measurement module.



Current measurement module is used for measuring current transformer output current. Module includes three phase current inputs and one zero sequence current input. The nominal rated current of the input can be selected with a software parameter either 1 A or 5 A.

The main characteristics of the current measurement module:

- Number of channels: 4.
- Rated frequency: 50 Hz, 60 Hz.
- Electronic iron-core flux compensation.
- Low consumption: ≤ 0.1 VA at rated current.
- Current measuring range: $35 \times I_n$.
- Selectable rated current 1 A/5 A by parameter.
- Thermal withstand:
 - 20 A (continuously)
 - 500 A (for 1 s)
 - 1200 A (for 10 ms)
- Relative accuracy: ± 0.5 %.
- Measurement of phase angle: 0.5° , $I \times 10$ % rated current.

10.9 Installation and dimensions

Figure. 10.9 - 164. Dimensions of AQ-x35x IED.




Figure. 10.9 - 165. Panel cut-out and spacing of AQ-x35x IED.




Figure. 10.9 - 166. Dimensions of AQ-x39x IED.





Figure. 10.9 - 167. Panel cut-out and spacing of AQ-x39x IED.

PANEL CUT-OUT



11 Technical data

11.1 Protection functions

Breaker failure protection function CBFP, (50BF)

| | |
|---------------------------|--------------|
| Current inaccuracy | <2 % |
| Re-trip time | Approx. 15ms |
| Operation time inaccuracy | ± 5 ms |
| Current reset time | 20ms |

Current unbalance protection function (60)

| | |
|--------------------------------------|-------|
| Pick-up starting inaccuracy at I_n | < 2 % |
| Reset ratio | 0,95 |
| Operate time | 70 ms |

Three-phase instantaneous overcurrent protection $I>$ (50)

| | |
|--|------------------|
| Operating characteristic | Instantaneous |
| Pick-up current inaccuracy | <2% |
| Reset ratio | 0.95 |
| Operate time at $2 \cdot I_n$ Peak value calculation Fourier calculation | <15 ms <25 ms |
| Reset time | 16 – 25 ms |
| Transient overreach Peak value calculation Fourier calculation | 80 % 2 % |

Three-phase time overcurrent protection $I>$ (50/51)

| | |
|----------------------------------|--------------------------|
| Pick-up current inaccuracy | < 2% |
| Operation time inaccuracy | $\pm 5\%$ or ± 15 ms |
| Reset ratio | 0.95 |
| Minimum operating time with IDMT | 35ms |
| Reset time | Approx 35ms |
| Transient overreach | 2 % |

| | |
|-------------|-----------|
| Pickup time | 25 – 30ms |
|-------------|-----------|

Residual instantaneous overcurrent protection I0> (50N)

| | |
|---|------------------|
| Operating characteristic | Instantaneous |
| Pick-up current inaccuracy | <2% |
| Reset ratio | 0.95 |
| Operate time at 2*I _n Peak value calculation Fourier calculation | <15 ms <25 ms |
| Reset time | 16 – 25 ms |
| Transient overreach Peak value calculation Fourier calculation | 80 % 2 % |

Residual time overcurrent protection I0> (51N)

| | |
|----------------------------------|--------------|
| Pick-up current inaccuracy | < 2% |
| Operation time inaccuracy | ±5% or ±15ms |
| Reset ratio | 0.95 |
| Minimum operating time with IDMT | 35ms |
| Reset time | Approx 35ms |
| Transient overreach | 2 % |
| Pickup time | 25 – 30ms |

Three-phase directional overcurrent protection function I0Dir> (67)

| | |
|----------------------------------|--------------|
| Pick-up current inaccuracy | < 2% |
| Operation time inaccuracy | ±5% or ±15ms |
| Reset ratio | 0.95 |
| Minimum operating time with IDMT | 35ms |
| Reset time | Approx 35ms |
| Transient overreach | 2 % |
| Pickup time | 25 – 30ms |
| Angular inaccuracy | <3° |

Residual directional overcurrent protection function I0Dir> (67N)

| | |
|----------------------------|------|
| Pick-up current inaccuracy | < 2% |
|----------------------------|------|

| | |
|----------------------------------|--------------------------------|
| Operation time inaccuracy | $\pm 5\%$ or $\pm 15\text{ms}$ |
| Reset ratio | 0.95 |
| Minimum operating time with IDMT | 35ms |
| Reset time | Approx 35ms |
| Transient overreach | 2 % |
| Pickup time | 25 – 30ms |
| Angular inaccuracy | $< 3^\circ$ |

Overvoltage protection function U> (59)

| | |
|---|---------------------|
| Pick-up starting inaccuracy | $< 0,5 \%$ |
| Reset time U> \rightarrow Un U> \rightarrow 0 | 50 ms 40 ms |
| Operation time inaccuracy | $\pm 15 \text{ ms}$ |

Undervoltage protection function U< (27)

| | |
|--|----------------|
| Pick-up starting inaccuracy | $< 0.5 \%$ |
| Reset time: • U> \rightarrow Un • U> \rightarrow 0 | 50 ms 40 ms |
| Operate time inaccuracy | +15 ms |

Residual overvoltage protection function U0> (59N)

| | |
|---|---------------------|
| Pick-up starting inaccuracy | $< 0,5 \%$ |
| Reset time U> \rightarrow Un U> \rightarrow 0 | 50 ms 40 ms |
| Operate time inaccuracy | $\pm 15 \text{ ms}$ |

Overfrequency protection function f> (81O)

| | |
|----------------------------|-------------------|
| Operating range | 40 - 60 Hz |
| Operating range inaccuracy | 30mHz |
| Effective range inaccuracy | 2mHz |
| Minimum operating time | 100ms |
| Operation time inaccuracy | $\pm 10\text{ms}$ |
| Reset ratio | 0,99 |

Underfrequency protection function $f <$ (81U)

| | |
|----------------------------|------------|
| Operating range | 40 - 70 Hz |
| Operating range inaccuracy | 30 mHz |
| Effective range inaccuracy | 2 mHz |
| Minimum operating time | 140 ms |
| Operation time inaccuracy | +10 ms |
| Reset ratio | 0.99 |

Rate-of-change of frequency protection function $df/dt >$ (81R)

| | |
|---------------------------|--------------|
| Effective operating range | -5...+5 Hz/s |
| Pick-up inaccuracy | 0.01 Hz/s |
| Minimum operating time | 140 ms |
| Operation time inaccuracy | +15 ms |

Thermal overload protection function $T >$ (49)

| | |
|---|---------------|
| Operation time inaccuracy at $I > 1.2 \cdot I_{trip}$ | 3 % or +20 ms |
|---|---------------|

Line differential protection $IdL >$ (87L)

| | |
|---------------------------|--|
| Operating characteristic | Biased 2 breakpoints and unrestrained decision |
| Reset ratio | 0.95 |
| Characteristic inaccuracy | $< 2\%$ ($I_{bias} > 2 \cdot I_n$) |
| Operate time | Typically 35ms ($I_{bias} > 0.3 \cdot I_n$) |
| Reset time | Typically 60ms |

Distance protection $Z >$ (21)

| | |
|--|---|
| Number of zones | 5 |
| Current effective range | 20...2000% of I_n |
| Voltage effective range | 2...110% of U_n |
| Operation inaccuracy (current & voltage) | $\pm 1\%$ |
| Impedance effective range | 0.1 – 200 Ohm ($I_n = 1A$) 0.1 – 40 Ohm ($I_n = 5A$) |
| Impedance operation inaccuracy | $\pm 5\%$ |
| Zone static range | 48...52Hz 49.5...50.5Hz |

| | |
|-------------------------|---|
| Zone static inaccuracy | $\pm 5\%$ (48..52Hz) $\pm 2\%$ (49.5...50.5Hz) |
| Zone angular inaccuracy | $\pm 3^\circ$ |
| Minimum operate time | <20ms |
| Typical operate time | 25ms |
| Operate time inaccuracy | $\pm 3\text{ms}$ |
| Reset time | 16-25ms |
| Reset ratio | 1.1 |

Teleprotection (85)

| | |
|-----------------------|--|
| Operate time accuracy | $\pm 5\%$ or $\pm 15\text{ ms}$, whichever is greater |
|-----------------------|--|

Inrush current detection function INR2, (68)

| | |
|--------------------|---------------|
| Current inaccuracy | <2 % |
| Reset ratio | 0,95 |
| Operating time | Approx. 20 ms |

11.2 Control functions

Switch on to fault logic

| | |
|----------------|---|
| Timer accuracy | $\pm 5\%$ or $\pm 15\text{ms}$, whichever is greater |
|----------------|---|

Synchroncheck function du/df (25)

| | |
|---------------------------|-----------------------------|
| Rated Voltage Un | 100/200V, setting parameter |
| Voltage effective range | 10-110 % of Un |
| Voltage inaccuracy | $\pm 1\%$ of Un |
| Frequency effective range | 47.5 – 52.5 Hz |
| Frequency inaccuracy | $\pm 10\text{mHz}$ |
| Phase angle inaccuracy | $\pm 3^\circ$ |
| Operate time inaccuracy | $\pm 3\text{ms}$ |
| Reset time | <50ms |
| Reset ratio | 0.95 |

11.3 Monitoring functions

Current transformer supervision function CTS

| | |
|--------------------------------------|------|
| Pick-up starting inaccuracy at I_n | <2% |
| Minimum operation time | 70ms |
| Reset ratio | 0.95 |

Voltage transformer supervision function VTS

| | |
|----------------------------|--------|
| Pick-up voltage inaccuracy | 1 % |
| Operation time inaccuracy | <20 ms |
| Reset ratio | 0.95 |

Voltage variation (sag and swell)

| | |
|--------------------------------|---|
| Voltage measurement inaccuracy | ± 1 % of U_n |
| Timer inaccuracy | ± 2 % of setting value or ± 20 ms |

Dead line detection (DLD)

| | |
|----------------------------|-------|
| Pick-up voltage inaccuracy | 1% |
| Operation time inaccuracy | <20ms |
| Reset ratio | 0.95 |

Trip logic (94)

| | |
|--------------------------------|------|
| Impulse time duration accuracy | <3ms |
|--------------------------------|------|

11.4 Hardware

Power supply module

| | |
|---------------------------|------------------------|
| Input voltage | 80-255VAC 90-300VDC |
| Nominal voltage | 110VDC/220VDC |
| Maximum interruption | 100ms |
| Maximum power consumption | 30W |

Current measurement module

| | |
|---|--|
| Nominal current | 1/5A (parameter settable) 0.2A (ordering option) |
| Number of channels per module | 4 |
| Rated frequency | 50Hz 60Hz (ordering option) |
| Burden | <0.1VA at rated current |
| Thermal withstand | 20A (continuous) 500A (for 1s) 1200A (for 10ms) |
| Current measurement range | 0-50xIn |
| Power consumption at rated current | 0.01 VA with 1A rated current 0.25 VA with 5A rated current |
| Phase angle accuracy at $I_x \geq 10\% \pm 1$ digit | $\leq 0.5^\circ$ |
| Relative accuracy [%] ± 1 digit | ± 1 ($> 0.5I_n$) with 1A rated current ± 1 ($> 0.4I_n$) with 5A rated current |

Voltage measurement module

| | |
|-------------------------------|---|
| Rated voltage U_n | 100/ $\sqrt{3}$, 100V, 200/ $\sqrt{3}$, 200V (parameter settable) |
| Number of channels per module | 4 |
| Rated frequency | 50Hz 60Hz (ordering option) |
| Burden | <1VA at 200V |
| Voltage withstand | 250V (continuous) 275VAC/350VDC (1s) |
| Voltage measurement range | 0.05-1.2x U_n |
| Power consumption | 0.61VA at 200V 0.2 VA at 100V |
| Relative accuracy | $\pm 0.5\%$ ($> 0.6U_n$) |
| Frequency measurement range | $\pm 0.01\%$ at $U_x \geq 25\%$ of rated voltage |
| Phase angle accuracy | $\leq 0.5^\circ$ at $U_x \geq 25\%$ of rated voltage |

Binary input module

| | |
|-----------------------------|---------------------------------|
| Rated voltage U_n | 110 or 220Vdc (ordering option) |
| Number of inputs per module | 12 (in groups of 3) |
| Current drain | approx. 2mA per channel |

| | |
|-------------------|-------------------------|
| Breaking capacity | 0.2A (L/R=40ms, 220Vdc) |
|-------------------|-------------------------|

Binary output module

| | |
|------------------------------|-------------------------|
| Rated voltage Un | 250Vac/dc |
| Number of outputs per module | 7 (NO) + 1(NC) |
| Continuous carry | 8A |
| Breaking capacity | 0.2A (L/R=40ms, 220Vdc) |

High speed trip module

| | |
|------------------------------|-----------------------|
| Rated voltage Un | 110/220VDC |
| Max. withstand voltage | 242V DC |
| Number of outputs per module | 4 |
| Continuous carry | 8A |
| Making capacity | 30A (0.5s) |
| Breaking capacity | 4A (L/R=40ms, 220Vdc) |

11.5 Tests and environmental conditions

Disturbance tests

| | |
|---|---|
| EMC test | CE approved and tested according to EN 50081-2, EN 50082-2 |
| Emission - Conducted (EN 55011 class A) - Emitted (EN 55011 class A) | 0.15 - 30MHz 30 - 1 000MHz |
| Immunity | |
| - Static discharge (ESD) (According to IEC244-22-2 and EN61000-4-2, class III) | Air discharge 8kV Contact discharge 6kV |
| - Fast transients (EFT) (According to EN61000-4-4, class III and IEC801-4, level 4) | Power supply input 4kV, 5/50ns other inputs and outputs 4kV, 5/50ns |
| - Surge (According to EN61000-4-5 [09/96], level 4) | Between wires 2 kV / 1.2/50µs Between wire and earth 4 kV / 1.2/50µs |
| - RF electromagnetic field test (According. to EN 61000-4-3, class III) | f = 80....1000 MHz 10V /m |
| - Conducted RF field (According. to EN 61000-4-6, class III) | f = 150 kHz....80 MHz 10V |

Voltage tests

| | |
|---|------------------|
| Insulation test voltage acc- to IEC 60255-5 | 2 kV, 50Hz, 1min |
|---|------------------|

| | |
|--|----------------------|
| Impulse test voltage acc- to IEC 60255-5 | 5 kV, 1.2/50us, 0.5J |
|--|----------------------|

Mechanical tests

| | |
|--|---|
| Vibration test | 2 ... 13.2 Hz \pm 3.5mm 13.2 ... 100Hz, \pm 1.0g |
| Shock/Bump test acc. to IEC 60255-21-2 | 20g, 1000 bumps/dir. |

Casing and package

| | |
|---------------------------|--|
| Protection degree (front) | IP 54 (with optional cover) |
| Weight | 5kg net (AQ-x35x devices) 6kg net (AQ-x39x devices) 6kg with package (AQ-x35x devices) 7kg with package (AQ-x39x devices) |

Environmental conditions

| | |
|---------------------------------------|-------------|
| Specified ambient service temp. range | -10...+55°C |
| Transport and storage temp. range | -40...+70°C |

12 Ordering information

Visit <https://configurator.arcteq.fi/> to build a hardware configuration, define an ordering code and get a module layout image.

13 Contact and reference information

Manufacturer

Arcteq Relays Ltd.

Visiting and postal address

Kvartsikatu 2 A 1
65300 Vaasa, Finland

Contacts

| | |
|--------------------|---|
| Phone: | +358 10 3221 370 |
| Website: | arcteq.fi |
| Technical support: | support.arcteq.fi +358 10 3221 388 (EET 9:00 – 17.00) |
| E-mail (sales): | sales@arcteq.fi |