

AQ-110xLV

Arc sensor device with overcurrent

Instruction manual




Table of contents

1 Document information	4
2 Safety information	5
3 Abbreviations	6
4 General	7
5 Device features	8
6 Connections	9
6.1 Simplified block diagram	10
6.2 Inputs	13
6.2.1 Current measurement inputs	13
6.2.2 Arc sensor channels	13
6.2.3 Binary inputs	15
6.3 Outputs	15
6.3.1 Binary outputs	15
6.3.2 High-speed output(s)	16
6.3.3 Trip relays	17
6.3.4 System failure relay	17
6.4 Auxiliary voltage	18
7 Arc sensors	19
7.1 Arc light point sensor AQ-01	19
7.2 Arc light and pressure point sensor AQ-02	20
7.3 Arc light fiber optic loop sensor AQ-06	21
7.4 Arc light fiber optic loop sensor AQ-07	22
7.5 Arc light fiber optic loop sensor AQ-08	22
7.6 Sensor dependencies	22
7.7 Wiring of point sensors	22
8 Operation and configuration	24
8.1 Current threshold settings	24
8.2 DIP switch settings	24
8.3 Available logic schemes	26
8.3.1 SS:0a	27
8.3.2 SS:0b	29
8.3.3 SS:1a	31
8.3.4 SS:1b	33
8.3.5 SS:2a	35
8.3.6 SS:2b	37
8.4 Push button (SET)	39
8.4.1 System setup (auto-configuration)	40
8.4.2 Reset	40
8.4.3 Input connection check	40
8.5 Circuit breaker failure protection	41
8.6 LED indicator functions	41
8.7 LED operations guide	41
8.8 Non-volatile memory	43
9 System self-supervision	44
10 Wiring example	46
11 Dimensions and installation	48
12 Testing	53
12.1 Testing the light-only mode	53
12.2 Testing the light and current mode	53

12.3 Testing the CBFP function	54
12.4 Testing the operation time	54
12.5 Test plan example	55
13 Troubleshooting	56
14 Technical data	57
14.1 Operating times	57
14.2 Auxiliary voltage	57
14.3 Binary inputs	57
14.4 Trip relays	57
14.5 High-speed output(s)	58
14.6 Binary output(s)	58
14.7 System failure relay	58
14.8 Point sensors	59
14.9 Fiber optic loop sensors	60
14.10 Disturbance tests	61
14.11 Voltage tests	61
14.12 Mechanical tests	61
14.13 Environmental conditions	61
14.14 Casing	62
15 Ordering information	63
16 Contact and reference information	65

Disclaimer

Please read these instructions carefully before using the equipment or taking any other actions with respect to the equipment. Only trained and qualified persons are allowed to perform installation, operation, service or maintenance of the equipment. Such qualified persons have the responsibility to take all appropriate measures, including e.g. use of authentication, encryption, anti-virus programs, safe switching programs etc. necessary to ensure a safe and secure environment and usability of the equipment. The warranty granted to the equipment remains in force only provided that the instructions contained in this document have been strictly complied with.

Nothing contained in this document shall increase the liability or extend the warranty obligations of the manufacturer Arcteq Relays Ltd. The manufacturer expressly disclaims any and all liability for any damages and/or losses caused due to a failure to comply with the instructions contained herein or caused by persons who do not fulfil the aforementioned requirements. Furthermore, the manufacturer shall not be liable for possible errors in this document.

Please note that you must always comply with applicable local legislation and regulations. The manufacturer gives no warranties that the content of this document is in all respects in line with local laws and regulations and assumes no liability for such possible deviations.

You are advised to notify the manufacturer in case you become aware of any errors in this document or of defects in the equipment.

The manufacturer reserves the right to update or amend this document at any time.

Copyright

Copyright © Arcteq Relays Ltd. 2024. All rights reserved.

1 Document information

Table. 1 - 1. History of Revision 1.

Revision	1.00
Date	September 2020
Changes	- The first revision of the manual.
Revision	1.01
Date	January 2023
Changes	<ul style="list-style-type: none"> - Updated the Arcteq logo on the cover. - Replaced "one fifths" with "; 1 A or 5 A secondary nominal can be selected" in the "Unit features" chapter. - Updated the distance between the flash and the unit in the "Testing the unit operation time" chapter. - Unified terminology used throughout the manual (e.g. unit and device means the same thing. Now all AQ 100 series relays are called "devices"). - Improved many existing drawings. - Rearranged topics into a more logical order. - Added connection drawings to input and output descriptions under "Connections" chapter. - Added hyperlinks to chapters. (e.g. "See Device features chapter for more information") - Listed more features in Device features chapter. - T3 is now considered to be normally open by default and normally closed as an order option. - Added information about binary output pulse messages. - Many tables have been simplified and made easier to read. - Scheme matrixes and simplified logic diagrams have been made more detailed in "Available schemes" chapter.
Revision	1.02
Date	April 2023
Changes	<ul style="list-style-type: none"> - Small changes to visual style. - Small improvements to descriptions.
Revision	1.03
Date	September 2024
Changes	<ul style="list-style-type: none"> - Fixed SS:1a logic matrix. BO1 is not activated from I> in this scheme. - Added point sensor dimensions.

2 Safety information

This document contains important instructions that should be saved for future use. Read the document carefully before installing, operating, servicing, or maintaining this equipment. Please read and follow all the instructions carefully to prevent accidents, injury and damage to property.

Additionally, this document may contain four (4) types of special messages to call the reader's attention to useful information as follows:



NOTICE!

"Notice" messages indicate relevant factors and conditions to the concept discussed in the text, as well as to other relevant advice.



CAUTION!

"Caution" messages indicate a potentially hazardous situation which, if not avoided, could result in minor or moderate personal injury, in equipment/property damage, or software corruption.



WARNING!

"Warning" messages indicate a potentially hazardous situation which, if not avoided, could result in death or serious personal injury as well as serious damage to equipment/property.



DANGER!

"Danger" messages indicate an imminently hazardous situation which, if not avoided, will result in death or serious personal injury.

These symbols are added throughout the document to ensure all users' personal safety and to avoid unintentional damage to the equipment or connected devices.

Please note that although these warnings relate to direct damage to personnel and/or equipment, it should be understood that operating damaged equipment may also lead to further, indirect damage to personnel and/or equipment. Therefore, we expect any user to fully comply with these special messages.

3 Abbreviations

AQD	– arc quenching device
BI	– binary input
BO	– binary output
CB	– circuit breaker
CBFP	– circuit breaker failure protection
CT	– current transformer
EPROM	– erasable, programmable read-only memory
HSO	– high-speed output
LED	– light emitting diode
LV	– low-voltage
MV	– medium-voltage
NC	– normally closed
NO	– normally open
PCB	– printed circuit board
RF	– radio frequency
Rx	– receiver
SAS	– standard arc scheme
SF	– system failure
Tx	– transceiver
μP	– microprocessor

4 General

The AQ-110PLV is a sophisticated microprocessor-based arc flash protection device with point sensor channels and an optional fiber loop sensor channel. The AQ-110FLV is a sophisticated microprocessor-based arc flash protection device with fiber loop sensor channels. The devices are designed to minimize the damage caused by an arc fault. This is done by tripping the circuit breaker which supplies current to the fault when sensors detect arc light.

AQ-110PLV and AQ-110FLV devices have three phase current measurement channels. Devices can be set to require overcurrent to trip the circuit breaker when arc flash is detected.

The device includes a complete system self-supervision functionality which provides the highest level of dependability as it continuously monitors all internal system functions as well as all external connections.

Figure. 4 - 1. Arc protection devices AQ-110PLV (left) and AQ-110FLV (right).



The AQ-110PLV and AQ-110FLV are designed according to the latest protection relay standards and are therefore suitable for installations in rough environments. These include utilities and power plants (both traditional and renewable), various heavy industry applications (off-shore, marine, oil, gas, mining, steel, etc.) as well as commercial and institutional electrical systems. While these devices are suitable for MV use, it is designed for LV switchgears and for motor control center applications in both new and retrofitted installations.

5 Device features

AQ-110PLV and AQ-110FLV are arc flash protection devices which can be applied to a variety of applications. Both can be used on their own as a stand-alone device, or they can be a part of a more complex arc protection system by using binary inputs and outputs to connect multiple AQ 100 series devices together.

The AQ-110PLV supports four (4) arc sensing point sensor channels as well as one (1) optional fiber sensor channel for arc detection or arc quencher control. The AQ-110FLV supports three (3) arc sensing fiber sensor channels as well as one (1) optional fiber channel for arc quencher control. All other features are the same in both variants.

The following list presents the main features of the AQ-110PLV device:

- 92...265 V AC/DC auxiliary power supply or 18...72 V DC auxiliary power supply (optional)
- three (3) phase current inputs; 1 A or 5 A secondary nominal can be selected
- one (1) trimmer for configuring overcurrent function trip level
- four (4) arc flash point sensor channels, max. three (3) point sensors per channel
- one (1) fiber loop sensor channel for arc flash detection or AQ-1000 arc quenching device control (optional)
- two (2) binary inputs with nominal operation voltage of 24 V DC
- two (2) high-speed semiconductor trip outputs (HSO [HSO1] and HST [HSO2])
- four (4) trip relay outputs
- one (1) binary output (with internal 24 V DC power supply)
- one (1) system failure output (change-over)
- nineteen (19) indication LEDs
- sixteen (16) DIP switches for logic configuration
- one (1) push button.

The following list presents the main features of the AQ-110FLV device:

- 92...265 V AC/DC auxiliary power supply or 18...72 V DC auxiliary power supply (optional)
- three (3) phase current inputs; 1 A or 5 A secondary nominal can be selected
- one (1) trimmer for configuring overcurrent function trip level
- three (3) fiber loop sensor channels for arc flash detection
- one (1) fiber connector for AQ-1000 arc quenching device control (optional)
- two (2) binary inputs with nominal operation voltage of 24 V DC
- two (2) high-speed semiconductor trip outputs (HSO [HSO1] and HST [HSO2])
- four (4) trip relay outputs
- one (1) binary output (with internal 24 V DC power supply)
- one (1) system failure output (change-over)
- eighteen (18) indication LEDs
- sixteen (16) DIP switches for logic configuration
- one (1) push button.

6 Connections

The figures below depict the connections of AQ-110PLV and AQ-110FLV. Please note that the SF relay is in the de-energized position; also note that the device has been halved for the image to allow for space for all connector explanations.

Figure. 6 - 2. Rear terminals of AQ-110PLV.





Figure. 6 - 3. Rear terminals of AQ-110FLV.



6.1 Simplified block diagram

The figures below presents the main components that can be found in the AQ-110xLV devices (AQ-110PLV and AQ-110FLV).

Figure. 6.1 - 4. Simplified block diagram of AQ-110PLV.






Figure. 6.1 - 5. Simplified block diagram of AQ-110FLV.



6.2 Inputs

6.2.1 Current measurement inputs

Figure. 6.2.1 - 6. Current measurement connections



This device contains three (3) CT inputs for measuring the three phase currents. The phase current inputs can be configured to a nominal current of 1 A or 5 A with the DIP switches (for more information, please refer to the [DIP switch settings](#) chapter).


The [Current threshold settings](#) chapter describes the setting of current threshold levels in more detail.

This device includes a current transformer supervision function. See [System self-supervision](#) chapter for more information.

6.2.2 Arc sensor channels

AQ-110PLV

Figure. 6.2.2 - 7. Arc point sensor connections



AQ-110PLV has four (4) arc point sensor channels: S1, S2, S3 and S4. Up to three (3) arc point sensors can be connected to each channel. When the arc protection system has been set up, point sensor connections are constantly monitored. In case of sensor fault or disconnection, the device will go into Error mode. See [System self-supervision](#) chapter for more information.

Figure. 6.2.2 - 8. Optional fiber loop channel connection




S5 is the optional fiber loop sensor channel with a transmitter (Tx) terminal and a receiver (Rx) terminal. The function of S5 is controlled with the DIP switches (please refer to the [DIP switch settings](#) chapter for more information). When S5 is configured as a fiber loop arc sensor channel, one of its ends is connected to "Tx" and the other to "Rx". This sensor loop is then continuously monitored by a test light pulse that travels through the loop. If a discontinuity is detected, the device goes into Error mode. See [System self-supervision](#) chapter for more information.

Alternatively, S5 can be configured to control the arc quenching device (AQD). Device sends a test pulse continuously to the arc quenching device to supervise the fiber connection. If the arc quenching device doesn't receive the test pulses the device will go into Error mode.

For more information on sensors, please refer to the [Arc sensors](#) chapter as well as to the AQ-0x instruction booklet which can be found on Arcteq's website (<https://www.arcteq.fi/downloads/>). For more information on AQ-1000 arc quenching device (AQD) please refer to the AQ-1000 Instruction manual.

AQ-110FLV

Figure. 6.2.2 - 9. Arc fiber loop sensor and arc quenching device connections




AQ-110FLV has three (3) fiber loop arc sensor channels: S1, S2 and S3. Each channel has a transmitter (Tx) terminal and a receiver (Rx) terminal. These sensor loops are continuously monitored by a test light pulse that travels through the loop. If a discontinuity is detected, the device goes into Error mode. See [System self-supervision](#) chapter for more information.

AQ-110F can be ordered with an additional transmitter (Tx) terminal for arc quenching device (AQD) control. Device sends a test light pulse continuously to the arc quenching device to supervise the fiber connection. If the arc quenching device doesn't receive the test pulses the device will go into Error mode.

For more information on sensors, please refer to the [Arc sensors](#) chapter as well as to the AQ-0x instruction booklet which can be found on Arcteq's website (<https://www.arcteq.fi/downloads/>). For more information on AQ-1000 arc quenching device (AQD) please refer to the AQ-1000 Instruction manual.

6.2.3 Binary inputs

Figure. 6.2.3 - 10. Binary input connections



This device contains two (2) binary inputs. Typically, the binary inputs are used for receiving arc light signals, master trip commands or overcurrent signals. Function of binary inputs are configured using DIP switches. For more information, please refer to the [DIP switch settings](#) chapter.

Please note that when this device receives an overcurrent signal from a non-AQ 100 series device, the actual operating time depends on the operating time of the that device. Therefore, the total operating time cannot be specified in the technical data.


The binary inputs are activated when a connected DC signal reaches the specified nominal voltage level of the corresponding input. The nominal voltage level for this device is 24 VDC. Please note that the actual activation threshold of the binary input is at a lower voltage than the specified nominal voltage value (see [Technical Data](#) chapter).

AQ 100 series devices monitor health of wiring between binary inputs and binary outputs. If binary input loses connection to any of the configured binary outputs, the device will go into Error mode. See [System self-supervision](#) chapter for more information.

6.3 Outputs

6.3.1 Binary outputs

Figure. 6.3.1 - 11. Binary output connection



The device has one (1) binary output: BO1. AQ 100 series binary outputs have an internal 24 VDC power supply. This binary output is used for sending overcurrent, light detection, master trip and other signals to other AQ 100 series devices in the same system. The binary output function can be configured with the DIP switches. For more information on the configuration, please refer to the [DIP switch settings](#) chapter.


AQ 100 series device's binary outputs send out a short pulse every second. Binary inputs of the receiving AQ 100 series devices use these pulses to count the number of connected binary outputs. See [System self-supervision](#) chapter for more information.

**NOTICE!**

Please note that the binary outputs are polarity-sensitive.

6.3.2 High-speed output(s)

Figure. 6.3.2 - 12. The high-speed output's direction of rotation.



The device contains two (2) high-speed semiconductor outputs, namely HSO and HST. These outputs can be used as heavy-duty signaling outputs. Due to their high current-carrying capacity, HSO and HST can send overcurrent or light information to a maximum of twenty (20) pieces of AQ 100 series devices without a need for signal amplifiers. The operation of these high-speed outputs depends on the DIP switch settings (for more information, please refer to the [DIP switch settings](#) chapter).

AQ 100 series device's high-speed outputs send out a short pulse every second. Binary inputs of the receiving AQ 100 series devices use these pulses to count the number of connected high-speed outputs. See [System self-supervision](#) chapter for more information.


The output's direction of rotation is as follows: the signal goes in the even pin and out from the odd pin (see the image below, as detailed in the device's side sticker).

**NOTICE!**

The high-speed outputs are polarity-sensitive.

6.3.3 Trip relays

Figure. 6.3.3 - 13. Trip relay connections




This device has four (4) normally open trip relay outputs. Trip relays T1 and T2 are used for tripping circuit breakers. T4 is generally used for tripping one additional disconnecting device, or as a trip alarm (local or remote) monitoring and alarming system.

T3 can alternatively be ordered as a normally closed trip relay (electronic lock-out relay). Once opened by fault detection it holds its open position until it receives a manual reset command or until auxiliary power supply is lost. When re-applying the auxiliary power supply, the electronic lock-out relay returns to the same position it had prior to the power loss. This normally closed relay output can also be used for tripping contactor-controlled devices.

T3 and T4 are always latching relays. Trip relays T1 and T2 can be set as latching relays by setting DIP switch SW2:8 ("T1/T2: Latching / Non-latching") to "Latching" position. Latched relays can be reset by pressing the "SET" button.

6.3.4 System failure relay


Figure. 6.3.4 - 14. System failure relay connection (de-energized position)



The system failure (SF) relay is of the change-over type (NO/NC) and it is energized when the device is in a healthy condition and powered on. Whenever the device detects a system error or the auxiliary power supply is disconnected, the SF relay changes its state. The state stays this way until the device returns to a healthy condition. See the [System self-supervision](#) chapter for more information.

6.4 Auxiliary voltage

Figure. 6.4 - 15. Auxiliary power supply connection



The auxiliary power supply voltage is 92....265 V AC/DC. Alternatively, the optional auxiliary power supply can be of 18...72 V DC. This choice must be specified when ordering.

7 Arc sensors

The AQ 100 series provides arc light point sensors and arc light fiber optic loop sensors. These sensors can be used with different devices and different switchgear types according to specific application requirements.

Arc light point sensors are typically installed in metal-clad compartments, and they provide a quick and accurate location of the fault area. Arc light fiber loop sensors typically cover a wider protected area with one fiber, when there is no need to pinpoint the exact location for a fault.

7.1 Arc light point sensor AQ-01

AQ-01 is an arc light point sensor with a light-sensitive photodiode element activated by arc light. The AQ-01 sensors should be mounted in the switchgear cubicles in such a way that the light-sensitive part covers the protected area as completely as possible. While multiple sensors can be installed, in most cases one sensor per closed metal-clad compartment is sufficient. In open spaces (such as a busbar section) the sensors should be mounted no more than two meters apart.

The default light intensity threshold for an AQ-01 sensor is 8,000 lux. Depending on the demand of the application, light point sensors can be ordered with 25,000 lux or 50,000 lux thresholds. Its detection radius is 180 degrees.

Figure. 7.1 - 16. The AQ-01 light sensor.



An AQ-01 is installed either inside or outside the compartment wall. When mounting inside the wall, the sensor is placed on the wall with the colored side against the wall and then fixed to the wall with two screws. When mounting outside the wall the sensor is placed on the wall with the grey side against the wall and the eye is pushed into the drilled compartment hole and then fixed to the wall with two screws from the back of the sensor. No external mounting plates are needed regardless of the mounting type; however, mounting brackets can be used if so desired.


Up to three (3) sensors can be connected in series (with the exception of AQ-103 which can take only one point sensor per channel). Installing a connection cable is simple as each end of the sensor has a detachable cover over the cable connectors. Please remember to reattach the cover once the wires have been installed.



NOTICE!

The AQ-01 point sensor does not come with a connection cable!

Figure. 7.1 - 17. Dimensions of arc flash sensors.



7.2 Arc light and pressure point sensor AQ-02

AQ-02 is an arc light and pressure point sensor that comes with arc light detection and ambient pressure detection. AQ-02 point sensor activates when both light and pressure are detected. The AQ-02 sensors should be mounted in the switchgear cubicles in such a way that the light-sensitive part covers the protected area as completely as possible. While multiple sensors can be installed, in most cases one sensor per closed metal-clad compartment is sufficient. The AQ-02 sensors cannot be installed in open spaces.

The default light intensity threshold for an AQ-02 sensor is 8,000 lux. Depending on the demand of the application, AQ-02 can also be ordered with 25,000 lux or 50,000 lux thresholds. Its detection radius is 180 degrees. The pressure threshold is fixed at 0.2 bar above ambient pressure.

Figure. 7.2 - 18. AQ-02 arc light and pressure point sensor.



An AQ-02 can only be installed inside the compartment wall as not to block pressure detection located next to "the eye". The sensor is placed on the wall (with the colored side against the wall), and then fixed to the wall with two screws. No external mounting plates are needed regardless of the mounting type; however, mounting brackets can be used if so desired.


Up to three (3) sensors can be connected in series (with the exception of AQ-103 which can take only one point sensor per channel). Installing a connection cable is simple as each end of the sensor has a detachable cover over the cable connectors. Please remember to reattach the cover once the wires have been installed.



NOTICE!

The AQ-02 point sensor does not come with a connection cable!

Figure. 7.2 - 19. Dimensions of arc flash sensors.



7.3 Arc light fiber optic loop sensor AQ-06

AQ-06 is an arc light fiber optic loop sensor, which is a plastic fiber optic cable. Fiber sensors are distributed through the protected switchgear cells. The fixed light intensity threshold of an AQ-06 sensor is 8,000 lux. The sensor's detection radius is 360 degrees.

AQ-06 sensors can be ordered in pre-manufactured lengths of 3...40 meters (3 m, 5 m, 10 m, 15 m, 20 m, 25 m, 30 m, 35 m, 40 m).

7.4 Arc light fiber optic loop sensor AQ-07

AQ-07 is an arc light fiber optic loop sensor, which is a robust fiber optic cable with a practically unlimited bending radius. The sensor contains hundreds of glass fiber drains covered by a plastic tube, thus making it extremely strong and durable. Fiber sensors are distributed through the protected switchgear cells.

AQ-07 sensors can be ordered in pre-manufactured lengths of 3...50 meters (3 m, 5 m, 10 m, 15 m, 20 m, 25 m, 30 m, 35 m, 40 m, 45 m, 50 m).

The fixed light intensity threshold of an AQ-07 sensor is 8,000 lux. The sensor's detection radius is 360 degrees.

If necessary, the ends of an AQ-07 cable can be ordered with heat shrinking tubing to avoid light detection outside the protected zone. The covered area can be one (1) or two (2) meters by default; if other lengths are required, please consult the Arcteq sales team. You can find the [Contact and reference information](#) page at the end of this manual.

7.5 Arc light fiber optic loop sensor AQ-08

AQ-08 is an arc light fiber optic loop sensor. It is designed to withstand temperatures up to 125 °C, which makes it suitable for e.g. wind turbine windings. AQ-08 is a robust fiber optic cable with a practically unlimited bending radius. The sensor contains hundreds of glass fiber drains that are covered by a plastic tube, thus making it extremely strong and durable. Fiber sensors are distributed through the protected switchgear cells.

AQ-08 sensors can be ordered in pre-manufactured lengths of 3...15 meters (3 m, 5 m, 10 m, 15 m).

The fixed light intensity threshold of an AQ-08 sensor is 8,000 lux. The sensor's detection radius is 360 degrees.

7.6 Sensor dependencies

Compatibility of arc sensor types depend on the hardware available in the AQ 100 series device. The table below describes those dependencies.


Table. 7.6 - 2. Sensor dependencies.

	Point sensors (AQ-01 & AQ-02)	Fiber loops (AQ-06, AQ-07 & AQ-08)
AQ-101LV	Yes	Order option
AQ-101DLV	Yes	Order option
AQ-102LV	No	Yes
AQ-103LV	Yes	Order option
AQ-110PLV	Yes	Order option
AQ-110FLV	No	Yes

7.7 Wiring of point sensors

Point sensor connection with two-wire cable

Figure. 7.7 - 20. Point sensor connection with two wire cable.



1. Open the sensor covers and detach the connectors.
2. Attach the cable to the connector and to the arc protection device.
3. Reattach the connectors to the sensor.
4. Run the auto-configuration procedure. See [System setup](#) for more details.



NOTICE!

Connect the cable shield to point sensor channel "ground" connector. Don't connect the cable shield to same ground as device.




NOTICE!

Shield of the cable must be either copper or tinned copper.

Point sensor connection with three-wire cable

Figure. 7.7 - 21. Point sensor connection with three wire cable.



1. Open the sensor covers and detach the connectors.
2. Attach the cable to the connector and to the arc protection device.
3. Reattach the connectors to the sensor.
4. Run the auto-configuration procedure. See [System setup](#) for more details.



NOTICE!

If the cable has a shield (copper or tinned copper), it is recommended to connect it to same ground as the device.


8 Operation and configuration

8.1 Current threshold settings

The AQ-110xLV devices have three (3) phase current measurement inputs. The phase current measurements can be used as additional trip criteria in an arc protection system to avoid trips caused by natural light sources. When an arc sensor channel has been set to "Light and overcurrent" mode, overcurrent and light must be detected simultaneously for the device to trip.


Depending on the selected logic scheme the device can also send overcurrent indication signals with binary outputs or high-speed outputs to external devices.

Figure. 8.1 - 22. DIP switch for defining nominal current.



DIP switch SW2:2 can be used for selecting either 1 A or 5 A nominal current. The set points are set by using the trimmers (see the image below). The setting range for the phase overcurrent stage is $0.5...6 \times I_n$. The threshold for phase overcurrent is typically set to 50 % above the highest load current. You can get an accurate setting by injecting the desired set current into the phase current inputs of the device and by simultaneously adjusting the trimmer until the phase current indicator LEDs are lit.

Figure. 8.1 - 23. Overcurrent setting trimmer.



8.2 DIP switch settings

The DIP switches are used to easily configure various tripping logics and other functionalities for the device. Both AQ-110 variants contain two switch groups, SW1 and SW2. They are located at the back of the device. The figure below presents the numbering of the two switch groups, and the tables below that give a detailed description of the settings for both switch groups.

Protection logic can be defined by selecting a logic scheme with DIP switches SW1:1 to SW1:5. The scheme selection is based on binary arithmetic. Logic schemes are described in the next chapter.

Tripping can be set with DIP switches to require either just arc light or both arc light and overcurrent simultaneously. Adding overcurrent criteria ensures the device trips when an arc fault occurs but not when a strong natural light source hits the light sensor (e.g. sunlight). Device can detect overcurrent by measuring phase currents and residual current or by receiving overcurrent signal from an external device (mainly another AQ-110PLV or AQ-110FLV device) which is connected to a binary input.

CBFP (circuit breaker failure protection) function can be enabled with DIP switch SW2:4. CBFP time delay (100 ms or 150 ms) can be set with DIP switch SW2:3. CBFP logic depends on the selected logic scheme. See [Circuit breaker failure protection](#) chapter for more information.

Figure. 8.2 - 24. DIP switch diagram for AQ-110PLV (above) and AQ-110FLV (below).




Table. 8.2 - 3. DIP switch settings for SW1 group.

Switch	Function selection	ON (left position)	OFF (right position)
8	The tripping criterion for the S1 point sensor channel. (AQ-110PLV) The tripping criterion for the S1 fiber loop sensor channel. (AQ-110FLV)	Tripping on light only (L>).	Light detection only trips if overcurrent is also detected at the same time (L> + I>).
7	The tripping criterion for the S2 point sensor channel. (AQ-110PLV) The tripping criterion for the S2 fiber loop sensor channel. (AQ-110FLV)		
6	The tripping criterion for the S3 and S4 (point sensors) and S5 fiber loop channels. (AQ-110PLV) The tripping criterion for the S3 fiber loop channel. (AQ-110FLV)		
5	Selects the logic scheme.	Switch 1: 1	Switch 1: 0
4-1	Please refer to the Available logic schemes chapter.	Switch 2: 2	Switch 2: 0
		Switch 3: 4	Switch 3: 0
		Switch 4: 8	Switch 4: 0
		Switch 5: a	Switch 5: b

Table. 8.2 - 4. DIP switch settings for SW2 group.


Switch	Function selection	ON (left position)	OFF (right position)
8	Enables or disables T1 and T2 latching.	T1 and T2 operate as latching relays.	T1 and T2 latching is disabled.
7	Enables or disables HST (HSO2) high-speed output latching.	HST (HSO2) operates as a latching output.	HST (HSO2) latching is disabled.
6	Selects the function of a binary input.	The blocking function is selected.	A specific signal is selected. The signal is scheme-dependent, and can be either an external current signal or an external light signal.
5	The selection between the fiber loop function and the arc quenching system (AQD) control.	The S5 fiber sensor channel operates as the fiber loop sensor function.	The S5 fiber sensor channel operates as the arc quenching system (AQD) control. The Tx terminal of S5 sends a test pulse signal to the quenching system.
4	Enable or disable CBFP time delay.	CBFP time delay is not used.	Depending on the selected scheme, some outputs (trip contacts and binary output) activate after a time delay if the fault is not cleared. Check the logic scheme diagram for more information.
3	The setting for the CBFP time.	The CBFP time is set to 100 ms.	The CBFP time is set to 150 ms.
2	The nominal current selection for the phase currents IL1, IL2 and IL3.	The nominal current is 1 A.	The nominal current is 5 A.
1	<i>(Reserved for future use.)</i>	—	—

8.3 Available logic schemes

The schemes described below are the most commonly used ones for AQ-110PLV and AQ-110FLV devices. However, additional schemes are also available; please contact your nearest Arcteq representative for more information on those schemes. The schemes are configured using the first DIP switch group (SW1) and its switches numbered 1...4 ("Scheme selection") and 5 ("a or b"). The scheme selection is based on binary arithmetic:

- Switch 1: 1
- Switch 2: 2
- Switch 3: 4
- Switch 4: 8
- Switch 5: a or b

Figure. 8.3 - 25. DIP switches used for selecting the logic scheme.




AQ 100 series arc protection devices can be used as a stand-alone device or as a part of a more complex arc protection system with multiple AQ 100 series devices. The most convenient way to set the device to a more complex arc protection system is to use Standard Arc Schemes (SAS). For detailed instructions on each of the available Standard Arc Schemes please refer to the AQ-SAS™ booklet (can be found at arcteq.fi/downloads/).

8.3.1 SS:0a

The logic scheme SS:0a is designed for selective incoming feeder arc protection. It can be used for substations with one or more incoming feeders.

Figure. 8.3.1 - 26. Example application with AQ-110LV (SS:0a).



If a fault is detected in the incoming feeder cable compartment (S1), circuit breakers on both sides of the transformer will be tripped with T1 and T2. If the fault is not cleared on time, T3 will trip the tie breaker (if applicable) and HSO2 sends master trip signal to the outgoing feeder protection devices after the CBFP time delay has passed..

If a fault is detected in the incoming feeder circuit breaker compartment (S2), circuit breakers on both sides of the transformer (T1-T2), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If a fault is detected in the busbar compartment (S3) or in the tie breaker compartment (S4) the incoming feeder (T1), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If the fault is not cleared on time, T2 will trip the incoming feeder HV side circuit breaker after the CBFP time delay has passed..


HSO1 can be used for sending overcurrent detection signal to protection devices installed to outgoing feeders.

Figure. 8.3.1 - 27. Logic matrix of SS:0a.

SS:0a		OUTPUTS							
		T1	T2	T3	T4	HSO1	HSO2	BO1	AQD
INPUTS	S1	x ¹	x ¹	CBFP ¹	x ¹		CBFP ¹	x ²	x ³
	S2	x ¹	x ¹	x ¹	x ¹		x ¹	x	x ⁴
	S3, S4, S5	x ¹	CBFP ¹	x ¹	x ¹		x ¹	x	x ⁴
	Lex> AQ-110 (BI1)	x ¹	CBFP ¹	x ¹	x ¹		x ¹		x ⁴
	Lex> AQ-101 (BI2)	x ¹	CBFP ¹	x ¹	x ¹		x ¹	x	x ⁴
	I> Overcurrent					x			

1. Activates only if channel is set to light only mode or if overcurrent signal (I>) is ON.
2. If "Fast / CBFP" DIP-switch is set to CBFP mode, channel must be set to light only mode or overcurrent signal (I>) must be active for output activation to occur. If "Fast /CBFP" DIP-switch is set to FAST mode, no current signal is required.
3. Activates only when "Fast / CBFP" DIP-switch is set to FAST mode. When channel is set to light only mode, current detection is not required for activation.
4. Activates only if overcurrent signal (I>) is ON.

Figure. 8.3.1 - 28. Simplified logic diagram of SS:0a.




1. CBFP signals are activated instantly if "Fast /CBFP" DIP-switch is set to FAST mode.
2. If "Fast /CBFP" DIP-switch is set to CBFP mode, channel must be set to light only mode or overcurrent signal (I>) must be active for output activation to occur. If "Fast /CBFP" DIP-switch is set to FAST mode, no current signal is required.

8.3.2 SS:0b

The logic scheme SS:0b is designed for selective incoming feeder arc protection. It can be used for substations with one or more incoming feeders. This scheme is a modification of 0a. In this scheme BI1 is used for receiving overcurrent signals AQ-110 devices installed to other incoming feeders.

Figure. 8.3.2 - 29. Example application with AQ-110LV (SS:0b).



If a fault is detected in the incoming feeder cable compartment (S1), circuit breakers on both sides of the transformer will be tripped with T1 and T2. If the fault is not cleared on time, T3 will trip the tie breaker (if applicable) and HSO2 sends master trip signal to the outgoing feeder protection devices after the CBFP time delay has passed..

If a fault is detected in the incoming feeder circuit breaker compartment (S2), circuit breakers on both sides of the transformer (T1-T2), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If a fault is detected in the busbar compartment (S3) or in the tie breaker compartment (S4) the incoming feeder (T1), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If the fault is not cleared on time, T2 will trip the incoming feeder HV side circuit breaker after the CBFP time delay has passed..


HSO1 can be used for sending overcurrent detection signal to protection devices installed to outgoing feeders.

Figure. 8.3.2 - 30. Logic matrix of SS:0b.

SS:0b		OUTPUTS							
		T1	T2	T3	T4	HSO1	HSO2	BO1	AQD
INPUTS	S1	x ¹	x ¹	CBFP ¹	x ¹		CBFP ¹		x ³
	S2	x ¹	x ¹	x ¹	x ¹		x ¹		x ²
	S3, S4, S5	x ¹	CBFP ¹	x ¹	x ¹		x ¹		x ²
	Lext> AQ-101 (BI2)	x ¹	CBFP ¹	x ¹	x ¹		x ¹		x ²
	lext> AQ-110 (BI1)					x			
	I> Overcurrent					x		x	

1. Activates only if channel is set to light only mode or if overcurrent signal (I> or BI1) is ON.
2. Activates only when overcurrent signal (I> or BI1) is ON.
3. Activates only when "Fast /CBFP" DIP-switch is set to FAST mode. Also when SW1/8 is set to light only mode, current detection is not required for activation.

Figure. 8.3.2 - 31. Simplified logic diagram of SS:0b.




1. CBFP signals are activated instantly if "Fast /CBFP" DIP-switch is set to FAST mode, delayed if DIP-switch 2/4 is set to CBFP mode. SW2/3 can be used for choosing 100 ms or 150 ms delay time.

8.3.3 SS:1a

The logic scheme SS:1a is designed for selective incoming feeder arc protection. It can be used for substations with one or more incoming feeders. This scheme is a modification of SS:0a. AQ-1000 arc quenching device is not tripped from S1 channel in this scheme.

Figure. 8.3.3 - 32. Example application with AQ-110LV (SS:1a).



If a fault is detected in the incoming feeder cable compartment (S1), circuit breakers on both sides of the transformer will be tripped with T1 and T2. If the fault is not cleared on time, T3 will trip the tie breaker (if applicable) and HSO2 sends master trip signal to the outgoing feeder protection devices after the CBFP time delay has passed..

If a fault is detected in the incoming feeder circuit breaker compartment (S2), circuit breakers on both sides of the transformer (T1-T2), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If a fault is detected in the busbar compartment (S3) or in the tie breaker compartment (S4) the incoming feeder (T1), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If the fault is not cleared on time, T2 will trip the incoming feeder HV side circuit breaker after the CBFP time delay has passed..


HSO1 can be used for sending overcurrent detection signal to protection devices installed to outgoing feeders.

Figure. 8.3.3 - 33. Logic matrix of SS:1a.

SS:1a		OUTPUTS							
		T1	T2	T3	T4	HSO1	HSO2	BO1	AQD
INPUTS	S1	x ¹	x ¹	CBFP ¹	x ¹		CBFP ¹	x ²	
	S2	x ¹	x ¹	x ¹	x ¹		x ¹	x	x ³
	S3, S4, S5	x ¹	CBFP ¹	x ¹	x ¹		x ¹	x	x ³
	Lext> AQ-110 (BI1)	x ¹	CBFP ¹	x ¹	x ¹		x ¹		x ³
	Lext> AQ-101 (BI2)	x ¹	CBFP ¹	x ¹	x ¹		x ¹	x	x ³
	I> Overcurrent					x			

1. Activates only if channel is set to light only mode or if overcurrent signal (I>) is ON.
2. If "Fast / CBFP" DIP-switch is set to CBFP mode, channel must be set to light only mode or overcurrent signal (I>) must be active for output activation to occur. If "Fast / CBFP" is set to FAST mode, no current signal is required.
3. Activates only if overcurrent signal (I>) is ON.

Figure. 8.3.3 - 34. Simplified logic diagram of SS:1a.




1. CBFP signals are activated instantly if "Fast / CBFP" DIP-switch is set to FAST mode.
2. If "Fast / CBFP" DIP-switch is set to CBFP mode, channel must be set to light only mode or overcurrent signal (I>) must be active for output activation to occur. If "Fast / CBFP" DIP-switch is set to FAST mode, no current signal is required.

8.3.4 SS:1b

The logic scheme SS:1b is designed for selective incoming feeder arc protection. It can be used for substations with one or more incoming feeders. This scheme is a modification of SS:1a. In this scheme BI1 is used for receiving overcurrent signals AQ-110 devices installed to other incoming feeders.

Figure. 8.3.4 - 35. Example application with AQ-110LV (SS:1b).



If a fault is detected in the incoming feeder cable compartment (S1), circuit breakers on both sides of the transformer will be tripped with T1 and T2. If the fault is not cleared on time, T3 will trip the tie breaker (if applicable) and HSO2 sends master trip signal to the outgoing feeder protection devices after the CBFP time delay has passed..

If a fault is detected in the incoming feeder circuit breaker compartment (S2), circuit breakers on both sides of the transformer (T1-T2), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If a fault is detected in the busbar compartment (S3) or in the tie breaker compartment (S4) the incoming feeder (T1), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If the fault is not cleared on time, T2 will trip the incoming feeder HV side circuit breaker after the CBFP time delay has passed..


HSO1 can be used for sending overcurrent detection signal to protection devices installed to outgoing feeders.

Figure. 8.3.4 - 36. Logic matrix of SS:1b.

SS:1b		OUTPUTS							
		T1	T2	T3	T4	HSO1	HSO2	BO1	AQD
INPUTS	S1	x ¹	x ¹	CBFP ¹	x ¹		CBFP ¹		
	S2	x ¹	x ¹	x ¹	x ¹		x ¹		x ²
	S3, S4, S5	x ¹	CBFP ¹	x ¹	x ¹		x ¹		x ²
	lext> AQ-101 (BI2)	x ¹	CBFP ¹	x ¹	x ¹		x ¹		x ²
	lext> AQ-110 (BI1)					x			
	I> Overcurrent					x		x	

1. Activates only if channel is set to light only mode or if overcurrent signal (I> or BI1) is ON.
2. Activates only if overcurrent signal (I> or Iext>) is ON.

Figure. 8.3.4 - 37. Simplified logic diagram of SS:1b.




1. CBFP signals are activated instantly if "Fast /CBFP" DIP-switch is set to FAST mode.

8.3.5 SS:2a

The logic scheme SS:2a is designed for selective incoming feeder arc protection. It can be used for substations with one or more incoming feeders. This scheme is a modification of SS:0a. Tie breaker is tripped immediately when an arc fault is detected in the incoming feeder cable compartment.

Figure. 8.3.5 - 38. Example application with AQ-110LV (SS:2a).



If a fault is detected in the incoming feeder cable compartment (S1), circuit breakers on both sides of the transformer will be tripped with T1 and T2 and the tie breaker will be tripped with T3 (if applicable). If the fault is not cleared on time HSO2 sends master trip signal to the outgoing feeder protection devices after the CBFP time delay has passed..

If a fault is detected in the incoming feeder circuit breaker compartment (S2), circuit breakers on both sides of the transformer (T1-T2), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If a fault is detected in the busbar compartment (S3) or in the tie breaker compartment (S4) the incoming feeder (T1), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If the fault is not cleared on time, T2 will trip the incoming feeder HV side circuit breaker after the CBFP time delay has passed..


HSO1 can be used for sending overcurrent detection signal to protection devices installed to outgoing feeders.

Figure. 8.3.5 - 39. Logic matrix of SS:2a.

SS:2a		OUTPUTS							
		T1	T2	T3	T4	HSO1	HSO2	BO1	AQD
INPUTS	S1	x ¹	x ¹	x ¹	x ²		CBFP ¹	CBFP ³	x ²
	S2	x ¹	x ¹	x ¹	x ¹		x ¹	x	x ¹
	S3, S4, S5	x ¹	CBFP ¹	x ²	x ¹		x ¹	x	x ¹
	Lex> AQ-110 (BI1)	x ¹	CBFP ¹	x ²	x ¹		x ¹		x ¹
	Lex> AQ-101 (BI2)	x ¹	CBFP ¹	x ²	x ¹		x ¹	x	x ¹
	I> Overcurrent					x			

1. Activates only if channel is set to light only mode or if overcurrent signal (I>) is ON.
2. Activates only if channel is set to light only mode or if overcurrent signal (I>) is ON. No activation if "Fast / CBFP" DIP-switch is set to CBFP mode.
3. If "Fast / CBFP" DIP-switch is set to CBFP mode, light channel must be set to light only mode or any overcurrent signal (I>) must be active for output activation to occur. If "Fast /CBFP" DIP-switch is set to FAST mode, no current signal is required.

Figure. 8.3.5 - 40. Simplified logic diagram of SS:2a.




1. CBFP signals are activated instantly if "Fast /CBFP" DIP-switch is set to FAST mode.
2. If "Fast / CBFP" DIP-switch is set to CBFP mode, light channel must be set to light only mode or overcurrent signal (I>) must be active for output activation to occur. If "Fast /CBFP" DIP-switch is set to FAST mode, no current signal is required.

8.3.6 SS:2b

The logic scheme SS:2b is designed for selective incoming feeder arc protection. It can be used for substations with one or more incoming feeders. This scheme is a modification of SS:2a. In this scheme BI1 is used for receiving overcurrent signals AQ-110 devices installed to other incoming feeders.

Figure. 8.3.6 - 41. Example application with AQ-110LV (SS:2b).



If a fault is detected in the incoming feeder cable compartment (S1), circuit breakers on both sides of the transformer will be tripped with T1 and T2 and the tie breaker will be tripped with T3 (if applicable). If the fault is not cleared on time HSO2 sends master trip signal to the outgoing feeder protection devices after the CBFP time delay has passed..

If a fault is detected in the incoming feeder circuit breaker compartment (S2), circuit breakers on both sides of the transformer (T1-T2), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If a fault is detected in the busbar compartment (S3) or in the tie breaker compartment (S4) the incoming feeder (T1), tie breaker (T3) and all outgoing feeders (HSO2) will be tripped. If the fault is not cleared on time, T2 will trip the incoming feeder HV side circuit breaker after the CBFP time delay has passed..


HSO1 can be used for sending overcurrent detection signal to protection devices installed to outgoing feeders.

Figure. 8.3.6 - 42. Logic matrix of SS:2b.

SS:2b		OUTPUTS							
		T1	T2	T3	T4	HSO1	HSO2	BO1	AQD
INPUTS	S1	x ¹	x ¹	x ¹	x ²		CBFP ¹		x ²
	S2	x ¹	x ¹	x ¹	x ¹		x ¹		x ¹
	S3, S4, S5	x ¹	CBFP ¹	x ¹	x ¹		x ¹		x ¹
	lext> AQ-101 (BI2)	x ¹	CBFP ¹	x ¹	x ¹		x ¹		x ¹
	lext> AQ-110 (BI1)					x			
	I> Overcurrent					x		x	

1. Activates only if channel is set to light only mode or if overcurrent signal (I> or BI1) is ON.
2. Activates only if channel is set to light only mode or if overcurrent signal (I> or BI1) is ON. No activation if "Fast / CBFP" DIP-switch is set to CBFP mode.

Figure. 8.3.6 - 43. Simplified logic diagram of SS:2b.



1. CBFP signals are activated instantly if "Fast /CBFP" DIP-switch is set to FAST mode.

8.4 Push button (SET)

The device contains one push button, SET, and it can be used for all operational functions. The push button is used for:


1. Setting up the system (also known as auto-configuration)
2. Resetting the indicator LEDs
3. Resetting latched outputs
4. Checking the input connections



WARNING!

The SET button may require you to change the DIP switches before it works correctly. Do **NOT** use force when pushing the button, as this may cause the button to lodge deep inside the chassis!

Figure. 8.4 - 44. The "SET" push button on the device's front panel.



8.4.1 System setup (auto-configuration)

After DIP switches have been set to correct position and all sensors, binary inputs and binary outputs have been connected, a system setup procedure (also known as auto-configuration) must be performed. The sequence is initialized by pressing the **SET** push button for two seconds. This causes the sensor and binary I/O LEDs to start blinking. The device scans these inputs to see if they are connected; when an input is detected, the corresponding LED lights up to indicate that a connection was found. All inputs that are not connected continue to blink for three more seconds. Then, all LEDs are turned off. Additionally, the DIP switch settings are stored in the non-volatile memory after this sequence.

All arc sensors are operational even when they have not been auto-configured. System setup is only used for self-supervision purposes.

Please note that to reconfigure a device with fewer connections (BI/BO or arc sensors) than in the previously memorized setup, one of the DIP switches must be moved back and forth once before the system setup procedure is carried out. You can reconfigure a device with more connections at any time without having to move one of the DIP switches.

8.4.2 Reset

All LED indications and latched trip relays can be reset by pressing the **SET** push button.

8.4.3 Input connection check

After the system setup (auto-configuration) procedure is completed, you can verify the connectivity of all sensors and binary input channels by pressing the **SET** push button three (3) times within two (2) seconds. The LEDs of the corresponding sensors, binary input channels and the "Power" LED start blinking. The LEDs blink as many times as there are connected sensors and binary output channels from other devices.

8.5 Circuit breaker failure protection

The circuit breaker failure protection function is used for detecting a failure to open the circuit breaker when tripping command has been given by the arc protection relay. The CBFP function activates when the arc protection relay detects the presence of fault for a set duration (100 ms or 150 ms). In case of circuit breaker failure the arc protection relay will send a trip signal to the next available circuit breaker. Please note that if the device is set to operate on both arc light and overcurrent, both conditions must persist to activate the CBFP function. The CBFP function can be set to operate either on a 100-ms or a 150-ms delay (please refer to the [DIP switch settings](#) chapter for more information). The operation logic of CBFP function depends on the chosen logic scheme (see Scheme selection chapter for more information).

8.6 LED indicator functions

The AQ-110PLV device has nineteen (19) indication LEDs and the AQ-110FLV device has eighteen (18) indication LEDs on the device's front panel.. Apart from the "Power" and "Error" LEDs, the user can write their own identifications for each of the remaining LEDs on the text insert located in the transparent pocket next to the LEDs.

When the device is powered up, it performs an LED test. All LEDs turn on for two (2) seconds and then turn off; only the blue "Power" LED stays on.

When the device operates normally, only the blue "Power" LED is lit.

All current measuring channels (that is, IL1, IL2 and IL3) have their own indication LEDs. When any channel measurement exceeds the set threshold value for longer than 1.5 ms, its corresponding LED turns on. In an open CT condition both the corresponding current channel indicator LED and the "Error" LED are blinking.

If an arc sensor is activated, its corresponding LED turns on. Activated arc sensor LEDs will stay on until user has reset them with "SET" push button.

If there is a loose sensor wire or if the self-supervision function detects a configuration mismatch (that is, a new sensor has been attached but the auto-configuration system setup has not been run), the corresponding LED starts flashing and the "Error" LED activates.

The binary I/O LEDs indicate the status of the input and output lines. If any of the lines become active, the corresponding LED turns on. All light channel and trip indication LEDs are latched, even if the DIP switch settings are in the non-latched mode.

All LED indications are stored in the non-volatile memory (EPROM) to help identify the necessary trip information even after auxiliary power is lost. When the device is re-powered after a power supply loss, the front panel shows the status of all LEDs.

You can clear the LEDs by pushing the SET button.

8.7 LED operations guide

The table below describes the function of each indicator LED in detail. Please note that the S4 and S5 sensor channels are not in use in the AQ-110FLV variant.

Table. 8.7 - 5. LED operations of AQ-110PLV and AQ-110FLV.

LED name (color)	Light off	Steady light	Blinking light	Action if abnormal
POWER (blue)	The auxiliary power supply is disconnected.	The auxiliary power supply is connected.	(N/A)	Check the power supply.
ERROR (red)	The system is healthy.	A system failure has occurred.	A configuration mismatch has been detected. Protection is partially operational.	Verify the system condition (see the System self-supervision and Troubleshooting chapters).
T1–T4 (red)	Normal status.	The trip relay has activated.	(N/A)	Check what caused the trip, clear the fault and reset the indicator LEDs with the push button.
S1–S3 (amber)	Normal status.	Light information has activated the sensor channel.	There is a sensor channel discontinuity or a system setup has not been performed.	Check the sensor continuity or perform a system setup (see the System setup chapter); or , check what activated the sensor.
S4 (amber) NB! Only in AQ-110PLV!	Normal status.	Light information has activated the sensor channel.	There is a sensor channel discontinuity or a system setup has not been performed.	Check the sensor continuity or perform a system setup (see the System setup chapter); or , check what activated the sensor.
S5 (amber) NB! Only in AQ-110PLV!	Normal status.	Light information has activated the fiber sensor channel. Or , if the device has AQD control configured to this fiber channel, an arc flash has activated the channel.	There is a fiber discontinuity or a system setup has not been performed.	Check the sensor continuity or perform a system setup (see the System setup chapter); or , check what activated the sensor.
AQD (amber) NB! Only in AQ-110PLV!	Normal status.	AQD (arc quenching device) has been given a trip signal.	The fiber connection to the AQD (arc quenching device) has dropped off or a system setup has not been performed.	Check the fiber connection and/or the system configuration.
BI1–BI2 (amber)	Normal status.	The binary input has been activated.	The binary input has a loose connection.	Check the binary input wiring.
BO1 (amber)	Normal status.	The binary output has been activated.	(N/A)	—
IL1–IL3 (amber)	Normal status (the actual current is below the set threshold).	The measured current is above the set threshold.	There is an open CT connection in the channel.	Check the set current thresholds, or check the CT wiring.

LED name (color)	Light off	Steady light	Blinking light	Action if abnormal
HSO (HSO1) (amber)	Normal status.	The high-speed output has been activated.	(N/A)	Check what activated the output, clear the fault and reset the indicator LEDs with the push button.
HST (HSO2) (amber)	Normal status.	The high-speed output has been activated.	(N/A)	Check what activated the output, clear the fault and reset the indicator LEDs with the push button.

8.8 Non-volatile memory

All critical system data (such as DIP switch settings and the system setup file) are stored in the non-volatile memory (EPROM) to ensure accurate operation and full self-supervision even if auxiliary power is lost temporarily.

Additionally, all LED indications are stored in the non-volatile memory to provide a quick recovery of the system status indication. This feature is especially important if tripping causes the device to lose its auxiliary power.

The non-volatile memory does not require a power supply to maintain the information and it retains the settings and the indications permanently without power.

9 System self-supervision

AQ 100 series devices have an extensive self-supervision function, including both internal functions and external connections. The self-supervision function monitors the following:

- power supply
- hardware
- software
- binary input connection(s)
- sensor connection(s)
- DIP switch settings
- current transformer supervision

When the device's condition is healthy and is powered on, the "Power" LED is lit and the system failure (SF) relay is energized. If the self-supervision function detects a faulty condition or if the power supply fails, the SF relay is released and the "Error" LED becomes lit.

Point sensor connection monitoring

If a point sensor failure occurs, the device will go into Error mode. The "Error" LED turns on, the SF relay releases, and the LED of the corresponding faulty sensor channel starts blinking. In this situation the device is still operational, although the faulty sensor channel is blocked. If the error is resolved, the device automatically energizes the SF relay and turns off the "Error" LED and the blinking sensor channel LED. If one or more of the sensors are disconnected, the healthy sensors remain in use and the device remains operational accordingly. However, the device remains in Error mode until the sensors are connected again.

Fiber loop connection monitoring

Fiber loop channel(s) is monitored by a test light pulse that travels through the loop from TX (transmitter) connector to RX (receiver) connector. If a discontinuity is detected, the "Error" LED turns on, the SF relay releases, and the LED of the corresponding faulty sensor channel starts blinking. If the error is resolved, the device automatically clears the system failure status, energizing the SF relay and turning off the "Error" LED. The device remains in Error mode until the sensors are connected again.

Binary input connection monitoring

During system setup (auto-configuration) AQ 100 series device checks how many AQ 100 device binary outputs or high-speed outputs have been connected to binary inputs. Each AQ 100 series device binary output and high-speed output constantly sends a short pulse every second which the receiving binary input uses to count the number of connected devices. If any of the outputs are disconnected after the system setup, the binary input will detect the mismatch and the device will go into Error mode and the binary input LED will blink. If the error is resolved, the device automatically clears the system failure status, energizing the SF relay and turning off the "Error" LED.

DIP switch setting monitoring

The device goes into Error mode, if a DIP switch setting is changed after the system setup procedure has been performed. However, the configured (stored) settings are still valid and the device is still operational.

Current transformer supervision

In AQ 100 series devices with current measurements the self-supervision function also monitors the three phase current transformer circuit. If the current flow exceeds $0.2 \times I_n$ in any of the phases, the device assumes that the switchgear is energized and the function monitors the phases for an open connection. If at least one of the phases remains above $0.2 \times I_n$ while at least one of the others are at zero, the device issues an open CT alarm: the SF relay is released, the "Error" LED is turned on and the LED of the faulty phase(s) starts blinking.

10 Wiring example

Figure. 10 - 45. Example wiring diagram for AQ-110PLV.





Figure. 10 - 46. Example wiring diagram for AQ-110FLV.



11 Dimensions and installation

The device can be either door-mounted or panel-mounted in a standard 19 inch rack. The device's dimensions (without PCBs) are as follows:

- Height: 177 mm (6.97 in)
- Width: 102 mm (4.02 in)
- Depth: 168 mm (6.61 in).

The figure below presents the dimension of the device visually. It also shows the dimensions of the cut-out (bottom-left) required when mounting the device on a panel.

Figure. 11 - 47. Dimensions of the device.





Figure. 11 - 48. Installing a AQ-100 series device to a door.



Point sensors

Figure. 11 - 49. Dimensions of arc flash sensors.





Figure. 11 - 50. Installing an arc flash sensor.






NOTICE!


Although the image above depicts the installation of an AQ-01 point sensor, please note that an AQ-02 pressure and point sensor is installed in the same way.

Fiber loops


1. Drill holes on the wall for the sensor cable to enter the protected compartment.
2. Install protective covers in the holes to ensure the sensor cable remains unharmed by rough edges.



3. Run the sensor cable through the holes and along the protected area. Fasten it to the compartment walls with cable clips or some other appropriate anchoring method.



4. Turn the black and blue receiver ("Rx") and transceiver ("Tx") screws counter-clockwise and plug in the sensor cable terminals. Then turn the screws clockwise to secure the terminals in their place.



12 Testing

It is recommended that the device is tested prior to substation energizing. Testing is carried out by simulating an arc light for each sensor and verifying that the correct trip contact(s) tripped and that the correct indicator LED(s) turned on.

Any strong camera flash works well to simulate arc light. Please note that small LED lights like smartphone flashes are not strong enough to activate a point sensor or a fiber loop. Having a self-timer helps with the testing process because it can be connected to the test kit. Any strong flashlight works to test non-latched signals and the CBFP function. Before testing please check that the equipment used has a fully charged battery.

12.1 Testing the light-only mode

1. Check that the DIP switch settings are positioned according to your application.
2. Activate the camera flash within 30 cm (12 inches) of the sensor that is being tested.
3. Verify that the indicator LED of the corresponding sensor channel is lit.
4. Verify the activation(s) of the relay output(s) by checking the circuit breaker's status, or by monitoring the trip contact's status. The circuit breaker should open, or the contacts operate. Please note that you achieve the best test results when you operate the circuit breaker while testing.
5. Verify that the indicator LED(s) of the corresponding relay output(s) is lit.
6. If you are using the BO1 binary output and/or one or both of the high-speed outputs, verify their signal activation either through the status change of the relevant input, or by measuring the signal output voltage. Please note that BO1 is of the non-latched type.
7. If you are using the BO1 binary output and/or one or both of the high-speed outputs, also verify that their corresponding LED is lit.
8. Press the **SET** push button to reset all indications and latches.
9. If you are using the BI2 binary input as the master trip, activate it and verify that the trip has occurred by repeating the steps 4 and 5.
10. Press the **SET** push button to reset all indications and latches.
11. Repeat the steps 1 through 10 for all sensors.

12.2 Testing the light and current mode

1. Check that the DIP switch settings are positioned according to your application.
2. Activate the following two things simultaneously: the camera flash within 30 cm (12 inches) of the sensor that is being tested, and the binary input used for the overcurrent condition (I>).
3. Verify that the indicator LED of the corresponding sensor channel is lit.
4. Verify that the indicator LED of the binary input is lit.
5. Verify the activation(s) of the relay output(s) by checking the circuit breaker's status, or by monitoring the trip contact's status. The circuit breaker should open, or the contacts operate. Please note that you achieve the best test results when you operate the circuit breaker while testing.
6. Verify that the indicator LED(s) of the corresponding relay output(s) is lit.
7. If you are using the BO1 binary output or a high-speed output (HSO1 and/or HSO2), verify the signal activation either through the status change of the relevant input, or by measuring the signal output voltage.
8. If you are using the BO1 binary output or a high-speed output (HSO1 and/or HSO2), also verify that the corresponding LED is lit. Please note that BO1 is of the non-latched type.
9. Activate the camera flash within 30 cm (12 inches) of the sensor but do not activate the binary input used for the overcurrent condition (I>).
10. Verify that no trip has occurred and only the indicator LED of the sensor activation is lit.

11. If you are using the BO1 signal and have configured it to send light information, verify that it is activated.
12. Press the **SET** push button to reset all indications and latches.
13. If you are using a binary input as the master trip, activate it and verify that the trip has occurred by repeating the steps 5 and 6.
14. Press the **SET** push button to reset all indications and latches.
15. Repeat the steps 1 through 12 for all sensors.

12.3 Testing the CBFP function

The circuit breaker failure protection (CBFP) function is tested by taking the light signal and the additional trip criterion signal (if applicable) and leaving them active for longer than the set CBFP time (that is, 100 or 150 ms). Check that the correct outputs activated after the set delay time.

12.4 Testing the operation time

An operation time test is not required at commissioning as it is performed by the manufacturer both as a type test and as a routine production test. If you want to have more information of these tests, please refer to the routine test reports sent with the AQ-110 device and/or consult your nearest Arcteq representative for the type test reports.

However, if it is deemed necessary, you can conduct an on-site timing test with the following instructions.

1. Use a calibrated relay test set.
2. Connect one of the test set's outputs to a strong camera flash to initialize the flash and to configure the set's timer to start simultaneously with the flash.
3. Connect one of the AQ-110 device's trip outputs (T1, T2, T3, T4) or high-speed outputs (HSO1, HSO2) to a test set input and configure the input to stop the timer.
4. Place the camera flash within 30 cm (12 inches) of the sensor.
5. Initiate the flash and the timer by using the test set output.
6. Read the measured time between the simulated arc light and the operation of the trip contact.
7. Subtract the digital input delay of the test set from the final measured time (if applicable). For specific test instructions, please consult the manufacturer of the relay test set.

12.5 Test plan example

Basic data	
Date:	
Substation:	
Switchgear:	
Serial number:	



Preconditions	Additional notes
Trip mode (channel 1): <input type="checkbox"/> L> <input type="checkbox"/> L> + I>	
Trip mode (channels 2, 3, 4): <input type="checkbox"/> L> <input type="checkbox"/> L> + I>	
BI master trip in use: <input type="checkbox"/> Yes <input type="checkbox"/> No	
CBFP in use: <input type="checkbox"/> Yes <input type="checkbox"/> No	
CBFP time setting: <input type="checkbox"/> 100 ms <input type="checkbox"/> 150 ms	

Object activated	LED active	T1, T2, T3, T4 active	BO1 active	Additional notes
Sensor channel 1	S1			
	S2			
	S3			
Sensor channel 2	S1			
	S2			
	S3			
Sensor channel 3	S1			
	S2			
	S3			
Sensor channel 4	S1			
	S2			
	S3			
Fiber sensor channel				
Binary inputs	BI1			
	BI2			
Phase current (IL1, IL2, IL3)				
Residual current (IO)				

Involved personnel	
Tested by:	
Approved by:	

13 Troubleshooting

Table. 13 - 6. Troubleshooting guide for AQ-110x variants.

Problem	Possible solution(s)
The sensor does not activate during testing.	Check the sensor's cable wiring. <u>or</u> Check the testing equipment, especially the camera flash intensity (see the Testing chapter for more information).
The trip relay does not operate even when the sensor is activated.	Tripping might require overcurrent signal simultaneously with light signal. Check the DIP switch settings (see the DIP switch settings chapter for more information).
The current measurement's indicator LED is continuously lit.	Check the set current threshold (see the Current threshold settings chapter for more information).
The current measurement's indicator LED is blinking.	Check that the connections of the three phase currents are correct (see the System self-supervision for more information).

14 Technical data

14.1 Operating times

Table. 14.1 - 7. Technical data for relay operating times.

Trip time using HSO	2 ms*
Trip time using mechanical trip relays	7 ms*
Reset time: - light stage - overcurrent stage	1 ms 50 ms

*) The total trip time when using both the arc light (L>) or phase/residual overcurrent (I>) from this device and the arc light (L>) from an AQ-101 variant or an AQ-102 device.

14.2 Auxiliary voltage

Table. 14.2 - 8. Technical data for the relay auxiliary voltage (Uaux).

Auxiliary power supply	92...265 V AC/DC 18...72 V DC (optional)
Maximum power consumption	5 W, < 10 mΩ
Standby current	90 mA
Start-up inrush current	<150 ms (110 V DC) <600 ms (24 V DC)

14.3 Binary inputs

Table. 14.3 - 9. Technical data for the binary inputs (BI1, BI2).

Nominal threshold voltage	24 V DC
Threshold: - pick-up - drip-off	Approximately 16 V DC Approximately 15 V DC
Rated current	3 mA
Number of inputs	2

14.4 Trip relays

Table. 14.4 - 10. Technical data for the trip relays (T1, T2, T3, T4).

Number of trip relays	4 NO <u>or</u> 3 NO + 1 NC
-----------------------	----------------------------

Voltage withstand	250 V AC/DC
Carry: - continuous carry - make-and-carry for 3 s - make-and-carry for 0.5 s	5 A 16 A 30 A
Breaking capacity DC*	40 W (0.36 A at 110 V DC)
Contact material	AgNi 90/10

*) When the time constant $L/R = 40$ ms.

14.5 High-speed output(s)

Table. 14.5 - 11. Technical data for the high-speed outputs (HSO, HST).

Number of outputs	2
Rated voltage	250 V DC
Carry: - continuous carry - make-and-carry for 3 s - make-and-carry for 0.5 s	2 A 6 A 15 A
Breaking capacity DC*	1 A/110 W
Contact material	Semiconductor

*) When the time constant $L/R = 40$ ms.

14.6 Binary output(s)

Table. 14.6 - 12. Technical data for the binary output (BO1).

Number of outputs	1
Rated voltage	+24 V DC (internal power supply)
Rated current (max.)	20 mA

14.7 System failure relay

Table. 14.7 - 13. Technical data for the system failure relay (SF).

Number of SF relays	1
Rated voltage	250 V AC/DC
Carry: - continuous carry - make-and-carry for 3 s - make-and-carry for 0.5 s	5 A 16 A 30 A

Breaking capacity DC*	40 W (0.36 A at 110 V DC)
Contact material	AgNi 90/10

*) When the time constant L/R = 40 ms.

14.8 Point sensors

AQ-01 point sensor

Table. 14.8 - 14. Technical data for the AQ-01 light point sensor.

Light intensity threshold	8,000 lux 25,000 lux 50,000 lux
Detection radius	180°
Mechanical protection	IP 20
Sensor cable specification	Shielded twisted pair 0.75 mm ² (AWG: 18)
Maximum sensor cable length (per channel)	200 m
Operating temperature	−20...+85 °C

AQ-02 point sensor

Table. 14.8 - 15. Technical data for the AQ-02 light and pressure point sensor.

Light intensity threshold	8,000 lux 25,000 lux 50,000 lux
Pressure threshold (fixed)	0.2 bar above ambient pressure
Pressure measuring accuracy	±1.8 % (of full scale)
Detection radius	180°
Mechanical protection	IP 20
Sensor cable specification	Shielded twisted pair 0.75 mm ² (AWG: 18)
Maximum sensor cable length (per channel)	200 m
Operating temperature	−20...+85 °C

14.9 Fiber optic loop sensors

AQ-06 fiber optic loop sensor

Table. 14.9 - 16. Technical data for the AQ-06 fiber optic loop sensor.

Material	Plastic fiber
Light intensity threshold	8,000 lux
Cable length (min...max)	3...40 m
Cable diameter	1.0 mm
Detection radius	360°
Bending radius	5 cm
Operating temperature	−40...+85 °C

AQ-07 fiber optic loop sensor

Table. 14.9 - 17. Technical data for the AQ-07 fiber optic loop sensor.

Material	Covered glass fiber
Light intensity threshold	8,000 lux
Cable length (min...max)	3...50 m
Cable diameter	1.2 mm
Detection radius	360°
Bending radius	1 cm
Operating temperature	−40...+85 °C

AQ-08 fiber optic loop sensor

Table. 14.9 - 18. Technical data for the AQ-08 fiber optic loop sensor.

Material	Covered glass fiber
Light intensity threshold	8,000 lux
Cable length (min...max)	3...15 m
Cable diameter	1.2 mm
Detection radius	360°
Bending radius	1 cm
Operating temperature	−40...+125 °C

14.10 Disturbance tests

Table. 14.10 - 19. Technical data for the disturbance tests.

Electromagnetic compatibility test	CE-approved and tested according to EN 50081-2 and EN 50082-2
Conducted emission (EN 55011, class A)	0.15...30.00 Hz
Radiated emission (EN 55011, class A)	30.00...1,000.00 MHz
Electrostatic discharge immunity (IEC 244-222 and EN 61000-4-2, level 4)	Air discharge: 15 kV Contact discharge: 8 kV
Electrical fast transients (EN 61000-4-4, class III & IEC 801-4, level 4)	Power supply input: 4 kV, 5/50 ns Other inputs and outputs: 4 kV, 5/50 ns
Surge immunity (EN 61000-4-5, level 4)	Between wires: 2 kV, 1.2/50 μ s Between wire and earth: 4 kV, 1.2/50 μ s
RF electromagnetic field (EN 61000-4-3, level 3)	f = 80...1,000 MHz, 10 V/m
Conducted RF field (EN 61000-4-6, level 3)	f = 150 kHz...80 MHz, 10 V/m

14.11 Voltage tests

Table. 14.11 - 20. Technical data for the voltage tests.

Insulation test voltage (IEC 60255-5)	2 kV, 50 Hz, 1 min
Impulse test voltage (IEC 60255-5)	5 kV, 1.2/50 μ s, 0.5 J

14.12 Mechanical tests

Table. 14.12 - 21. Technical data for the mechanical tests.

Vibration test	2...13.2 Hz (\pm 3.5 mm) 13.2...100 Hz (\pm 1.0 g)
Shock/bump test (IEC 60255-21-2)	20 g and 1,000 bumps/dir.

14.13 Environmental conditions

Table. 14.13 - 22. Technical data for the environmental conditions.

Specified ambient service temperature	-35...+70 °C
Transportation and storage temperature	-40...+70 °C

Relative humidity	Up to 97 %
Altitude	Up to 2,000 m above sea level


14.14 Casing

Table. 14.14 - 23. Technical data for the device casing.


Protection: - front - back	IP 52 IP 20
Device dimensions (W × H × D)	102 × 177 × 161 mm
Weight	1.2 kg

15 Ordering information


AQ-110xLV current measurement and arc sensing device



AQ-0x point sensors



AQ-0x fiber optic loop sensors



Accessories

Order code	Description	Note	Manufacturer
AQX006	Wall mounting bracket	For AQ-103 and AQ-110x variants (MV and LV).	Arcteq Ltd.
AQX016	Wall mounting bracket	For AQ-101, AQ-101S and AQ-102 devices (MV and LV).	Arcteq Ltd.

16 Contact and reference information

Manufacturer

Arcteq Relays Ltd.

Visiting and postal address

Kvartsikatu 2 A 1
65300 Vaasa, Finland

Contacts

Phone:	+358 10 3221 370
Website:	arcteq.com
Technical support:	arcteq.com/support-login +358 10 3221 388 (EET 9:00 – 17.00)
E-mail (sales):	sales@arcteq.fi