
AQ-110PLV SS:1b



SS:1b		OUTPUTS					
		T1	T2	T3	T4	BO1	AQD
INPUTS	S1	x[1]	x[1]	CBFP[1]	x[1]		
	S2	x[1]	x[1]	x[1]	x[1]		x[2]
	S3, S4, S5	x[1]	CBFP[1]	x[1]	x[1]		x[2]
	Lext> AQ-103LV (BI2)	x[1]	CBFP[1]	x[1]	x[1]		x[2]
	I> Overcurrent					x	

1) Activates only if channel has been set to light only mode or any overcurrent signal (I> or BI1) is ON.
2) Activates only if any overcurrent signal (I> or BI1) is ON.

AQ-103LV SS:0



SS:0		OUTPUTS				
		T1	T2	T3	T4	BO1
INPUTS	S1 - S15	x[1]	x[1]	x[1]	x[1]	x

1) Activates only if channel has been set to light only mode or overcurrent signal (BI1) is ON.

